

# VOLUME 3

Firmware Revisions 20.74/24.74

## Configuration and Advanced Operation

Omni 3000 / 6000 Flow Computer  
User Manual

Turbine/Positive Displacement/  
Coriolis Liquid Flow Metering  
Systems with K Factor  
Linearization

Effective May 2009



# Volume 3

## CONFIGURATION AND ADVANCED OPERATION

### Contents of Volume 3

**Figures of Volume 3.....vii**

- About Our Company..... ix**
- Contacting Our Corporate Headquarters ..... ix**
  - Getting User Support ..... ix
- About the Flow Computer Applications ..... x**
- About the User Manual..... x**
  - Target Audience ..... x
  - Manual Structure ..... xi
  - Conventions Used in this Manual .....xiii
  - Trademark References .....xiv
  - Copyright Information and Modifications Policy .....xiv
- Warranty, Licenses and Product Registration..... xiv**

- Overview of Firmware Revisions 20/24 ..... 1-1**
  - 1.1. Number of Meter Runs - Type of Flowmeters..... 1-1**
  - 1.2. Product Configuration ..... 1-1**
  - 1.3. Configurable Sensors per Meter Run..... 1-2**
  - 1.4. Configurable Sensors per Prover ..... 1-2**
  - 1.5. Temperature..... 1-2**

1.6. Densitometers .....	1-2
1.7. Station Capability.....	1-2
1.8. Auxiliary Inputs .....	1-2
1.9. Number of products - Information Stored/Product.....	1-2
1.10. Type of Products Measured .....	1-2
1.11. Batching and Interface Detection .....	1-3
1.12. Auto Proving Features.....	1-3
1.13. Retroactive Meter Factors and Override Gravity .....	1-3
1.14. Retroactive Density Correction Factor .....	1-3
1.15. Flow Rate/Viscosity Linearizing .....	1-3
1.16. PID Control Functions .....	1-3
1.17. Flow Weighted Averages .....	1-4
1.18. User-Programmable Digital I/O .....	1-4
1.19. User-Programmable Logic Functions.....	1-4
1.20. User-Programmable Alarm Functions .....	1-4
1.21. User-Programmable Variables.....	1-4
1.22. User Display Setups .....	1-4
1.23. User Report Templates.....	1-4
1.24. Serial Communication Links.....	1-4
1.25. Peer-to-Peer Communications.....	1-5
1.26. Archive Data .....	1-5
1.27. OmniCom® Windows Version Software Communications Package .....	1-5
1.28. OmniView® Windows Version Software Communications Package .....	1-5
1.29. Ethernet Module .....	1-5
1.30. Network Printing .....	1-5
<b>Flow Computer Configuration.....</b>	<b>2-1</b>
2.1. Introduction .....	2-1
2.2. Configuring with the Keypad in Program Mode.....	2-1
2.2.1. Entering the Program Mode .....	2-1
2.2.2. Changing Data.....	2-1
2.2.3. Menu Selection Method .....	2-2
2.2.4. Random Access Method .....	2-2
2.2.5. Passwords .....	2-4

<b>2.3. Getting Help .....</b>	<b>2-5</b>
<b>2.4. Program Inhibit Switch .....</b>	<b>2-5</b>
<b>2.5. Configuring the Physical Inputs / Outputs .....</b>	<b>2-6</b>
2.5.1. Miscellaneous Configuration (Misc. Setup Menu) .....	2-7
2.5.2. Physical I/O Points not Available for Configuration .....	2-8
2.5.3. Password Maintenance Settings .....	2-8
2.5.4. Entries Requiring a Valid Privileged Password .....	2-9
2.5.5. Meter Station Settings .....	2-10
2.5.6. Meter Run Settings .....	2-12
2.5.7. Prover Settings .....	2-14
2.5.8. PID Control Settings .....	2-16
2.5.9. Analog Output Settings .....	2-17
2.5.10. Front Panel Counter Settings .....	2-18
2.5.11. Programmable Boolean Statements .....	2-18
2.5.12. Programmable Variable Statements .....	2-21
2.5.13. User Display Settings .....	2-24
2.5.14. Digital I/O Point Settings .....	2-27
2.5.15. Serial Input / Output Settings .....	2-30
2.5.16. Custom Modbus™ Data Packet Settings .....	2-32
2.5.17. Peer-to-Peer Communications Settings .....	2-33
2.5.18. Programmable Logic Controller Setup .....	2-37
2.5.19. Archive File Setup .....	2-37
<b>2.6. Setting Up the Time and Date .....</b>	<b>2-38</b>
2.6.1. Accessing the Time/Date Setup Submenu .....	2-38
2.6.2. Time and Date Settings .....	2-38
<b>2.7. Configuring the Meter Station .....</b>	<b>2-39</b>
2.7.1. Accessing the Station Setup Submenu .....	2-39
2.7.2. Meter Station Settings .....	2-39
<b>2.8. Configuring Meter Runs .....</b>	<b>2-42</b>
2.8.1. Accessing the Meter Run Setup Submenu .....	2-42
2.8.2. Meter Run Settings .....	2-42
<b>2.9. Configuring Temperature .....</b>	<b>2-47</b>
2.9.1. Accessing the Temperature Setup Submenu .....	2-47
2.9.2. Station and Meter Run Temperature Settings .....	2-47
2.9.3. Station and Meter Run Density Temperature Settings .....	2-49
2.9.4. Prover Temperature Settings .....	2-50

2.9.5. Prover Density Temperature Settings .....	2-51
<b>2.10. Configuring Pressure .....</b>	<b>2-52</b>
2.10.1. Accessing the Pressure Setup Submenu.....	2-52
2.10.2. Station and Meter Run Pressure Settings .....	2-52
2.10.3. Station and Meter Run Density Pressure Settings.....	2-53
2.10.4. Prover Pressure Settings.....	2-55
2.10.5. Prover Density Pressure Settings.....	2-56
<b>2.11. Configuring Meter Relative Density / API Relative Density.....</b>	<b>2-57</b>
2.11.1. Accessing the Gravity/Density Setup Submenu.....	2-57
2.11.2. Meter Relative Density / Density Settings .....	2-57
<b>2.12. Configuring PID Control Outputs .....</b>	<b>2-60</b>
2.12.1. Accessing the PID Control Setup Submenu.....	2-60
2.12.2. PID Control Output Settings .....	2-60
<b>2.13. Configuring Provers .....</b>	<b>2-62</b>
2.13.1. Accessing the Prover Setup Submenu.....	2-62
2.13.2. Prover Settings .....	2-62
<b>2.14. Configuring Products .....</b>	<b>2-66</b>
2.14.1. Accessing the Product Setup Submenu.....	2-66
2.14.2. Product Settings .....	2-66
<b>2.15. Configuring Batches.....</b>	<b>2-70</b>
<b>2.16. Configuring Miscellaneous Factors .....</b>	<b>2-70</b>
2.16.1. Accessing the Factor Setup Submenu .....	2-70
2.16.2. Factor Settings.....	2-71
<b>2.17. Configuring Printers .....</b>	<b>2-72</b>
2.17.1. Accessing the Printer Setup Submenu.....	2-72
2.17.2. Printer Settings .....	2-73
<b>User-Programmable Functions.....</b>	<b>3-76</b>
<b>3.1. Introduction .....</b>	<b>3-76</b>
<b>3.2. User Programmable Boolean Flags and Statements.....</b>	<b>3-76</b>
3.2.1. What is a Boolean?.....	3-76
3.2.2. Sign (+, -) of Analog or Calculated Variables (6001 → 8999).....	3-78
3.2.3. Boolean Statements and Functions.....	3-78
3.2.4. How the Digital I/O Assignments are Configured.....	3-83
<b>3.3. User Programmable Variables and Statements .....</b>	<b>3-85</b>

3.3.1.	Variable Statements and Mathematical Operators Allowed.....	3-85
3.3.2.	Using Boolean Variables in Variable Statements.....	3-87
3.3.3.	Entering Values Directly into the User Variables.....	3-88
3.3.4.	Using the Variable Expression as a Prompt.....	3-88
3.3.5.	Password Level Needed to Change the Value of a User Variable .....	3-88
3.3.6.	Using Variables in Boolean Expressions.....	3-89
<b>3.4.</b>	<b>User Configurable Display Screens .....</b>	<b>3-90</b>
<b>Flow Equations and Algorithms for US Customary Units (Revision 20.74+) ....</b>		<b>4-1</b>
<b>4.1.</b>	<b>Liquid Flow Rate for Flowmeters.....</b>	<b>4-1</b>
4.1.1.	Volumetric Flow Rate at Flowing Conditions ' $Q_v$ ' (Bbls/hr) .....	4-1
4.1.2.	Volumetric Flow Rate at Base Conditions ' $Q_b$ ' (Bbls/hr).....	4-1
4.1.3.	Mass Flow Rate ' $Q_m$ ' (KLbs/hr).....	4-1
4.1.4.	Calculations for Liquid Flows When "Mass Pulses" is Selected (Mass Calculation Standard not Selected).....	4-2
4.1.5.	Mass Measurement Standard with "Mass Pulses" Selected.....	4-2
4.1.6.	"Mass Calculation" Algorithm with Volumetric Flowmeter Pulses .....	4-2
	For Propylene .....	4-3
	Density of Ethane, Propane and C3+ Mixes .....	4-3
	Density and other physical properties of Ethylene (IUPAC).....	4-3
4.1.7.	Nomenclature .....	4-3
<b>4.2.</b>	<b>Correction Factors for Liquid Flow .....</b>	<b>4-4</b>
4.2.1.	Volume Correction Factor ' $C_{TL}$ ' .....	4-5
4.2.2.	Correction Factor for Pressure on Liquid ' $C_{PL}$ ' .....	4-6
4.2.3.	Correction Factor for Sediment and Water Content ' $C_{S\&W}$ ' .....	4-7
4.2.4.	Linearizing Coefficient ' $L_{CF}$ ' .....	4-7
<b>4.3.</b>	<b>Densities and Other Properties of Liquids .....</b>	<b>4-7</b>
4.3.1.	Flowing Density ' $\rho_f$ ' for Crude Oil and Refined Products.....	4-8
4.3.2.	Density and Relative Density (Specific Gravity) Calculated from Live Digital Densitometer Output Frequency .....	4-9
<b>4.4.</b>	<b>Recalculation of Batch Ticket .....</b>	<b>4-12</b>
4.4.1.	Recalculated Gross Standard Volume ' $GSV_{Recalc}$ ' (Bbls) .....	4-12
4.4.2.	Recalculated Net Standard Volume .....	4-13
<b>4.5.</b>	<b>Liquid Flow Rate for Provers .....</b>	<b>4-13</b>
4.5.1.	Prove Gross Flow Rate at Flowing Conditions (Bbls/hr) .....	4-13
4.5.2.	Prove Flow Rate using Pulse Interpolation Method .....	4-13

4.5.3. Meter Factors for Provers ..... 4-14

**4.6. Calculations for PID Control ..... 4-16**

4.6.1. Primary Variable Error % 'e<sub>p</sub>' ..... 4-16

4.6.2. Secondary Variable Error % 'e<sub>s</sub>' ..... 4-17

4.6.3. Control Output % 'C<sub>0</sub>' (Before Startup Limit Function) ..... 4-17

4.6.4. Integral Error 'Σe' ..... 4-17

**Flow Equations and Algorithms for SI (Metric) Units (Revision 24.74) ..... 5-1**

**5.1. Liquid Flow Rate for Flowmeters ..... 5-1**

5.1.1. Volumetric Flow Rate at Flowing Conditions 'Q<sub>v</sub>' (m<sup>3</sup>/hr) ..... 5-1

5.1.2. Volumetric Flow Rate at Base Conditions 'Q<sub>b</sub>' (Nm<sup>3</sup>/hr) ..... 5-1

5.1.3. Mass Flow Rate 'Q<sub>m</sub>' (Ton/hr) ..... 5-1

5.1.4. Flow Rates for Mass Pulses ..... 5-2

5.1.5. Nomenclature ..... 5-3

**5.2. Correction Factors for Liquid Flow ..... 5-3**

5.2.1. Volume Correction Factor 'V<sub>CF</sub>' ..... 5-4

5.2.2. Correction Factor for Pressure on Liquid 'C<sub>PL</sub>' ..... 5-5

**5.3. Densities and Other Properties of Liquids ..... 5-5**

5.3.1. Flowing Density 'ρ' for Crude Oil and Refined Products ..... 5-5

5.3.2. Density of Ethane, Propane and C3+ Mixes ..... 5-6

5.3.3. Density and Relative Density (Specific Gravity) Calculated from Live Digital Densitometer Output Frequency ..... 5-6

**5.4. Liquid Flow Rate for Provers ..... 5-10**

5.4.1. Prove Gross Flow Rate at Flowing Conditions (m<sup>3</sup>/hr) ..... 5-10

5.4.2. Nomenclature ..... 5-11

5.4.3. Meter Factors for Provers ..... 5-12

**5.5. Calculations for PID Control ..... 5-14**

5.5.1. Primary Variable Error % 'e<sub>p</sub>' ..... 5-14

5.5.2. Secondary Variable Error % 'e<sub>s</sub>' ..... 5-14

5.5.3. Control Output % 'C<sub>0</sub>' (Before Startup Limit Function) ..... 5-14

5.5.4. Integral Error 'Σe' ..... 5-14

# Figures of Volume 3

Fig. 1-1. Typical Configuration Using Helical Turbine, Positive Displacement and Coriolis Flowmeters 1-1

Fig. 2-1. Figure Showing Program Inhibit Switch ..... 2-6

Fig. 3-1. Figure Showing Four-Meter Run Valve Switching ..... 3-82

Fig. 3-2. Keypad Layout - A through Z Keys ..... 3-91





# For Your Information



## About Our Company

OMNI Flow Computers, Inc. is the world's leading manufacturer and supplier of panel-mount custody transfer flow computers and controllers. Our mission is to continue to achieve higher levels of customer and user satisfaction by applying the basic company values: our people, our products and productivity.

**OMNI Flow Computers** – Our products are currently being used world-wide at:

- ✓ Offshore oil and gas production facilities
- ✓ Crude oil, refined products, LPG, NGL and gas transmission lines
- ✓ Storage, truck, and marine loading/offloading terminals
- ✓ Refineries; petrochemical and cogeneration plants

Our products have become the international flow computing standard. OMNI Flow Computers pursues a policy of product development and continuous improvement. As a result, our flow computers are considered the “brain” and “cash point” of liquid and gas flow metering systems.

Our staff is knowledgeable and professional. They represent the energy, intelligence and strength of our company, adding value to our products and services. With the customer and user in mind, we are committed to quality in everything we do, devoting our efforts to deliver workmanship of high caliber. Teamwork with uncompromising integrity is our lifestyle.

## Contacting Our Corporate Headquarters



**OMNI Flow Computers, Inc.**  
12620 West Airport Suite 100  
Sugar Land, Texas 77478 USA



**Phone:** 281-240-6161

**Fax:** 281-240-6162



**World-wide Web Site:**

<http://www.omniflow.com>



**E-mail Addresses:**

[helpdesk@omniflow.com](mailto:helpdesk@omniflow.com)

## Getting User Support

Technical and sales support is available world-wide through our corporate or authorized representative offices. If you require user support, please contact the location nearest you or our corporate offices. Our staff and representatives will enthusiastically work with you to ensure the sound operation of your flow computer.

## About the Flow Computer Applications

OMNI 6000 and OMNI 3000 Flow Computers are integrated into the majority of liquid flow measurement and control systems. The current production firmware revision of OMNI 6000/OMNI 3000 Flow Computers are:

- θ **2075/2475:** Turbine/Positive Displacement/Coriolis Liquid Flow Metering Systems with K Factor Linearization (US/metric units)

## About the User Manual

This manual applies to all .73, .74 and .75 firmware revisions of OMNI 6000 and OMNI 3000 Flow Computers. It is structured into 5 volumes and is the principal part of your flow computer documentation.

### Target Audience

As a user's reference guide, this manual is intended for a sophisticated audience with knowledge of liquid and gas flow measurement technology. Different user levels of technical know-how are considered in this manual. You need not be an expert to operate the flow computer or use certain portions of this manual. However, some flow computer features require a certain degree of expertise and/or advanced knowledge of liquid and gas flow instrumentation and electronic measurement. In general, each volume is directed towards the following users:

- Volume 1. System Architecture and Installation
  - ◆ Installers
  - ◆ System/Project Managers
  - ◆ Engineers/Programmers
  - ◆ Advanced Operators
  - ◆ Operators
- Volume 2. Basic Operation
  - ◆ All Users
- Volume 3. Configuration and Advanced Operation
  - ◆ Engineers/Programmers
  - ◆ Advanced Operators
- Volume 4. Modbus™ Database Addresses and Index Numbers
  - ◆ Engineers/Programmers
  - ◆ Advanced Operators
- Volume 5. Technical Bulletins
  - ◆ Users with different levels of expertise.

## Manual Structure

The User Manual comprises 5 volumes; each contained in separate binding for easy manipulation. You will find a detailed table of contents at the beginning of each volume.



**User Reference Documentation** – *The User Manual is structured into five volumes. Volumes 1, 2, and 5 are generic to all flow computer application revisions. Volumes 3 and 4 are application specific. These have four versions each, published in separate documents; i.e., one per application revision per volume. You will receive the version that corresponds to your application revision.*

*The volumes respective to each application revision are:*

**Revision 20.75/24.75:** Volume #s 3, 4

### Volume 1. Architecture and Installation

Volume 1 is generic to all applications and considers both US and metric units. This volume describes:

- Basic hardware/software features
- Installation practices
- Calibration procedures
- Flow computer specifications

### Volume 2. Basic Operation

Volume 2 is generic to all applications and considers both US and metric units. It covers the essential and routine tasks and procedures that may be performed by the flow computer operator.

General computer-related features are described, such as:

- Overview of keypad functions
- Adjusting the display
- Clearing and viewing alarms
- Computer totalizing
- Printing and customizing reports

The application-related topics may include:

- Batching operations
- Proving functions
- PID control functions
- Audit trail
- Other application specific functions

Depending on your application, some of these topics may not be included in your specific documentation. An index of display variables and corresponding key press sequences that are specific to your application are listed at the end of each version of this volume.

### Volume 3. Configuration and Advanced Operation

Volume 3 is intended for the advanced user. It refers to application-specific topics and is available in four separate versions (one for each application revision). This volume covers:

- Application overview
- Flow computer configuration data entry
- User-programmable functions
- Modbus™ Protocol implementation
- Flow equations and algorithms

### Volume 4. Modbus™ Database Addresses and Index Numbers

- Volume 4 is intended for the system programmer (advanced user). It comprises a descriptive list of database point assignments in numerical order, within our firmware. This volume is application specific, for which there is one version per application revision.

### Volume 5. Technical Bulletins




**Manual Updates and Technical Bulletins** – Volume 5 of the User Manual is a compendium of Technical bulletins. You can view and print technical bulletins from our website: <http://www.omniflow.com>

Volume 5 includes technical bulletins that contain important complementary information about your flow computer hardware and software. Each bulletin covers a topic that may be generic to all applications or specific to a particular revision. They include product updates, theoretical descriptions, technical specifications, procedures, and other information of interest.

This is the most dynamic and current volume. Technical bulletins may be added to this volume after its publication.

## Conventions Used in this Manual

Several typographical conventions have been established as standard reference to highlight information that may be important to the reader. These will allow you to quickly identify distinct types of information.

CONVENTION USED	DESCRIPTION
	<p>The light bulb icon indicates a tip, suggestion, or concise information of interest. It is highly recommended that you read them.</p>
<p><b>Keys / Key Press Sequences</b></p> <p><u>Example:</u></p> <p><b>[Prog] [Batch] [Meter] [n]</b></p>	<p>Keys on the flow computer keypad are denoted with brackets and bold face characters (e.g. the 'up arrow' key is denoted as <b>[↑]</b>). The actual function of the key as it is labeled on the keypad is what appears between brackets. Key press sequences that are executed from the flow computer keypad are expressed in a series of keys separated by a space (as shown in the example).</p>
<p><b>Screen Displays</b></p> <p><u>Example:</u></p> <div style="border: 1px solid gray; padding: 5px; width: fit-content;"> <p><b>Use Up/Down Arrows To Adjust Contrast; Left, Right Arrows To Adjust Backlight</b></p> </div>	<p>Sample screens that correspond to the flow computer display appear surrounded by a dark gray border with the text in bold face characters and mono-spaced font. The flow computer display is actually 4 lines by 20 characters. Screens that are more than 4 lines must be scrolled to reveal the text shown in the manual.</p>
<p><b>Headings</b></p> <p><u>Example:</u></p> <p><b>2. Chapter Heading</b></p> <p><b>2.3. Section Heading</b></p> <p><b>2.3.1. Subsection Heading</b></p>	<p>Sequential heading numbering is used to categorize topics within each volume of the User Manual. The highest heading level is a chapter, which is divided into sections, which are likewise subdivided into subsections. Among other benefits, this facilitates information organization and cross-referencing.</p>
<p><b>Figure Captions</b></p> <p><u>Example:</u></p> <p><b>Fig. 2-3. Figure No. 3 of Chapter 2</b></p>	<p>Figure captions are numbered in sequence as they appear in each chapter. The first number identifies the chapter, followed by the sequence number and title of the illustration.</p>
<p><b>Page Numbers</b></p> <p><u>Example:</u></p> <p><b>2-8</b></p>	<p>Page numbering restarts at the beginning of every chapter and technical bulletin. Page numbers are preceded by the chapter number followed by a hyphen. Technical bulletins only indicate the page number of that bulletin. Page numbers are located on the outside margin in the footer of each page.</p>

## Trademark References

The following are trademarks of OMNI Flow Computers, Inc.:

- OMNI 3000
- OMNI 6000
- OmniCom®
- OmniView®

Other brand, product and company names that appear in this manual are trademarks of their respective owners.

## Copyright Information and Modifications Policy

This manual is copyright protected. All rights reserved. No part of this manual may be used or reproduced in any form, or stored in any database or retrieval system, without prior written consent of OMNI Flow Computers, Inc., Sugar Land, Texas, USA. Making copies of any part of this manual for any purpose other than your own personal use is a violation of United States copyright laws and international treaty provisions.

OMNI Flow Computers, Inc., in conformance with its policy of product development and improvement, may make any necessary changes to this document without notice.

## Warranty, Licenses and Product Registration

Product warranty and licenses for use of OMNI Flow Computer Firmware and of OmniCom Configuration PC Software are included in the first pages of each Volume of this manual. We require that you read this information before using your OMNI Flow Computer and the supplied software and documentation.

If you have not done so already, please complete and return to us the product registration form included with your flow computer. We need this information for warranty purposes, to render you technical support and serve you in future upgrades. Pointed users will also receive important updates and information about their flow computer and metering system.



**Important!**

**Copyright ©1991-2009 by OMNI Flow Computers, Inc.**

**All Rights Reserved.**

# Chapter 1

## Overview of Firmware Revisions 20/24


### Turbine / Positive Displacement / Coriolis Liquid Flow Metering Systems (with K Factor Linearization)

#### 1.1. Number of Meter Runs - Type of Flowmeters

Minimum 1 run, Maximum 4 runs - Turbine, Positive Displacement Flow Meters or Mass Flow Meters. 'Level A' dual channel 'Pulse Fidelity' checking can be performed on all 4 meter runs.

#### 1.2. Product Configuration

Parallel runs measuring the same product or independent runs with different products.



**Fig. 1-1.** Typical Configuration Using Helical Turbine, Positive Displacement and Coriolis Flowmeters



### **1.3. Configurable Sensors per Meter Run**

Meter Pulses, meter temperature and pressure, meter density, density temperature and pressure.

### **1.4. Configurable Sensors per Prover**

Prover inlet and outlet temperature and pressure, prover densitometer any type (analog or digital pulse type such as Solartron, Sarasota or UGC).

### **1.5. Temperature**

Each temperature sensor can be individually selected to be a 4-20mA, 4-wire DIN curve RTD or 4-wire American curve RTD.

### **1.6. Densitometers**

Can be configured for any combination or mix of individual or shared densitometers of any type (analog or digital pulse type such as Solartron, Sarasota or UGC) the maximum number that can be connected is five. Each analog density can be specified as flowing or reference conditions. For mass proving a densitometer can be configured on the prover.

### **1.7. Station Capability**

Meter runs may be combined or subtracted in any mode to provide station flow rates and totalizers.

### **1.8. Auxiliary Inputs**

Four auxiliary inputs are provided for miscellaneous sensors (for example: BS&W, Viscosity monitors, etc.) and can be individually selected to be a 4-20mA, 4-wire DIN curve RTD or 4-wire American curve RTD.

### **1.9. Number of products - Information Stored/Product**

Sixteen. - Product name, factors for each meter, gravity/density override, calculation mode to be used when running the product.

### **1.10. Type of Products Measured**

Crude oil, refined products, NGL's using API 2540, LPG's using GPA TP16,GPA27 and propylene using API 11.3.3.2. Ethylene using NIST 1045, API 2565, or IUPAC equations. Mass measurement mode is also standard. ASTM D1550, D1555, 1952 Table 23,24 are also provided.

## 1.11. **Batching and Interface Detection**

Six batch setups per meter run can be programmed with alphanumeric batch ID tag, product number to run and expected size of batch.

Individual meter run batch preset down counters provide 'batch end warning' and 'batch end reached' alarms.

Batches can be ended manually or automatically on size of batch, change of product, beginning of new day, day of the week or day of the month.

Product interface detection is achieved using a station interface detector densitometer mounted ahead of the meter runs. Line pack countdown counters allow up to three product interfaces to be tracked between the interface detector gravitometer and the valve manifold allowing pre-emptive product cuts.

## 1.12. **Auto Proving Features**

Fully automated proving to API chapter 12. User configured for Uni-, Bi-directional and compact provers with optional inlet and outlet temperature and pressure sensors. Both up-stream and downstream water draw volume inputs are available. Plenum chamber pressure on a Brooks prover is also input as an analog and controlled by the computer. Master meter proving is also featured. Proving can be triggered on change of flow rate versus last known prove for each meter or on the amount of flow which has occurred since the last prove. Proves can also be triggered by a meter being shut in for more than a specified amount of time.

## 1.13. **Retroactive Meter Factors and Override Gravity**

Meter factors and override product gravity can be applied retroactively for a selectable number of barrels at any time during a batch. Meter factors determined by a prove can be automatically implemented from that point or retroactively to the beginning of the batch.

## 1.14. **Retroactive Density Correction Factor**

Density correction factors can be applied retroactively for a selectable number of barrels at any time during a batch.

## 1.15. **Flow Rate/Viscosity Linearizing**

Viscosity/Flow Rate Linearizing of Helical Turbine/Positive Displacement meters can be accomplished by apply a linearization correction factor (LCF) to the incoming flowmeter pulses. The LCF is calculated in real time by monitoring a live viscosity input signal which is input via the auxiliary inputs.

## 1.16. **PID Control Functions**

Four independent control loops are provided for control of a primary variable with either high or low override control by a secondary variable. Contact closure inputs are activated to provide a startup and shutdown ramp function for each control loop if needed. Primary setpoint can be adjusted via an analog input, a keypad entry or communication link. Control loops are not dedicated and may be cascaded. Data is

processed every 500 msec.

### **1.17. Flow Weighted Averages**

Flow weighted averages are calculated for all input variables and correction factors based on hourly, daily totals and running batch totals.

### **1.18. User-Programmable Digital I/O**

Each I/O point is individually configurable as either an input or output with variable 'Delay On' and 'Delay Off'. Pulse widths are adjustable when used as auxiliary totalizer outputs or sampler outputs.

### **1.19. User-Programmable Logic Functions**

Sixty-four logic statements can be user programmed to control meter run switching, prover loop and provide user auxiliary control functions.

### **1.20. User-Programmable Alarm Functions**

Sixteen of the programmable logic statements described above can be used to contain custom text messages which can be displayed, logged and printed.

### **1.21. User-Programmable Variables**

Sixty-four user variables can be programmed to manipulate data for display and printing or remote access via a communication port. Typical uses include special units conversions, customer averaging algorithms for leak detection, special limit checking and control functions. The programmable variable statements can also be used to type cast data of one type to another (i.e., change a floating point variable to an integer type so that a PLC or DCS system can make use of it).

### **1.22. User Display Setups**

The user may specify eight key press combinations which recall display screens. Each user display screen can show four variables each with a descriptive tag defined by the user.

### **1.23. User Report Templates**

Using OmniCom the user can generate custom report templates or edit existing templates. These are uploaded into the flow computer. Custom templates for the snapshot, batch end, daily and prove reports can be defined.

### **1.24. Serial Communication Links**

Up to six serial data links are available for communications with other devices such as printers, SCADA systems, PLC's and other OMNI Flow Computers.

Ports communicate using a superset of the Modbus™ protocol (ASCII or RTU). Printer data is ASCII data. Baud rate has been increased to 57600 on all serial ports.

## **1.25. Peer-to-Peer Communications**

OMNI flow computers can be user configured to communicate with each other as equal peers. Groups of data variables can be exchanged or broadcast between other flow computers. Multiple flow computers can share resources such as a PLC.

## **1.26. Archive Data**

Two types of data archiving are possible in the flow computer. 1) Formatted ASCII text using custom report templates, 2) Raw Data using archive records and files.

## **1.27. OmniCom® Windows Version Software Communications Package**

OmniCom® Windows version software is provided with each flow computer, and allows the user to configure the computer on-line or off-line using a personal computer.

## **1.28. OmniView® Windows Version Software Communications Package**

A Man-Machine Interface package for the OMNI Flow Computer is also available as an option.

## **1.29. Ethernet Module**

An Ethernet module 68-6209 is available that will allow users to print reports and communicate using TCP/IP. See Technical Bulletin TB-020101 for more information.

## **1.30. Network Printing**

Network Printing is available with OMNI Firmware 20.74/24.74+ and SE Module Firmware v.1.50+. Additional help in setting up the network printing can be found in Help menu in OmniCom 1.39 or greater.

**This page left intentionally blank.**

# Chapter 2

## Flow Computer Configuration

### 2.1. Introduction

Configuration data is stored in the computer's battery backed-up RAM memory which will retain its data for at least 1 to 2 months with no power applied. Configuration data can be entered using one of three methods:

- 1) Configure off-line using the OmniCom PC configuration program and then uploading all data at once.
- 2) Configure on-line using the OmniCom PC configuration program which uploads each change as it is entered.
- 3) Enter configuration data via the front panel keypad using the Program Mode.

Methods 1) and 2) require an IBM compatible PC running the OmniCom Configuration Software and are described in **Volume 5** and in OmniCom Help. Method 3) is described here.

### 2.2. Configuring with the Keypad in Program Mode

#### 2.2.1. Entering the Program Mode



**INFO** - Key presses are denoted in bold face between brackets; e.g.: the enter key appears in this manual as **[Enter]**.

While in the Display Mode press the **[Prog]** key. The front panel Program LED above the key will glow green and the following selection menu will be displayed on the first three lines of the LCD display. The 4th line of the display is used to show the user key presses.

Press Keys to Select  
Group Entry, or  
Press "Prog" to Exit

#### 2.2.2. Changing Data

Data can be accessed using a sequential list of menu prompts or in a random access manner by going directly to a specific group of entries.

### 2.2.3. Menu Selection Method



**TIP** - It is best to use the menu selection method when programming an application for the first time as every possible option and variable will be prompted. Once a computer is in operation and you become familiar with the application you can decide to use the faster Random Access Method. To use the menu selection method, while in the Program Mode (program LED on) press [Setup] [Enter]. A Setup Menu similar to the one on the right will be displayed.

```

***  SETUP MENU  ***
Misc Configuration _
Time/Date Setup
Station Setup
Meter Run Setup
Temperature Setup
Pressure Setup
Grav/Density Setup
PID Control Setup
Prover Setup
Product Setup
Batch Preset Setup
Batch Sequence
Factor Setup
Printer Setup
  
```

Use the [↑]/[↓] (up/down arrow) keys to move the cursor to the appropriate entry and press [Enter] to access a particular submenu. The first menu, 'Misc Configuration', should always be completed first as these entries specify the number and type of input and output devices connected to the flow computer; i.e., the menus following the 'Misc Configuration' menu do not ask for configuration data unless a transducer has been defined.

### 2.2.4. Random Access Method

In addition to the Setup Menu, the data is also presented in related groups such as Temperature, Pressure, Meter, etc. You press the group key of your choice to get to a data area. By specifying a meter run before or after a group you go directly to the data for that group and that group only.

Once a group is selected use the 'Up/Down' arrow keys to step to a specific data entry within the group. You can view data and, assuming a valid password has been entered, change its value as required. If an error is made, press [Clear], re-enter the correct data and press [Enter] to enter the new value. The cursor will automatically step to the next data item in that group unless that would cause a total change of screen (i.e., you can always verify your entry). A list of data groups and associated key presses are listed later in this chapter.

**Example:**

Pressing **[Temp]** will allow you access to temperature data for all meter runs. Pressing **[Meter] [1] [Temp]** or **[Temp] [Meter] [1]** will allow access to only Meter Run #1 temperature data. For example, pressing **[Meter] [1] [Temp]** will display the following until the **[Enter]** key is pressed. The 4<sup>th</sup> line of the display is used to show the user key presses.

```
Press Keys to Select
Group Entry, or
Press "Prog" to Exit
Meter 1 Temp
```

Pressing the **[Enter]** key will display a screen similar to this:

```
TEMPERATURE #1 Deg.F
Low Limit      30.0
High Limit     125.0
Override       60.0
```



### 2.2.5. Passwords



**INFO** – Most entry groups occupy multiple screens so be sure to use the [↑]/[↓] to scroll and see all data.

Except when changing transducer high/low alarm limits, a password is usually asked for when changing the configuration data within the computer.

The flow computer has independent password protection of the following:

- o Local Keypad Access / Modbus Port #1 (selectable)  
(Physical Serial Port #1)
- o Modbus Port #2 - (Physical Serial Port #2)
- o Modbus Port #3 - (Physical Serial Port #3)
- o Modbus Port #4 - (Physical Serial Port #4)
- o Modbus Port #5 - (Physical Serial Port #5)
- o Modbus Port #6 - (Physical Serial Port #6)

#### Local Keypad Access

Three password levels are provided:

- **Privileged Level** Allows complete access to all entries within the flow computer including keypad passwords 1, 1A and 2 below. The initial privileged password for each Modbus port is selected via this password level.
- **Level 1** This level allows technician access to most entries within the flow computer with the exception of I/O Points assignments, programmable variables and Boolean statements and passwords other than 'Keypad Level 1'.
- **Level 1A** This level allows technician access to the following entries only:
  - ◆ Meter Factors
  - ◆ K Factors
  - ◆ Densitometer Correction Factors (Pycnometer Factor)
- **Level 2** Allows access to the operator type entries. These entries include:
  - ◆ Transducer Manual Overrides
  - ◆ Product Gravity Overrides
  - ◆ Prove Operations
  - ◆ Batching Operations

## Changing Passwords at the Keypad



**INFO** - Characters in '[' ]' refer to key presses.

- 1) At the keypad press **[Prog] [Setup] [Enter]**.
- 2) With the cursor blinking on '**Misc Configuration**', press **[Enter]**.
- 3) With the cursor blinking on '**Password Maint?**', press **[Enter]**.
- 4) Enter the Privileged Level Password (up to 6 Characters) and press **[Enter]**.
- 5) The Level 1, 1A and Level 2 passwords can now be viewed and changed if required.
- 6) Scroll down to access each of the Modbus serial port 'Level A' passwords. These are labeled 'Serial 1' (if Modbus Protocol is selected), 'Serial 2', 'Serial 3', and 'Serial 4' corresponding to the physical port numbering for Modbus Ports 1, 2, 3 and 4.



**INFO** – See Technical Bulletin TB-960701 in Volume 5 for setting Level B and Level C passwords using OmniCom.



**Note:** – Level B and Level C passwords for each Modbus port cannot be viewed or changed from the keypad.



**INFO** - The Help System is not limited to just the Program Mode. Context sensitive help is available in all modes of operation.

## 2.3. Getting Help

Context sensitive help is available for most data entries. Help is summoned by pressing the **[Display/Enter]** key twice (**[Help]** key) with the cursor on the data field in question. Help screens are frequently more than 1 full screen so always use the **[↑]/[↓]** keys to scroll in case there is more. Press **[Prog]** or **[Enter]** once to exit the help system and return to your original screen.

## 2.4. Program Inhibit Switch

A 'Program Inhibit Switch' mounted behind the front panel prevents unauthorized changing of data when in the 'Inhibit' position. Most data can be viewed while the switch is in the program inhibit position, but any attempt to alter data will be ignored and cause 'PROGRAM LOCKOUT' to be displayed on the bottom line of the LCD display.

The inner enclosure of the flow computer can be locked or sealed within the outer enclosure blocking access to the 'Program Inhibit Switch'.



**Caution** - These units have an integral latching mechanism which first must be disengaged by lifting the bezel upwards before withdrawing the unit from the case.




Fig. 2-1. Figure Showing Program Inhibit Switch

## 2.5. Configuring the Physical Inputs / Outputs



**Tip** - It is best to use the Menu Selection Method (see 9.2.3) when programming an application for the first time as every possible option and variable will be prompted. Once a computer is in operation and you become familiar with the application you can decide to use the faster Random Access Method (see 9.2.4).



**INFO** - The first menu, 'Misc Configuration', should always be completed first as these entries specify the number and type of input and output devices connected to the flow computer. You are advised to complete all entries under this menu before proceeding. Only transducers that have been assigned to physical I/O points will be available for further configuration (i.e., the menus following the 'Misc Configuration' menu do not ask for or accept configuration data unless a transducer has been defined). (See 9.5.2)

The OMNI Flow Computer can accept many I/O modules and be configured to match just about any combination of measurement transmitters. Configuring the physical I/O means setting up the number of meter runs, what types of transducers are to be used and to which physical I/O points they are connected.

### 2.5.1. Miscellaneous Configuration (Misc. Setup Menu)

The physical I/O configuration of the flow computer is changed by entering the 'Misc. Setup' menu while the 'Select Group Entry' screen is displayed (see 2.2.1. "Entering the Program Mode").

```
Press Keys to Select
Group Entry, or
Press "Prog" to Exit
Setup
```

Press **[Setup]** then **[Enter]** and the following selection menu will be displayed:

```
*** SETUP MENU ***
Misc Configuration _
Time/Date Setup
Station Setup
```

The cursor automatically appears at the 'Misc Configuration' option. Press **[Enter]** and the following selection menu will be displayed:

```
*** Misc. Setup ***
Password Maint?(Y)
Check Modules?(Y)
Config Station?(Y)
Config Meter "n"
Config Prove?(Y)
Config PID?"n"
Config D/A Out"n"
Front Pnl Counters
Program Booleans?
Program Variables?
User Display?"n"
Config Digital"n"
Serial I/O "n"
Custom Packet "n"
PLC Group "n"
Archive File "n"
Peer/Peer Comm(Y)?
```

## 2.5.2. Physical I/O Points not Available for Configuration

Configuration parameter groups are only prompted as needed. Meter runs and transducers which are not assigned to a physical I/O point will not be available for configuration. In these cases the following message will be displayed:

**Variable Selected is  
Not Assigned to a  
Physical I/O Point**

If this message is displayed, check the I/O point assignment for the variable.

## 2.5.3. Password Maintenance Settings



**INFO** - Characters in '{ }' refer to password levels. Characters in '[' ]' refer to key presses.



**TIP** - Use the blank lines provided next to each configuration option to write down the corresponding settings you entered in the flow computer. Some of these entries may not appear on the display or in OmniCom. Depending on the various configuration settings of your specific metering system, only those configuration options which are applicable will be displayed.

Password maintenance settings can only be entered via the OMNI front panel keypad. Enter [Y] at 'Password Maint ?' of the 'Misc Setup' menu to open the following entries:

### {PL} Privileged \_\_\_\_\_

Enter the privileged password to allow you to view and change all configuration data including other passwords.

### {PL} Level 1 \_\_\_\_\_

Enter the Level 1 password to allow entry of all configuration data except entries which determine the physical I/O personality of the computer.

### {PL} Level 1A \_\_\_\_\_

Enter the Level 1A password to allow entry of Meter factors, K Factors and Density Correction Factors only.

### {PL} Level 2 \_\_\_\_\_

Enter the Level 2 password which is required for operator type entries such as gravity overrides and meter factors.

### {PL} Serial Port #1 thru Serial Port #6 Password \_\_\_\_\_

Enter the Serial Port password. All data in the Modbus database except passwords can be read via the serial ports. These passwords allow writes to the Modbus database. Password protection can be disabled by entering a blank field as a password.

### {PL} Lockout Switch Active? (Serial Port #1 thru #6) \_\_\_\_\_

Enter [N] for the lockout switch to be **inactive** for this serial port.

Enter [Y] for the lockout switch to be **active** for this serial port.

### 2.5.4. Entries Requiring a Valid Privileged Password

The following entries display only when a Valid Privileged Password is entered:

**{PL} Model Number (0=3000, 1=6000)** \_\_\_\_\_

This entry is used by the OmniCom configuration software to determine the maximum I/O capability of the computer. Windows OmniCom user can select 3000 or 6000 when opening a new configuration file.

**{PL} Disable Download?** \_\_\_\_\_

Enter [Y] to prevent OmniCom from downloading the configuration file to the OMNI Flow Computer.

**{PL} Re-configure Archive** \_\_\_\_\_

Enter [Y] to re-configure archive records definition. Enter [N] when finished.

**{PL} Archive Run (Y/N)** \_\_\_\_\_

Enter [Y] to start the archive running.

**{PL} Delay Cycle 0-20** \_\_\_\_\_

**{PL} Reset All Totalizers ? (Y/N)** \_\_\_\_\_

Entering Y will reset all current meter totalizers to 0.0. Once this has been done the user will see another display " All Totalizers now reset" and the user can now select the totalizers resolution # of digits, 0=9, 1=8. Next the user can select the decimal place resolution for the front panel by selecting the number of decimal places required for Gross, Net and Mass. The three electromechanical totalizers on the front of the computer cannot be zeroed.

**{PL} Reset All RAM ? (Y/N)** \_\_\_\_\_

Resetting all RAM will clear all configuration data, calibration data and totalizers. This means that all configuration data will have to be re-entered.

**{PL} Input Calibrate Default ?** \_\_\_\_\_

Entering a [Y] here will set all the analog input calibration constants used to scale zero and span settings to the default value. This will require you to re calibrate all the inputs. **You can also do this on a channel by channel basis by entering the input channel number.**

**{PL} D/A Calibrate Default ?** \_\_\_\_\_

Entering a [Y] here will set all the analog output calibration constants used to scale zero and span settings to the default value. This will require you to recalibrate all the outputs. **You can also do this on a channel by channel basis by entering the output channel number.**



**Caution** - If you change the number or type of installed I/O modules, you must perform the 'Check Modules' Function to inform the computer that you wish to use the new hardware configuration.

Enter [Y] at 'Check Modules ?' of the 'Misc Setup' menu and a screen similar to the following will display: MODULE S-WARE H-WARE

A-1	Y	Y
E/D-1	Y	Y
D-1	Y	Y
S-1	Y	Y
Update S-Ware ?		

**{PL} Update S-Ware ? (Y)** \_\_\_\_\_

A table is displayed showing all of the physically installed I/O modules verses the I/O modules recognized by the software (see display example above). You must answer the 'Update Software' question entering [Y] whenever you change the number or type of installed modules. The available I/O point numbers are allocated to each module at this time according to the type and number of each module (see **Chapter 2** for more information).

### 2.5.5. Meter Station Settings



**INFO** - The number of process variable I/O points available depends on the number of combo modules installed (see Chapter 2 in Volume 1 for more information). Point numbers range from 01 through 24. Assign [0] to 'invalidate the assigning of a variable.



**I/O Type Mismatch** - The computer will not let you assign the same I/O point # to incompatible transducer types; i.e., an I/O point cannot be assigned as a temperature input for Meter Run #1 and a pressure input for Meter Run #2. If the 'I/O Type Mismatch' message is displayed, recheck the I/O.



**Shared Transducers** - Enter the same I/O point to share transducers between meter runs



**Correcting a Mistake** - Enter an I/O point # of [0] to cancel an incorrectly entered I/O point #, then enter the correct number.



**Assigning I/O Point #99** - This indicates that the associated variable will be available for display and be used in all calculations, but will not be obtained via a live input. The variable value is usually downloaded into the flow computer database via a communication port or via a user variable statement.

Enter [Y] at 'Config Station ?' of the 'Misc Setup' menu to open the following entries:

#### {PL} Station Configured As: \_\_\_\_\_

Station Totals and Flows Defined As: Define which meter runs will be included in the station flow rates and totalizers. Meter data can be added or subtracted.

**Example:** Entering [1] [+] [2] [-] [3] [-] [4] defines the station flows and totals as the result of Meter Runs #1 and #2 added together, subtracted by the flows of Meters #3 and #4.

Enter [0] for no station totalizers.

#### {PL} Density I/O Point Number \_\_\_\_\_

Enter the I/O point number that corresponds to the station density or gravity input used as the product interface detector. Digital densitometers can be corrected for temperature and pressure effects using the station pressure and temperature points. Digital pulse densitometers can only be assigned I/O point numbers corresponding to the 4<sup>th</sup> input channel of a B Type Combo Module, or Channels 3 or 4 of an E/D Type Combo Module.

#### Densitometer Tag \_\_\_\_\_

Enter the 8-character tag name used to identify this density transducer on the LCD display.

#### Densitometer Type \_\_\_\_\_

Enter the densitometer type:

- 0 = No density type selected
- 1 = 4-20mA output signal linear with API gravity units (many API devices are actually designed to drive non-linear API chart recorders; they are usually linear with relative density units)
- 2 = 4-20mA output signal linear with relative density (SG) units
- 3 = 4-20mA output signal linear with grs/cc density
- 4 = Solartron digital pulse
- 5 = Sarasota digital pulse
- 6 = UGC digital pulse.

#### {PL} Density Temperature I/O Point Number \_\_\_\_\_

Enter the I/O point number to which the temperature sensor used to compensate the station densitometer is connected.

When a digital densitometer is used as the station transducer, it can be corrected for temperature effects by assigning a temperature I/O point.

For the station product interface densitometer, enter a meter run temperature sensor in cases where a separate temperature transmitter is not available.

RTD probes should be assigned to the 1<sup>st</sup> channel on any type of combo module. RTD probes can also be assigned to the 2<sup>nd</sup> channel of B Type combo modules.

**Density Temperature Tag** \_\_\_\_\_

Enter the 8-character tag name used to identify this density temperature transducer on the LCD display.

**Density Temperature Type** \_\_\_\_\_

Enter the densitometer temperature transmitter type:

- 0 = RTD probes that follow the DIN curve and  $\alpha = 0.0385$
- 1 = RTD probes that follow the American curve and  $\alpha = 0.0392$
- 2 = Honeywell smart transmitter connected to an 'H' combo module or a transducer with a 4-20mA linear output

**{PL} Density Pressure I/O Point Number** \_\_\_\_\_

Enter the I/O point number to which the pressure transmitter used to compensate the station digital densitometers is connected.

When a digital densitometer is used as the product interface detector, it can be corrected for pressure effects by assigning a station pressure point.

If a separate pressure transmitter is not available, enter a meter pressure transmitter I/O point.

**Density Pressure Tag** \_\_\_\_\_

Enter the 8-character tag name used to identify this density pressure transducer on the LCD display.

**Auxiliary Input Assignment**

**{PL} Auxiliary Input #1 I/O Point Number** \_\_\_\_\_

Enter the physical I/O point number to which this auxiliary input is connected. Auxiliary Inputs can be used to enter S&W, viscosity and other miscellaneous variables.

**Auxiliary Input #1 Tag** \_\_\_\_\_

Enter the 8-character tag name used to identify this transducer on the LCD display.

**Auxiliary Input #1 Type** \_\_\_\_\_

Enter the Auxiliary Input Type:

- 0 = RTD probes that follow the DIN curve and  $\alpha = 0.0385$
- 1 = RTD probes that follow the American curve and  $\alpha = 0.0392$
- 2 = Transducer with a 4-20mA linear output or Honeywell smart transmitter connected to an 'H' combo module

**{PL} Auxiliary Input #2 I/O Point Number** \_\_\_\_\_

**Auxiliary Input #2 Tag** \_\_\_\_\_

**Auxiliary Input #2 Type** \_\_\_\_\_

**{PL} Auxiliary Input #3 I/O Point Number** \_\_\_\_\_

**Auxiliary Input #3 Tag** \_\_\_\_\_

**Auxiliary Input #3 Type** \_\_\_\_\_

**{PL} Auxiliary Input #4 I/O Point Number** \_\_\_\_\_

**Auxiliary Input #4 Tag** \_\_\_\_\_

**Auxiliary Input #4 Type** \_\_\_\_\_



## 2.5.6. Meter Run Settings



**Config Meter Runs** - Physical I/O information for up to 4 meter runs can be entered. Transducers that are not assigned an I/O point will not be available for display or further configuration.



**Assigning I/O Point #99** - This indicates that the associated variable will be available for display and be used in all calculations, but will not be obtained via a live input. The variable value is usually downloaded into the flow computer database via a communication port or via a user variable statement.

Enter [1], [2], [3] or [4] at 'Config Meter "n"' of the 'Misc Setup' menu to open the following entries:

	<u>Meter #1</u>	<u>Meter #2</u>	<u>Meter #3</u>	<u>Meter #4</u>
<b>{PL} Flow I/O Point Number</b>	_____	_____	_____	_____
Enter the number of the I/O point used to input the flow signal for each meter run. Flowmeter pulse inputs can only be assigned to the 3 <sup>rd</sup> input channel of any combo module and 4 <sup>th</sup> input channel of A Type combo modules. When working with compact provers using pulse interpolation, you must assign each of the flowmeter pulse signals to the 3 <sup>rd</sup> or 4 <sup>th</sup> channel of an E Type combo module.				
<b>Flow Transmitter Tag</b>	_____	_____	_____	_____
Enter the 8-character tag name used to identify this flowmeter on the LCD display.				
<b>{PL} Dual Pulse Fidelity Check?</b>	_____	_____	_____	_____
Enter [Y] to enable 'Level A' pulse fidelity and security checking for this meter run (API MPMS Chapter 5, Section 5). The 'Flow I/O Point' entered above must correspond to the 3 <sup>rd</sup> input channel of an E Combo Module. The flowmeter pulses are physically wired to Input Channels 3 and 4 of the E Combo Module. Enter [N] to disable dual pulse fidelity checking.				
<b>{PL} Select Mass Pulses?</b>	_____	_____	_____	_____
Enter [Y] to select Mass pulses if the flowmeter you are using produces pulses based on mass.				
<b>{PL} Temperature I/O Point #</b>	_____	_____	_____	_____
Enter the I/O point number used to input the temperature signal for each meter run. Duplicate I/O assignments are allowed when a sensor is shared by more than one meter run.				
<b>{PL} Temperature Transducer Tag</b>	_____	_____	_____	_____
Enter the 8-character tag name used to identify this temperature transducer on the LCD display.				
<b>{PL} Temperature Transducer Type</b>	_____	_____	_____	_____
Enter the Temperature Transmitter Type:				
0 = RTD probes that follow the DIN curve and $\alpha = 0.0385$				
1 = RTD probes that follow the American curve and $\alpha = 0.0392$				
2 = Honeywell smart transmitter connected to an 'H' combo module or a transducer with a 4-20mA linear output				
<b>{PL} Pressure I/O Point #</b>	_____	_____	_____	_____
Enter the I/O point number used to input the pressure signal for each meter run. Duplicate I/O assignments are allowed when a sensor is shared by more than one meter run.				
<b>Pressure Transducer Tag</b>	_____	_____	_____	_____
Enter the 8-character tag name used to identify this pressure transducer on the LCD display.				
<b>{PL} Density I/O Point #</b>	_____	_____	_____	_____
Enter the I/O point number used to input the density signal for each meter run. Duplicate I/O assignments are allowed when a densitometer is shared by more than one meter run. Digital pulse densitometers can only be assigned I/O point numbers corresponding to the 4 <sup>th</sup> input channel of a 'B' Type Combo Module or the 3 <sup>rd</sup> and 4 <sup>th</sup> input channels of an E/D Combo Module.				
<b>{PL} Densitometer Tag</b>	_____	_____	_____	_____
Enter the 8-character tag name used to identify this density transducer on the LCD display.				

**Meter #1**   **Meter #2**   **Meter #3**   **Meter #4**  
 \_\_\_\_\_

**{PL} Densitometer Type**

Enter the Densitometer Type:

- 0 = No density type selected
- 1 = 4-20mA output signal linear with API gravity units (many API devices are actually designed to drive non-linear API chart recorders; they are usually linear with relative density units)
- 2 = 4-20mA output signal linear with relative density (SG) units
- 3 = 4-20mA output signal linear with grs/cc density
- 4 = Solartron digital pulse
- 5 = Sarasota digital pulse
- 6 = UGC digital pulse.

**{PL} Flowing/Reference Conditions** \_\_\_\_\_

This entry applies only if you selected a 4-20mA type densitometer in the previous entry. Specify if the density transducer signal represents density at:

- 0 = Flowing temperature and pressure
- 1 = Reference temperature and pressure

**{PL} Density Temp I/O Point #** \_\_\_\_\_

Enter the I/O point number used to input the signal applied to compensate for temperature effects at the densitometer for each meter run.

If the densitometer has no temperature sensor fitted, enter the same I/O point assignment as the meter run temperature sensor.

**{PL} Density Temperature Tag** \_\_\_\_\_

Enter the 8-character tag name used to identify this density temperature transducer on the LCD display.

**{PL} Density Temperature Type** \_\_\_\_\_

Enter the Densitometer Temperature Transmitter Type:

- 0 = RTD probes that follow the DIN curve and  $\alpha = 0.0385$
- 1 = RTD probes that follow the American curve and  $\alpha = 0.0392$
- 2 = Honeywell smart transmitter connected to an 'H' combo module or a transducer with a 4-20mA linear output

**{PL} Density Pressure I/O Point #** \_\_\_\_\_

Enter the I/O point number used to input the signal applied to compensate for pressure effects at the densitometer for each meter run.

If the densitometer has no pressure sensor fitted, enter the same I/O point assignment as the meter run pressure sensor.

**{PL} Density Pressure Tag** \_\_\_\_\_

Enter the 8-character tag name used to identify this density pressure transducer on the LCD display.

### 2.5.7. Prover Settings



**Configuring the Prover:** When an input and output transducer signal is available, the computer uses the average of both signals. Otherwise, it uses the signal from the available transducer. The pressure or temperature of the meter run being proved will be used to compensate the prover if neither left or right transducer is assigned to an I/O point #.

Enter [Y] at 'Config Prove ?' of the 'Misc Setup' menu to open the following entries:

- |  | <u>Inlet</u> | <u>Outlet</u> |
|--|--------------|---------------|
| <b>{PL} Prover Temperature I/O Point Number</b> _____  |              |               |
| Enter the I/O point number used to input the prover inlet/outlet temperature signal. Inlet and outlet temperature sensor readings are averaged to determine the actual prover temperature. To use the meter run temperature, enter [0] for both inlet and outlet. If there is only one temperature sensor, enter [0] for outlet or enter the same number for both prover inlet and outlet.   |              |               |
| <b>{PL} Prover Temperature Transducer Tag</b> _____  |              |               |
| Enter the 8-character tag name used to identify this temperature transducer on the LCD display.  |              |               |
| <b>{PL} Prover Temperature Transmitter Type</b> _____  |              |               |
| Enter the Prover Temperature Transmitter Type:   |              |               |
| 0 = RTD probes that follow the DIN curve and $\alpha = 0.0385$   |              |               |
| 1 = RTD probes that follow the American curve and $\alpha = 0.0392$  |              |               |
| 2 = Honeywell smart transmitter connected to an 'H' combo module or a transducer with a 4-20mA linear output   |              |               |
| <b>{PL} Prover Pressure I/O Point Number</b> _____   |              |               |
| Enter the I/O point number used to input the prover inlet/outlet pressure signal. Inlet and outlet pressure sensor readings are averaged to determine the actual prover pressure. To use the meter run pressure, enter [0] for both inlet and outlet. If there is only one pressure sensor, enter [0] for outlet or enter the same number for both prover inlet and outlet.  |              |               |
| <b>{PL} Prover Pressure Transducer Tag</b> _____   |              |               |
| Enter the 8-character tag name used to identify this pressure transducer on the LCD display.   |              |               |
| <b>{PL} Prover Plenum Pressure I/O Point Number</b> _____  |              |               |
| Applies only when a Brooks compact prover is specified. Enter the I/O point number used to input the compact prover plenum pressure sensor input.  |              |               |
| <b>{PL} Prover Plenum Pressure Tag</b> _____   |              |               |
| Enter the 8-character tag name used to identify this plenum pressure transducer on the LCD display.  |              |               |
| <b>{PL} Prover Density I/O Point Number</b> _____  |              |               |
| Enter the I/O point number used to input the density signal for the prover. The prover density I/O point is used to calculate the mass of liquid in the prover during a mass proving run (i.e., coriolis meter proving). Digital pulse densitometers can be corrected for temperature and pressure effects using the station pressure and temperature points. Digital pulse densitometers must be assigned to the 4 <sup>th</sup> channel of a 'B' type module or the 3 <sup>rd</sup> or 4 <sup>th</sup> channel of an E/D module. |              |               |
| <b>Density Transducer Tag</b> _____  |              |               |
| Enter the 8-character tag name used to identify this density transducer on the LCD display.  |              |               |

**Densitometer Type** \_\_\_\_\_

Enter the Densitometer Type:

- 0 = No density type selected
- 1 = 4-20mA output signal linear with API gravity units (many API devices are actually designed to drive non-linear API chart recorders; they are usually linear with relative density units)
- 2 = 4-20mA output signal linear with relative density (SG) units
- 3 = 4-20mA output signal linear with grs/cc density
- 4 = Solartron digital pulse
- 5 = Sarasota digital pulse
- 6 = UGC digital pulse.

**{PL} Prover Density Temperature I/O Point Number** \_\_\_\_\_

Enter the I/O point number to which the temperature sensor used to compensate the prover densitometer is connected.

When a digital densitometer is used as the prover transducer, it can be corrected for temperature effects by assigning a temperature I/O point.

For the prover densitometer, enter the same I/O points as the prover inlet/outlet temperature sensor in cases where a separate temperature transmitter is not part of the densitometer.

RTD probes should be assigned to the 1<sup>st</sup> channel on any type of combo module. RTD probes can also be assigned to the 2<sup>nd</sup> channel of B Type combo modules.

**Density Temperature Transducer Tag** \_\_\_\_\_

Enter the 8-character tag name used to identify this density temperature transducer on the LCD display.

**Density Temperature Type** \_\_\_\_\_

Enter the Prover Temperature Transmitter Type: 0=DIN RTD, 1=AMER RTD, 2=4-20mA.

**{PL} Prover Density Pressure I/O Point Number** \_\_\_\_\_

Enter the I/O point number to which the pressure transmitter used to compensate the prover digital densitometer is connected.

Enter the same I/O point as the prover inlet pressure sensor in cases where a separate pressure transmitter is not available.

**Density Pressure Transducer Tag** \_\_\_\_\_

Enter the 8-character tag name used to identify this density pressure transducer on the LCD display.

### 2.5.8. PID Control Settings



**Proportional Integral Derivative (PID)** -- For practical reasons we refer to PID Control Loops in this manual. However, your flow computer actually performs the Proportional Integral (PI) function and does not apply the derivative term. The addition of the derivative term would greatly complicate tuning of the control loop and besides is not normally applicable to the types of flow and pressure control used in pipelines



**Valid Assignments** - Any 32-bit integer or floating point variable within the database can be assigned to be the primary or secondary controlled variable (see **Volume 4** for a complete listing of database addresses and index numbers)

Enter [1], [2], [3] or [4] at 'Config PID ? "n"' of the 'Misc Setup' menu to open the following entries:

Loop #1    Loop #2    Loop #3    Loop #4

**{PL} Assign Primary Variable**    \_\_\_\_\_

Enter the database index number of the primary variable in the PID loop.

**Remarks**    \_\_\_\_\_

Enter a remark in this 16-character field to identify the function of each variable assignment.

**{PL} Primary Action (F/R)**    \_\_\_\_\_

Enter [F] (forward action) if the value of the primary variable increases as the controller output % increases. Enter [R] (reverse action) if the value of the primary variable decreases as the controller output % increases.

**{PL} Remote Setpoint I/O Point #**    \_\_\_\_\_

Enter the I/O point number that the remote set point analog signal is connected to (01-24). Assign this point to **99** in cases where the set point will be downloaded via a communication port. Enter [0] if you will not be using a remote setpoint.

**{PL} Assign Secondary Variable**    \_\_\_\_\_

Enter the database index number of the secondary variable in the PID loop.

**Remarks**    \_\_\_\_\_


Enter a remark in this 16-character field to identify the function of each variable assignment.

**{PL} Secondary Action (F/R)**    \_\_\_\_\_

Enter [F] (forward action) if the value of the primary variable increases as the controller output % increases. Enter [R] (reverse action) if the value of the primary variable decreases as the controller output % increases.

**{PL} Error Select (L/H)**    \_\_\_\_\_

This entry determines the circumstances under which the primary or secondary variables are controlled. Enter [L] for low or [H] for high error select, according to the following modes:



**Mode #1:** The controller will attempt to control the primary variable but will switch to controlling the secondary variable, should the controller be trying to drive the secondary variable ABOVE its setpoint. An example of this mode would be controlling flow rate (primary) while not exceeding a MAXIMUM delivery pressure (secondary).

**Mode #2:** The controller will attempt to control primary variable but will switch to controlling the secondary variable, should the controller be trying to drive the secondary variable BELOW its setpoint. An example of this mode would be controlling flow rate (primary) while not dropping below a MINIMUM pressure value (secondary).

**{PL} Startup Mode (L/M)** \_\_\_\_\_

This entry determines how the computer handles a system reset such as a momentary loss of power. Enter **[L]** (Last) to cause the PID loop to stay in the operating mode it was last in before the system reset. Enter **[M]** (Manual) to cause the PID loop to startup with the PID loop in manual control mode and with the valve open % as it was before the system reset.

**{PL} PID Tag** \_\_\_\_\_

Enter an 8-character tag name to identify the PID controller output signal on the LCD display.

### 2.5.9. Analog Output Settings

Press **[n]** **[Enter]** at 'Config D/A Out "n"' of the 'Misc Setup' menu to open the following entries (n = Analog Output #1 through #12):

	<u>Assign</u>	<u>@ 4mA</u>	<u>@ 20mA</u>
<b>{L1} Analog Output #1</b>	_____	_____	_____
Under 'Assign', enter the database index number of the variable that will be assigned to the digital-to-analog output points.			
Under 'at 4mA' and 'at 20mA', enter the required scaling parameters in engineering units at 4mA and 20mA (e.g.: For Meter #1 Net Flow Rate assign <b>7102</b> . Typical scaling might be 4mA=0.0 bbls/hr and 20mA=1000.0 bbls/hr).			
<b>Remark</b>	_____		
Enter a remark in this 16-character field which identifies and documents the function of each digital-to-analog output.			
<b>{L1} Analog Output #2</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		
<b>{L1} Analog Output #3</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		
<b>{L1} Analog Output #4</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		
<b>{L1} Analog Output #5</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		
<b>{L1} Analog Output #6</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		
<b>{L1} Analog Output #7</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		
<b>{L1} Analog Output #8</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		
<b>{L1} Analog Output #9</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		
<b>{L1} Analog Output #10</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		
<b>{L1} Analog Output #11</b>	_____	_____	_____
<b>{L1} Remark</b>	_____		

{L1} Analog Output #12 \_\_\_\_\_

{L1} Remark \_\_\_\_\_

### 2.5.10. Front Panel Counter Settings

Enter [Y] at 'Front Pnl Counters' of the 'Misc Setup' menu to open the following entries:

Counter A      Counter B      Counter C

{L1} Assign Front Panel Counter \_\_\_\_\_

Enter the database index number of the accumulator variable that will be output to this electromechanical counter.

The unit of measure is the same as that shown on the LCD for the totalizer (i.e., barrels, klbs, m<sup>3</sup>, etc.) The maximum count rate is limited to 10 counts per second. Count rates higher than 10 pulses per second will cause the computer to remember how many counts did not get output and continue to output after the flow stops until all buffered counts are output.

{L1} Remarks \_\_\_\_\_

Enter a remark in this 16-character field which identifies and documents the function of each front panel counter.

{L1} Pulses/Unit \_\_\_\_\_

Enter the number of pulses per unit (volume, mass, energy).

### 2.5.11. Programmable Boolean Statements



**Program Booleans** - These 64 Boolean statements are evaluated every 100 msec starting at Point 1025 continuing through 1088. Each statement can contain up to 3 Boolean variables, optionally preceded by the slash (/) denoting the NOT Function and separated by a valid Boolean operator:

Operator	Symbol	Operator	Symbol	Operator	Symbol
NOT	/	AND	&	OR	+
EXOR	*	EQUAL	=	IF	)
GOTO	G	MOVE	:	COMPARE	%
INDIRECT	"				



E.g.: 1025 1002&/1003

Boolean 1025 is true when point 1002 is true AND point 1003 is NOT true.

Note: Points 1002 and 1003 in this example reflect the status of Physical Digital I/O Points 2 and 3.

There are no limitations as to what Boolean points can be used in a statement.

Statements can contain the results from other statements.



E.g.: 1026 /1025+1105

Boolean 1026 is true when Boolean 1025 is NOT true OR Point 1105 is true.

Using the '=' operator, the result of a statement can initiate a command.



E.g.: 1027 1719=1026

Request a 'Snapshot Report' when Boolean 1026 is true.

Enter [Y] at 'Program Booleans ?' of the 'Misc Setup' menu to open the following entries:

<u>Boolean Point 10xx</u>	<u>Equation or Statement</u>	<u>Comment or Remark</u>
{PL} 25:	_____	_____
{PL} 26:	_____	_____
{PL} 27:	_____	_____
{PL} 28:	_____	_____
{PL} 29:	_____	_____
{PL} 30:	_____	_____
{PL} 31:	_____	_____
{PL} 32:	_____	_____
{PL} 33:	_____	_____
{PL} 34:	_____	_____
{PL} 35:	_____	_____
{PL} 36:	_____	_____
{PL} 37:	_____	_____
{PL} 38:	_____	_____
{PL} 39:	_____	_____
{PL} 40:	_____	_____
{PL} 41:	_____	_____
{PL} 42:	_____	_____
{PL} 43:	_____	_____
{PL} 44:	_____	_____
{PL} 45:	_____	_____
{PL} 46:	_____	_____
{PL} 47:	_____	_____
{PL} 48:	_____	_____
{PL} 49:	_____	_____
{PL} 50:	_____	_____
{PL} 51:	_____	_____
{PL} 52:	_____	_____
{PL} 53:	_____	_____
{PL} 54:	_____	_____
{PL} 55:	_____	_____



<u>Boolean Point 10xx</u>	<u>Equation or Statement</u>	<u>Comment or Remark</u>
{PL} 56:	_____	_____
{PL} 57:	_____	_____
{PL} 58:	_____	_____
{PL} 59:	_____	_____
{PL} 60:	_____	_____
{PL} 61:	_____	_____
{PL} 62:	_____	_____
{PL} 63:	_____	_____
{PL} 64:	_____	_____
{PL} 65:	_____	_____
{PL} 66:	_____	_____
{PL} 67:	_____	_____
{PL} 68:	_____	_____
{PL} 69:	_____	_____
{PL} 70:	_____	_____
{PL} 71:	_____	_____
{PL} 72:	_____	_____
{PL} 73:	_____	_____
{PL} 74:	_____	_____
{PL} 75:	_____	_____
{PL} 76:	_____	_____
{PL} 77:	_____	_____
{PL} 78:	_____	_____
{PL} 79:	_____	_____
{PL} 80:	_____	_____
{PL} 81:	_____	_____
{PL} 82:	_____	_____
{PL} 83:	_____	_____
{PL} 84:	_____	_____
{PL} 85:	_____	_____
{PL} 86:	_____	_____
{PL} 87:	_____	_____
{PL} 88:	_____	_____

### 2.5.12. Programmable Variable Statements



**Programmable Variables** - These 64 variable statements are evaluated every 500 msec starting at the statement that determines the value of Points 7025 through 7088. Each statement can contain up to 3 variables or constants. Variables can be optionally preceded by the '\$' symbol denoting the ABSOLUTE value of the variable is to be used. Constants are identified by placing a '#' symbol ahead of the number. These and other operators are:

Operator	Symbol	Operator	Symbol	Operator	Symbol
ABSOLUTE	\$	ADD	+	MOVE	:
CONSTANT	#	SUBTRACT	-	COMPARE	%
POWER	&	EQUAL	=	INDIRECT	"
MULTIPLY	*	IF	)	RISING EDGE	(
DIVIDE	/	GOTO	G	FALLING EDGE	(/
ONE SHOT	@	ONE SHOT	<		



The order of precedence is: ABSOLUTE, POWER, MULTIPLY/DIVIDE, ADD/SUBTRACT. In cases where operators have the same precedence, statements are evaluated left to right.

E.g.: The value of floating point variable 7035 is defined as: 7035:7027&#0.5\*7026

The power operator is evaluated first (the value of Point 7035 is set equal to the square root of the number contained in Point 7027) and the result is multiplied by the number stored in variable 7026. Note that statements can contain the results of other statements. (See OmniCom Help for more information by pressing [F1] on your PC keyboard in the "Configure Variable Statement" menu.)

Enter [Y] at 'Program Variables ?' of the 'Misc Setup' menu to open the following entries:

<u>Prog Variable 70xx</u>	<u>Equation or Statement</u>	<u>Comment or Remark</u>
{PL} 25:	_____	_____
{PL} 26:	_____	_____
{PL} 27:	_____	_____
{PL} 28:	_____	_____
{PL} 29:	_____	_____
{PL} 30:	_____	_____
{PL} 31:	_____	_____
{PL} 32:	_____	_____
{PL} 33:	_____	_____
{PL} 34:	_____	_____
{PL} 35:	_____	_____
{PL} 36:	_____	_____

<u>Prog Variable 70xx</u>	<u>Equation or Statement</u>	<u>Comment or Remark</u>
{PL} 37:		
{PL} 38:		
{PL} 39:		
{PL} 40:		
{PL} 41:		
{PL} 42:		
{PL} 43:		
{PL} 44:		
{PL} 45:		
{PL} 46:		
{PL} 47:		
{PL} 48:		
{PL} 49:		
{PL} 50:		
{PL} 51:		
{PL} 52:		
{PL} 53:		
{PL} 54:		
{PL} 55:		
{PL} 56:		
{PL} 57:		
{PL} 58:		
{PL} 59:		
{PL} 60:		
{PL} 61:		
{PL} 62:		
{PL} 63:		
{PL} 64:		
{PL} 65:		
{PL} 66:		
{PL} 67:		
{PL} 68:		
{PL} 69:		
{PL} 70:		
{PL} 71:		

<u>Prog Variable 70xx</u>	<u>Equation or Statement</u>	<u>Comment or Remark</u>
{PL} 72:		
{PL} 73:		
{PL} 74:		
{PL} 75:		
{PL} 76:		
{PL} 77:		
{PL} 78:		
{PL} 79:		
{PL} 80:		
{PL} 81:		
{PL} 82:		
{PL} 83:		
{PL} 84:		
{PL} 85:		
{PL} 86:		
{PL} 87:		
{PL} 88:		



**TIP:** Use the blank lines provided next to each configuration option to write down the corresponding settings you enter in the flow computer



**Note:** See **Volume 4** for detailed list of Booleans and Status Commands



**Valid Numeric Variables** - These are any long integer or floating point number within the database (Points **5000-8999**), **including Boolean variables**. For the purpose of evaluation, Boolean variables have the value of 1.0 if they are True and 0.0 if they are False.

### 2.5.13. User Display Settings



**Valid Index Number Assignments** - Any Variable or floating point variable within the database can be assigned to be viewed via a user display (see **Volume 4** for a complete listing)



**Valid Key Press Sequences** - You may select a sequence of up to 4 key presses to recall each display. This does not count the **[Display/Enter]** key press which must be used to signal the end of the sequence. Each key is identified by the red A through Z character on each valid key.

**Valid keys are listed below:**

[A] - also labeled [Gross]	[J] - also labeled [D.P.]	[S] - also labeled [Print]
[B] - also labeled [Net]	[K] - also labeled [Orifice]	[T] - also labeled [Prove]
[C] - also labeled [Mass]	[L] - also labeled [Meter]	[U] - also labeled [Status]
[D] - also labeled [Energy]	[M] - also labeled [Time]	[V] - also labeled [Alarms]
[E] - also labeled [S.G./API]	[N] - also labeled [Counts]	[W] - also labeled [Product]
[F] - also labeled [Control]	[O] - also labeled [Factor]	[X] - also labeled [Setup]
[G] - also labeled [Temp]	[P] - also labeled [Preset]	[Y] - also labeled [Input]
[H] - also labeled [Press]	[Q] - also labeled [Batch]	[Z] - also labeled [Output]
[I] - also labeled [Density]	[R] - also labeled [Analysis]	



The **[↑]/[↓]/[←]/[→]** (Up/ Down/Left/Right arrow) keys and the **[Prog]**, **[Alpha Shift]** and **[Clear]** keys cannot be used in a key press sequence

**Note:** The 'A' through 'Z' keys are used simply to identify key presses. The **[Alpha Shift]** key does not need to be used when recalling user displays

## User Display Settings (Continued)

Enter 1 through 8 for the selected user display at 'User Display ? "n"' of the 'Misc Setup' menu to open the following password Level 1 {L1} entries:

### User Display #1 Key Press Sequence [ ] [ ] [ ] [ ]

Using the keys marked A through Z, enter the sequence of key presses needed to recall the selected user display (see the side bar for details). A maximum of 4 keys are allowed. User key press sequences take priority over any existing resident key press sequences.

#### 1<sup>st</sup> Variable Tag \_\_\_\_\_

Enter an 8-character tag name used to identify the display variable on the LCD display.

#### 1<sup>st</sup> Variable Index Number \_\_\_\_\_

Enter the database index number of the variable that you want to appear on the LCD display. Each variable within the flow computer database is assigned an index number or address. Any Boolean integer or floating point variable within the database can be displayed.

#### 1<sup>st</sup> Variable Decimal Point Position \_\_\_\_\_

Enter the number of digits to the right of the decimal point for the variable. Valid entries are 0 through 7. The computer will display each variable using the display resolution that you have selected, except in cases where the number is too large or too small. In either case, the flow computer will adjust the decimal position or default to scientific display mode.

	<u>Tag</u>	<u>Index #</u>	<u>Decimal Points</u>
2 <sup>nd</sup> Variable	_____	_____	_____
3 <sup>rd</sup> Variable	_____	_____	_____
4 <sup>th</sup> Variable	_____	_____	_____

### User Display #2 Key Press Sequence [ ] [ ] [ ] [ ]

	<u>Tag</u>	<u>Index #</u>	<u>Decimal Points</u>
1 <sup>st</sup> Variable	_____	_____	_____
2 <sup>nd</sup> Variable	_____	_____	_____
3 <sup>rd</sup> Variable	_____	_____	_____
4 <sup>th</sup> Variable	_____	_____	_____

### User Display #3 Key Press Sequence [ ] [ ] [ ] [ ]

	<u>Tag</u>	<u>Index #</u>	<u>Decimal Points</u>
1 <sup>st</sup> Variable	_____	_____	_____
2 <sup>nd</sup> Variable	_____	_____	_____
3 <sup>rd</sup> Variable	_____	_____	_____
4 <sup>th</sup> Variable	_____	_____	_____

### User Display Settings (Continued)

User Display #4 Key Press Sequence [ ] [ ] [ ] [ ]

	<u>Tag</u>	<u>Index #</u>	<u>Decimal Points</u>
1 <sup>st</sup> Variable	_____	_____	_____
2 <sup>nd</sup> Variable	_____	_____	_____
3 <sup>rd</sup> Variable	_____	_____	_____
4 <sup>th</sup> Variable	_____	_____	_____

User Display #5 Key Press Sequence [ ] [ ] [ ] [ ]

	<u>Tag</u>	<u>Index #</u>	<u>Decimal Points</u>
1 <sup>st</sup> Variable	_____	_____	_____
2 <sup>nd</sup> Variable	_____	_____	_____
3 <sup>rd</sup> Variable	_____	_____	_____
4 <sup>th</sup> Variable	_____	_____	_____

User Display #6 Key Press Sequence [ ] [ ] [ ] [ ]

	<u>Tag</u>	<u>Index #</u>	<u>Decimal Points</u>
1 <sup>st</sup> Variable	_____	_____	_____
2 <sup>nd</sup> Variable	_____	_____	_____
3 <sup>rd</sup> Variable	_____	_____	_____
4 <sup>th</sup> Variable	_____	_____	_____

User Display #7 Key Press Sequence [ ] [ ] [ ] [ ]

	<u>Tag</u>	<u>Index #</u>	<u>Decimal Points</u>
1 <sup>st</sup> Variable	_____	_____	_____
2 <sup>nd</sup> Variable	_____	_____	_____
3 <sup>rd</sup> Variable	_____	_____	_____
4 <sup>th</sup> Variable	_____	_____	_____

User Display #8 Key Press Sequence [ ] [ ] [ ] [ ]

	<u>Tag</u>	<u>Index #</u>	<u>Decimal Points</u>
1 <sup>st</sup> Variable	_____	_____	_____
2 <sup>nd</sup> Variable	_____	_____	_____
3 <sup>rd</sup> Variable	_____	_____	_____
4 <sup>th</sup> Variable	_____	_____	_____

## 2.5.14. Digital I/O Point Settings



**TIP:** Use the blank lines provided next to each configuration option to write down the corresponding settings you entered in the flow computer. Some of these entries may not appear on the display or in OmniCom. Depending on the various configuration settings of your specific metering system, only those configuration options which are applicable will be displayed.



**Config Digital "n":** Assign each physical I/O point to a Modbus address of a Boolean variable. There are no limitations as to what Boolean points can be assigned to physical I/O points. Enter [0] (zero) for Modbus control.



**Assigning as Pulse Output:** Meter and Station Accumulators may be output in the form of pulses.



**Pulse Width:** Pulse width is measured using 10msec ticks; i.e., 100 = 1 second.



**Pulse per Unit:** Pulse per unit entry can be used to provide unit conversion (e.g.: entering 4.2 pulses per barrel will give 1 pulse every 10 gallons as there are 42 gallons in a barrel). The units of volume, mass and energy flow are the same as is displayed on the LCD.



**Assigning as Control Output:** Any internal alarm or Boolean can be output.



**Delay On/Off:** Used to delay or stretch a control output. The delay is measured using 100msec ticks; i.e., 10 = 1 second.



**Assigning as Status or Command Inputs:** Switches, etc., can be used to trigger events within the flow computer, such as end a batch or start a prove sequence (see the facing page for more details).



**1700 Dummy Boolean:** Assign all physical I/O points which will be used only in Boolean statements for sequencing or control to 1700. This sets up the points as an input and Detector switch only.



**Note:** See Volume 4 for valid assignments.



### Digital I/O Point Settings (continued)

Enter 1 through 24 for the selected digital I/O Point at 'Config Digital "n"' of the 'Misc Setup' menu to open the following password Level 1 {L1} entries:

	<u>Assign</u>	<u>Pulse Width</u>	<u>Pulse/Unit</u> or	<u>Delay On</u>	<u>Delay Off</u>
Digital I/O #1	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #2	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #3	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #4	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #5	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #6	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #7	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #8	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #9	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #10	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #11	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #12	_____	_____	_____	_____	_____
Remark	_____				

	<u>Assign</u>	<u>Pulse Width</u>	<u>Pulse/Unit</u> or	<u>Delay On</u>	<u>Delay Off</u>
Digital I/O #13	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #14	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #15	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #16	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #17	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #18	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #19	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #20	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #21	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #22	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #23	_____	_____	_____	_____	_____
Remark	_____				
Digital I/O #24	_____	_____	_____	_____	_____
Remark	_____				

## 2.5.15. Serial Input / Output Settings



**Baud Rates Available:** 300, 600, 1200, 2400, 4800, 9600, 19200, 38400



**Data Bits - 7 or 8:** 7 for ASCII Modbus, 8 for RTU Modbus.



**Stop Bits:** 0, 1 or 2.



**Parity Bit:** Odd, Even, None.



**Transmitter Carrier Key Delay:** Delays are approximate only. 0=msec, 1=50msec, 2=100msec, 3=150msec.



**Modbus Type:** Select the protocol type which matches the Modbus master device. If the master can support either ASCII or RTU, choose RTU protocol as it is approximately twice as efficient as the ASCII protocol. Serial Ports #3 and #4 have additional protocol options.



**Modicon Compatible:** OmniCom will not operate if downloading configuration with this entry set to 'Y'.

Enter [1], [2], [3], [4], [5] or [6] at 'Serial I/O "n"' of the 'Misc Setup' menu to open the following entries: (Note: Only Ports 1 thru 4 are shown)

{L1} Baud Rate (Computer Default 9600)

{L1} Number of Stop Bits (Computer Default 1)

{L1} Number of Data Bits (Computer Default 8)

{L1} Parity Bit (Even/Odd/None) (Computer Default N)

{L1} Transmit Carrier Key Delay (Computer Default 0)

Enter one of the following options:

0 = 0 msec delay	2 = 100 msec delay
1 = 50 msec delay	3 = 150 msec delay

You must enter [0] for Transmitter Carrier Key Delay for any port that will be used with a shared printer.

{L1} Serial Port Type (Computer Port #1 = Default = Printer)

This entry corresponds to Serial Port #1 only. Enter one of the following options:

0 = Printer
1 = Modbus RTU

{L1} Modbus Protocol Type (Computer Default 2)

This entry does not apply to Serial Port #1. Enter the type of protocol to be used on this port:

0 = Modbus RTU
1 = Modbus ASCII
2 = Modbus RTU (modem).

Serial Port #4 has the following additional options:

3 = Allen Bradley Full Duplex
4 = Allen Bradley Half Duplex

Mixed protocols are not allowed on a communication link. All devices must use the same protocol type. The RTU protocol is preferred as it is twice the speed of the ASCII. Selecting 'Modbus RTU Modem' provides RTU protocol with relaxed timing which is usually needed when communicating via smart modems. These modems have been found to insert inter-character delays which cause a premature end of message to be detected by the flow computer.

**IMPORTANT:** You must select either 'Modbus RTU' or 'Modbus RTU Modem' protocol for the port that will be used to communicate with OmniCom PC configuration software.

**{L1} Modbus ID (Computer Default 1)**

This entry does not apply to Serial Port #1 when a printer is selected as the port type. Enter the Modbus slave ID number that this serial port will respond to (1 through 247 acceptable). This entry will be disabled for Serial Port #1 if a printer is selected as the port type.



**Skip CRC/LCR Check:** *If you have disabled the error checking on incoming messages, you must substitute dummy bytes in the message string. Outgoing messages will always include the error checking bytes.*

**{L1} Modicon Compatible (Y/N) (Computer Default N)**

Enter [Y] to configure these Modbus ports to be compatible with Modicon PLC equipment (e.g.: 984 series) and DCS systems (e.g.: Honeywell TDC3000 systems using the Advanced Process Manager APM-SI). This entry will be disabled for Serial Port #1 if a printer is selected as the port type.

In this mode the point number indexes requested and transmitted while using the Modbus RTU modes are actually one less than the index number documented in this manual. ASCII mode transmissions use the address documented in this manual. Data is counted in numbers of 16 bit registers rather than points. i.e., To request two 4 byte IEEE floating point variables, index numbers 7101 and 7102, would require the host to ask for 4 registers starting at index 7100. IEEE Floating Point data bytes are transmitted in swapped format:

NORMAL IEEE FLOAT FORMAT				ORDER TRANSMITTED			
Byte #1	Byte #2	Byte #3	Byte #4	Byte #1	Byte #2	Byte #3	Byte #4
Biased Exponent	MS Mantissa	Mantissa	LS Mantissa	Mantissa	LS Mantissa	Biased Exponent	MS Mantissa

**{L1} CRC Enabled (Computer Default Y)**

Many protocols use either a CRC, LRC or BCC error check to ensure that data received is not corrupted. The flow computer can be configured to ignore the error checking on incoming messages. This allows software developers an easy means of debugging communications software. **Error checking should only be disabled temporarily when debugging the master slave communication link.** The computer expects dummy characters in place of the CRC, LRC or BCC.

Enter [Y] to perform error checking on incoming messages. For maximum data integrity always enter [Y] during normal running conditions. Enter [N] to disable error checking on incoming messages. This entry will be disabled for Serial Port #1 if a printer is selected as the port type.

**{L1} New Ethernet (Y/N) (Computer Default N)**

Allow users to set the mode to work with earlier or newer modules of the Ethernet card. 0=earlier Ethernet modules with 384000 Baud and Only Modbus ID will be entered. 1= Newer Ethernet Modules 57600 Baudrate and additional entries as shown below.

**{L1} Modbus ID**

Enter the Modbus ID of the Ethernet Module

**{L1} IP Address**

All devices on a network require a unique IP address. The IP is entered in dotted decimal notation.

**{L1} Netmask**

IP address contain a Netmask identifier. The Netmask is entered in dotted decimal notation.

**{L1} Gateways**

If a default gateway exists for accessing other subnets, it can be entered here. The Gateway is entered in dotted decimal notation.

**{L1} Reports (Y/N)**

Select Y to allow reports to be printed.

**{L1} Alarms(Y/N)**

Select Y to allow Alarms reports to be printed

## 2.5.16. Custom Modbus™ Data Packet Settings



**INFO:** *Packets defined are usually read-only and must always be retrieved as a packet. When Modicon 984 is selected these packet setup entries are used to define a logical array of variables which can be read or written in any grouping. The number of data points is always input in terms of OMNI "logical" elements; i.e., an IEEE floating point number comprises two 16-bit words but is considered one logical element.*

Custom Modbus Data Packets are provided to reduce the number of polls needed to read multiple variables which may be in different areas of the database. Groups of data points of any type of data can be concatenated into one packet by entering each data group starting index numbers 001, 201 and 401. The number of data bytes in a custom packet in non-Modicon compatible mode cannot exceed 250 (RTU mode) or 500 (ASCII mode). When Modicon compatible is selected, the number of data bytes in a custom packet cannot exceed 400 (RTU mode) or 800 (ASCII mode).

Enter **[1], [2] or [3]** to select a data packet at **'Custom Packet "n"'** of the **'Misc Setup'** menu to open the entries below. Under **Index #**, enter the database address or Modbus index number for each start data point of each group. Under **Points**, enter the number of consecutive data points to include in each data group.

### Custom Modbus Data Packet #1 (Addressed at 001)

{L1} Index #   Points	Index #   Points	Index #   Points	Index #   Points
#1 _____   _____	#2 _____   _____	#3 _____   _____	#4 _____   _____
#5 _____   _____	#6 _____   _____	#7 _____   _____	#8 _____   _____
#9 _____   _____	#10 _____   _____	#11 _____   _____	#12 _____   _____
#13 _____   _____	#14 _____   _____	#15 _____   _____	#16 _____   _____
#17 _____   _____	#18 _____   _____	#19 _____   _____	#20 _____   _____

### Custom Modbus Data Packet #2 (Addressed at 201)

{L1} Index #   Points	Index #   Points	Index #   Points	Index #   Points
#1 _____   _____	#2 _____   _____	#3 _____   _____	#4 _____   _____
#5 _____   _____	#6 _____   _____	#7 _____   _____	#8 _____   _____

### Custom Modbus Data Packet #3 (Addressed at 401)

{L1} Index #   Points	Index #   Points	Index #   Points	Index #   Points
#1 _____   _____	#2 _____   _____	#3 _____   _____	#4 _____   _____
#5 _____   _____	#6 _____   _____	#7 _____   _____	#8 _____   _____
#9 _____   _____	#10 _____   _____	#11 _____   _____	#12 _____   _____
#13 _____   _____	#14 _____   _____	#15 _____   _____	#16 _____   _____
#17 _____   _____	#18 _____   _____	#19 _____   _____	#20 _____   _____

## 2.5.17. Peer-to-Peer Communications Settings



**TIP** - For maximum efficiency, always start Modbus ID numbers from 1

Serial Port #2 of the flow computer can be configured to act as a simple Modbus slave port or as a peer-to-peer communication link. Using the peer-to-peer link allows multiple flow computers to be interconnected and share data.

Enter [Y] at 'Peer / Peer Comm (Y) ?' of the 'Misc Setup' menu to open the following submenu:

### {L1} Activate Redundancy Mode

The active redundancy mode feature allows two flow computers to operate as a pair. Each flow computer receives the same process signals and performs the same calculations; i.e., in "redundancy". This mode is typically used in critical applications where failure of a flow computer cannot be tolerated.

Enter [Y] to allow both flow computers to manage the peer-to-peer link between them and automatically switch between being the master or slave computer. Important data such as meter factors and PID control settings can be continually exchanged between flow computers ensuring that at any time, should a failure occur to one, the other unit would be able to assume control of the PID and ticketing functions.

The redundancy mode requires that four digital I/O ports be cross-connected to sense watchdog failure modes using the following points 2714=Input master status, 2864=Output Master status, 2713 Input watchdog status, 2863 = Output of watchdog status. (See Technical Bulletin **TB-980402** in **Volume 5**.)

### {L1} Next Master in Sequence

Enter the slave number of the next flow computer in sequence in the peer-to-peer communication sequence to pass over control. After the flow computer completes all of its transactions it will attempt to pass over master control of the Modbus link to this Modbus ID. For maximum efficiency, always start Modbus ID definitions from 1.

Enter the Modbus ID of this flow computer if there are no other peers in sequence on the communication link.

**Enter [0] to disable the peer-to-peer feature and use Serial Port #2 as a standard Modbus slave port.**

### {L1} Last Master in Sequence ID #

Enter the slave number of the last OMNI (the highest Modbus ID number) in the peer-to-peer communication sequence. This is required for error recovery. Should this flow computer be unable to hand over control to the 'next master in sequence' (see previous entry), it will attempt to establish communications with a Modbus slave with a higher Modbus ID. It will keep trying until the ID number exceeds this entry. At that point the flow computer will start at Modbus ID #1.

Enter the Modbus ID of this flow computer if it is the only master on the link.

### {L1} Retry Timer

Should any slave device fail to respond to a communication request, the master device will retry to establish communications several times. Enter the number of 50 millisecond ticks that the flow computer should wait for a response from the slave device. To ensure fast recovery from communication failures, set this entry to as low a number as possible. Enter [3] for peer-to-peer links involving only OMNI flow computers. Other Modbus devices may require more time to respond.



**INFO** - The OMNI Flow Computer determines what Modbus function code and what data type is involved by the Modbus index number of the data within the OMNI's database. The Source Index determines the data type for a 'write'. The Destination Index determines the data type for a 'read'.

Function codes used are:      01=Read Multiple Booleans,    15=Write Multiple Booleans,  
03=Read Multiple Variables,    16=Write Multiple Variables

**Transaction #1****{L1} Target Slave ID #** \_\_\_\_\_

Each transfer of data is called a transaction. Enter the Modbus ID # of the other slave involved in the transaction. Modbus ID '0' can be used to broadcast write to all Modbus slave devices connected to the peer-to-peer link. Other valid IDs range from 1-247.

**{L1} Read/Write ?** \_\_\_\_\_

Enter [R] if data will be read from the slave. Enter [W] if data will be written to the slave.

**{L1} Source Index #** \_\_\_\_\_

Enter the database index number or address of the Modbus point where the data is to be obtained, corresponding to the first data point of the transaction. This is the slave's database index number when the transaction is a 'read', and the master's database index number when the transaction is a 'write'. Refer to **Volume 4** for a list of available database addresses or index numbers.

**{L1} Number of Points** \_\_\_\_\_

Enter the number of contiguous points to transfer. Each transaction can transfer multiple data points that can be any valid data type recognized by the OMNI. The maximum number of points that can be transferred depends on the type of data:

- 0 IEEE floats (4bytes each) → 63 max
- 0 32-bit Integers (4 bytes each) → 63 max
- 0 16-bit integers (2 bytes each) → 127 max
- 0 Packed coils or status (8 to a byte) → 2040 max.

The OMNI automatically knows what Modbus function to use and what data types are involved by the Modbus index number of the data within the flow computer database. The destination index number determines the data type when the transaction is a 'read'. The source index number determines the data type when the transaction is a 'write'.

**{L1} Destination Index #** \_\_\_\_\_

Enter the database index number or address of where the data is to be stored (destination index or address). If the transaction is a 'read', this will be the index number within the master OMNI's database. If the transaction is a 'write', this will be the register number within the remote slave's database.

**Transaction #2****{L1} Target Slave ID #** \_\_\_\_\_**{L1} Read/Write ?** \_\_\_\_\_**{L1} Source Index #** \_\_\_\_\_**{L1} Number of Points** \_\_\_\_\_**{L1} Destination Index #** \_\_\_\_\_**Transaction #3****{L1} Target Slave ID #** \_\_\_\_\_**{L1} Read/Write ?** \_\_\_\_\_**{L1} Source Index #** \_\_\_\_\_**{L1} Number of Points** \_\_\_\_\_**{L1} Destination Index #** \_\_\_\_\_

**Transaction #4**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_

**Transaction #5**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_

**Transaction #6**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_

**Transaction #7**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_

**Transaction #8**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_



**Transaction #9**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_

**Transaction #10**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_

**Transaction #11**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_

**Transaction #12**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_

**Transaction #13**

{L1} Target Slave ID # \_\_\_\_\_  
{L1} Read/Write ? \_\_\_\_\_  
{L1} Source Index # \_\_\_\_\_  
{L1} Number of Points \_\_\_\_\_  
{L1} Destination Index # \_\_\_\_\_

**Transaction #14**

{L1} Target Slave ID # \_\_\_\_\_  
 {L1} Read/Write ? \_\_\_\_\_  
 {L1} Source Index # \_\_\_\_\_  
 {L1} Number of Points \_\_\_\_\_  
 {L1} Destination Index # \_\_\_\_\_

**Transaction #15**

{L1} Target Slave ID # \_\_\_\_\_  
 {L1} Read/Write ? \_\_\_\_\_  
 {L1} Source Index # \_\_\_\_\_  
 {L1} Number of Points \_\_\_\_\_  
 {L1} Destination Index # \_\_\_\_\_

**Transaction #16**

{L1} Target Slave ID # \_\_\_\_\_  
 {L1} Read/Write ? \_\_\_\_\_  
 {L1} Source Index # \_\_\_\_\_  
 {L1} Number of Points \_\_\_\_\_  
 {L1} Destination Index # \_\_\_\_\_

**2.5.18. Programmable Logic Controller Setup**

**Note:** See *Technical Bulletin TB-960702 “Communicating with Allen-Bradley™ Programmable Logic Controllers”* in *Volume 5* for information on the ‘PLC Group “n”’ submenu.

**2.5.19. Archive File Setup**

**Note:** See *Technical Bulletin TB-960703 “Storing Archive Data within the Flow Computer”* in *Volume 5* for information on the ‘Archive File “n”’ submenu.

## 2.6. Setting Up the Time and Date



**Flow Computer Configuration via the Menu Selection Method:** It is best to use this method when programming an application for the first time as every possible option and variable will be prompted. Once a computer is in operation and you become familiar with the application you can decide to use the faster Random Access Method described below.

Once you have finished entering data in a setup submenu, press the [Prog] key to return to the 'Select Group Entry' screen.

Proceed as described in this manual for each setup option.



**Time and Date Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the [Prog] key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press [Time] [Enter] and use [↑]/[↓] keys to scroll.



**Note:** See Technical Bulletin TB-960703 "Storing Archive Data within the Flow Computer" in Volume 5 for information on the 'Archive File "n"' submenu. Setting Up the Time and Date.

### 2.6.1. Accessing the Time/Date Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press [Setup] [Enter] and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
Misc Configuration
Time/Date Setup  _
Station Setup

```

Use the [↑]/[↓] (up/down arrow) keys to move the cursor to 'Time/Date Setup' and press [Enter] to access the submenu.

### 2.6.2. Time and Date Settings

{L1} OMNI Time \_\_\_\_\_:\_\_\_\_\_:\_\_\_\_\_

Enter Current Time using the correct method 'hh:mm:ss'. To change only the hour, minutes or seconds, move cursor to the respective position and enter the new setting.

{L1} OMNI Date \_\_\_\_\_/\_\_\_\_\_/\_\_\_\_\_

Enter Current Date using the correct method 'mm/dd/yy' or 'dd/mm/yy'. To change only the month, day or year, move cursor to the respective position and enter the new setting.

{L1} Select Date Format Type \_\_\_\_\_

Select date format required by entering [Y] or [N]:

Y = month/day/year

N = day/month/year

## 2.7. Configuring the Meter Station



**Meter Station Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the **[Prog]** key. The Program LED will glow green and 'Select Group Entry' screen will appear. Then press **[Meter]** **[Enter]** and use **[↑]**/**[↓]** keys to scroll.



**Meter Station Run Switching Flow Rate Thresholds:** The OMNI flow computer has 3 Boolean flags which are set or reset depending on the station flow rate: Run Switching Flag #1 at Modbus database point 1824, Run Switching Flag #2 at Modbus database point 1825, Run Switching Flag #3 at Modbus database point 1826.

Each of these flags has a low threshold and high threshold flow rate. Each flag is set when the station flow rate exceeds the corresponding high threshold value. These flags reset when the station flow rate falls below the respective low threshold limit.

See Chapter 3 for more information on how to include these flags in Boolean statements to automatically switch meter runs depending on flow rates.

### 2.7.1. Accessing the Station Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press **[Setup]** **[Enter]** and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
Misc Configuration
Time/Date Setup
Station Setup      _
  
```

Use the **[↑]**/**[↓]** (up/down arrow) keys to move the cursor to 'Station Setup' and press **[Enter]** to access the submenu. Verify that the Config Station entry has station configured as example 1+2+3+4 (Meter 1 plus Meter 2 etc)

### 2.7.2. Meter Station Settings

#### {L1} Station ID

Enter 8 alphanumeric characters maximum. This string variable usually appears in user custom reports (Modbus database point **4815**).

#### Flow Low Alarm Limit

Enter the flow rate below which the Station Low Flow Alarm activates (Modbus database point **1810**). Flow rates 5% below this value activate the Low Alarm (Modbus database point **1809**).

#### Flow High Alarm Limit

Enter the flow rate above which the Station High Flow Alarm activates (Modbus database point **1811**). Flow rates 5% above this value activate the High Alarm (Modbus database point **1812**).

#### {L1} Gross Flow Rate at Full Scale

Enter the gross flow rate at full scale for the meter station. Sixteen-bit integer variables representing station gross and net flow rate are included in the database at **3802** and **3804**. These variables are scaled using this entry and stored as percentage of full scale with a resolution of 0.1% (i.e., 0 to 999 = 0% to 99.9%)

**{L1} Mass Flow Rate at Full Scale** \_\_\_\_\_

Enter the mass flow rate at full scale for the meter station. A 16-bit integer variable representing station mass flow rate is included in the database at **3806**. This variable is scaled using this entry and stored as percentage of full scale with a resolution of 0.1% (i.e., 0 to 1000 = 0% to 100.0%)

**Flag #1**      **Flag #2**      **Flag #3**

**{L1} Run Switching Threshold Low** \_\_\_\_\_

Enter the flow rate Low Threshold value which resets each Station Run Switching Flag when the station gross flow rate falls below this limit.

**{L1} Run Switching Threshold High** \_\_\_\_\_

Enter the flow rate High Threshold value which sets each Station Run Switching Flag when the station gross flow rate exceeds this limit (see note).



**INFO:** See the previous chapter for a description of batching features of the OMNI flow computer.

**{L1} Use Common Batch Stack?** \_\_\_\_\_

Enter [**Y**] to set up the flow computer to use a common product on all four meter runs; i.e., to run the same product at the same time on all 4 meter runs. Enter [**N**] to run different products at the same time on each meter run. (See **Volume 2b** on Batching Operations.)

**{L1} Batch Preset Warning** \_\_\_\_\_

Enter the quantity of barrels for the Batch Preset Warning. This entry displays only when Common Batch Stack is selected. The Batch preset counters are activated when a non-zero number is entered for batch size on the batch sequence stack (see **Volume 2b** on Batching Operations). The batch preset reached flag (database point **1819**) will be activated whenever the batch preset counter counts down to zero. The batch warning flag (database point **1818**) will be activated when the batch preset counter is equal or less than this entry.

**{L1} Relative Density (Gravity) / Density Rate of Change** \_\_\_\_\_

This entry displays only when a Station Density I/O Point has been assigned. It is used to detect product changes in the pipeline (product interface).

Enter the Gravity or Density Rate of Change in relative density units per barrel (US units) or in Kgs/m<sup>3</sup> per cubic meter (metric units) for this limit. The Relative Density/Density Rate of Change Flag (database point **1813**) is activated if the flowing gravity/density measured by the station densitometer exceeds this preset rate of change.

**{L1} Line Pack Delay** \_\_\_\_\_

This entry displays only when a Station Density I/O Point has been assigned. In many cases, the station densitometer that detects the product interfaces is installed many net barrels in advance of the metering skid to provide prior warning of a product change.

Enter the Line Pack Delay as the quantity of net barrels or net m<sup>3</sup> between the product interface detector densitometer or gravitometer and the valve manifold used to end the batch. A Delayed Gravity Rate of Change Flag (database point **1814**) is set when this number of barrels or m<sup>3</sup> has been measured after the Product Interface Flag (database point **1813**) is activated; i.e., a line pack delay is counted down to zero when a product interface is detected.

**{L1} Relative Density (Specific Gravity) Sample Time** \_\_\_\_\_

This entry displays only when a Station Density I/O Point has been assigned. It is used with the previous entry to determine the relative density rate of change.

Estimate the minimum amount of time in seconds it takes for a product change to be complete and set this timer by entering approximately 1/4 to 1/3 of that time. False triggering of the product interface detection flag can be eliminated by ensuring that any density change must exist for at least this many seconds.

**{L1} Gross Batch Preset Counter Units?** \_\_\_\_\_

Enter [**Y**] to select gross (actual) volume units (IV). Enter [**N**] to select net volume units (GSV).

**{PL} Select Volume Units** \_\_\_\_\_

This entry corresponds to metric units only and applies globally to all volumes within the flow computer. Enter the volume units:

- 0 = Cubic meters (m<sup>3</sup>)
- 1 = Liters (lts)

Prove Report      Batch Report

**{PL} Number of Decimal Places for Factors** \_\_\_\_\_

Enter the number of decimal places to use for correction factors appearing on prove and batch reports (4, 5 or 6 decimal places). These settings correspond to the following factors: CTLM, CTLP, CPLM, CPLP, CTSP, CPSP, CCF.

The density pycnometer factor remains fixed at four decimal places. For strict adherence to API MPMS 12.2 (default) select 4 decimal places. This is the recommend selection. Selecting 5 decimal places causes the flow computer to perform the normal API internal rounding and truncating rules with the exception of the last round which is to 5 places. Selecting 6 decimal places causes the flow computer to perform no internal rounding and truncating and rounds the final result to 6 decimal places.

**Auxiliary Inputs**



**Auxiliary Input Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the **[Prog]** key. The Program LED will glow green and 'Select Group Entry' screen will appear. Then press **[Analysis] [Input] [Enter]** or **[Analysis] [Input] [n] [Enter]** (n = Auxiliary Input # 1, 2, 3 or 4). Use **[↑] / [↓]** keys to scroll.



\* **Note:** Not Valid when a RTD Probe is specified.

Input #1      Input #2      Input #3      Input#4

**Low Alarm Limits** \_\_\_\_\_

Enter the auxiliary input signal value below which the Low Alarm activates. The low alarm activates when the auxiliary Input signal falls 5% below this value.

**High Alarm Limits** \_\_\_\_\_

Enter the auxiliary input signal value above which the High Alarm activates. The high alarm will activate when the auxiliary Input signal rises 5% above this value.

**{L2} Override Values** \_\_\_\_\_

Enter the value (in engineering units) which will be substituted for the transducer value, depending on the override code selected. An '\*' displayed along side of the value indicates that the override value is substituted.

**{L2} Override Codes** \_\_\_\_\_

Enter the Override Code which represents the strategy used regarding each auxiliary input override value:

- 0 = Never use override value
- 1 = Always use override value
- 2 = On transmitter failure, use override value
- 3 = On transmitter failure, use last hour's average

**{L1} at 4mA\*** \_\_\_\_\_

Enter the value in engineering units that produces a transducer output of 4mA or 1volt, or the 'lower range limit' (LRV) of Honeywell™ Smart Transmitters.

**{L1} at 20mA\*** \_\_\_\_\_

Enter the value in engineering units that produces a transducer output of 20mA or 5 Volts, or 'upper range limit' (URV) of Honeywell™ Smart Transmitters.

**{L1} Damping Code**

This entry only applies to Honeywell digital transmitters connected to an 'H' type combo module. The process variable (i.e., temperature/pressure) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry.

For Pressure Transmitters, enter the selected Damping Code:

0 = 0 seconds	5 = 2 seconds
1 = 0.16 seconds	6 = 4 seconds
2 = 0.32 seconds	7 = 8 seconds
3 = 0.48 seconds	8 = 16 seconds
4 = 1 seconds	9 = 32 seconds

For Temperature Transmitters, enter the selected Damping Code:

0 = 0 seconds	5 = 6.3 seconds
1 = 0.3 seconds	6 = 12.7 seconds
2 = 0.7 seconds	7 = 25.5 seconds
3 = 1.5 seconds	8 = 51.5 seconds
4 = 3.1 seconds	9 = 102.5 seconds

## 2.8. Configuring Meter Runs



**Meter Run Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the [Prog] key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press [Meter] [n] [Enter] (n = Meter Run # 1, 2, 3 or 4).. Use [↑] / [↓] keys to scroll.



**Alternate Access to Meter Run Settings from Meter Station Setup:** After entering the Meter Station Settings, without exiting, press the [↓] key and you will scroll down through each Meter Run setup entry.

### 2.8.1. Accessing the Meter Run Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press [Setup] [Enter] and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
Time/Date Setup
Station Setup
Meter Run Setup  _

```

Use the [↑]/[↓] (up/down arrow) keys to move the cursor to 'Meter Run Setup' and press [Enter] to access the submenu.

### 2.8.2. Meter Run Settings

**Meter #1**   **Meter #2**   **Meter #3**   **Meter #4**

**{L1} Meter ID**

Enter the ID of the flowmeter (up to 8 alphanumeric characters) for each meter run. This ID usually appears on reports.

**Flow Low Alarm Limit**

Enter the flow rate for each meter run below which the Flow Low Alarm (database point **1n21**) activates. The Low Alarm (database point **1n20**) activates when the flow rate falls 5% below this limit.

**Flow High Alarm Limit** \_\_\_\_\_

Enter the flow rate for each meter run above which the Flow High Alarm (database point **1n22**) activates. The High Alarm (database point **1n23**) activates when the flow rate rises 5% above this limit.

**{L1} Gross Flow Rate at Full Scale** \_\_\_\_\_

Enter the gross flow rate at full-scale for each meter run. Sixteen-bit integer variables representing meter run gross and net flow rate are included in the database at **3n42** and **3n40** respectively. These variables are scaled using this entry and stored as percentage of full scale with a resolution of 0.1% (i.e., 0 to 1000 = 0% to 100.0%)

**{L1} Mass Flow Rate at Full Scale** \_\_\_\_\_

Enter the mass flow rate at full-scale for each meter run. A 16-bit integer variable representing meter run mass flow rate is included in the database at **3n44**. This variable is scaled using this entry and stored as percentage of full scale with a resolution of 0.1% (i.e., 0 to 1000 = 0% to 100.0%)

**{L1} Active Frequency Threshold** \_\_\_\_\_

Enter the Active Frequency Threshold for each meter run. Flow meter pulse frequencies equal or greater than this threshold will cause the Meter Active Flag (**1n05**) to be set.

By using any Boolean statement you can use this flag bit to enable and disable totalizing by controlling the Disable Meter Run Totalizer Flags (Modbus database points **1736**, **1737**, **1738** & **1739**).

**Example:** 1030 1736=1/1105 ⇒ Turn off Meter #1 flow if not greater than Active Frequency.

**{L1} Alarm Meter Inactive ?** \_\_\_\_\_

Enter Y to trigger alarm when meter is inactive.

**Meter #1**    **Meter #2**    **Meter #3**    **Meter #4**

**{L1} Error Check Threshold** \_\_\_\_\_

This entry will display only when 'Dual Pulse' is selected under 'Config Meter Runs' (Misc Setup). It applies only when a 'E' combo module is fitted and 'Pulse Fidelity Checking' is enabled.

Enter the Pulse Fidelity Error Check Threshold (in Hz) for each meter run. To eliminate bogus alarms and error count accumulations, the dual pulse error checking functions are disabled until the sum of both pulse trains exceeds the pulses per seconds entered for this setting.

**Example:** Entering 50 for this threshold means that the dual pulse error checking will be disabled until both A and B channels of the flowmeter pick-offs are providing 25 pulses per second each.

**{L1} Max Error Counts per Batch** \_\_\_\_\_

This entry will display only when 'Dual Pulse' is selected under 'Config Meter Runs' (Misc Setup). It applies only when a 'E' combo module is fitted and 'Pulse Fidelity Checking' is enabled.

Enter the maximum number of error pulses allowed in one transaction for each meter run. The alarm points are:

- 1n48 A/B Comparitor Error Detected
- 1n49 A Channel Failed
- 1n50 B Channel Failed
- 1n51 A and B Channels not equal

The dual pulse A/B Comparitor Error Alarm (**1n48**) is activated when the accumulated error counts between the flowmeter channels exceeds this count threshold. Accumulated error counts are cleared for every batch.



### Flow Rate/Viscosity Linearization Settings



**K-Factor Linearization Settings:** Turbine and positive displacement flowmeters produce pulses proportional to the flow. The K factor is the quantity of pulses per unit volume (barrels or m<sup>3</sup>) or mass (lb or kg) that each meter produces. These settings are used to calculate the gross flow rate and volume.

**TIP:** Enter the viscosity linearization setting first and then return to configure the K Factor linearization

#### {L1A} K-Factor

This entry applies when Flow Rate/Viscosity Linearization is selected (see 'Viscosity Linear' entry below). Enter the K Factor for each meter run. In this case, only one K Factor is entered per flow meter. Linearization is accomplished by applying a Linearization Correction Factor (LCF) to incoming flow pulses. The LCF is calculated in real-time by monitoring a live viscosity signal.

The coefficient entries below are used to calculate the LCF for helical turbine or positive displacement (PD) flowmeters with the following equations:

$$LCF_{(HELICAL)} = a + b/x + c/x^2 + d/x^3 + e/x^4 + f/x^5 + g/x^6$$

$$LCF_{(PD)} = a + [(x^c)/b]$$

Enter the corresponding polynomial or equation coefficients of the linearizing algorithms used to calculate the LCF for each meter run:

<b>Coefficient, a</b>			
<b>Coefficient, b</b>			
<b>Coefficient, c</b>			
<b>Coefficient, d</b>			
<b>Coefficient, e</b>			
<b>Coefficient, f</b>			
<b>Coefficient, g</b>			

**K-Factor Linearization Settings**

	<u>Meter #1</u>	<u>Meter #2</u>	<u>Meter #3</u>	<u>Meter #4</u>
<b>{L1A} K-Factor #1</b>	_____	_____	_____	_____
This entry applies for simple flow-based linearization of K Factor; i.e., when "none" is selected for Flow Rate/Viscosity Linearization (see 'Viscosity Linear' entry below). Enter the K Factors for each meter run. In this case, up to 12 K Factors and the associated flowmeter pulse frequencies are entered per meter run to define the K Factor Curve. The flow computer will continuously monitor the flowmeter pulse frequency and calculate gross flow based on and interpolated K Factor derived from the entered data points. Use only K Factor #1 in cases where flowmeter linearizing is not required.				
<b>Frequency Point #1</b>	_____	_____	_____	_____
Enter the flowmeter pulse frequency associated with the corresponding K Factor. The frequency points must be entered lowest to highest (Hz).				
<b>K-Factor #2</b>	_____	_____	_____	_____
<b>Frequency Point #2</b>	_____	_____	_____	_____
<b>K-Factor #3</b>	_____	_____	_____	_____
<b>Frequency Point #3</b>	_____	_____	_____	_____
<b>K-Factor #4</b>	_____	_____	_____	_____
<b>Frequency Point #4</b>	_____	_____	_____	_____
<b>K-Factor #5</b>	_____	_____	_____	_____
<b>Frequency Point #5</b>	_____	_____	_____	_____
<b>K-Factor #6</b>	_____	_____	_____	_____
<b>Frequency Point #6</b>	_____	_____	_____	_____
<b>K-Factor #7</b>	_____	_____	_____	_____
<b>Frequency Point #7</b>	_____	_____	_____	_____
<b>K-Factor #8</b>	_____	_____	_____	_____
<b>Frequency Point #8</b>	_____	_____	_____	_____
<b>K-Factor #9</b>	_____	_____	_____	_____
<b>Frequency Point #9</b>	_____	_____	_____	_____
<b>K-Factor #10</b>	_____	_____	_____	_____
<b>Frequency Point #10</b>	_____	_____	_____	_____
<b>K-Factor #11</b>	_____	_____	_____	_____
<b>Frequency Point #11</b>	_____	_____	_____	_____
<b>K-Factor #12</b>	_____	_____	_____	_____
<b>Frequency Point #12</b>	_____	_____	_____	_____

## More Meter Run Settings

Meter #1   Meter #2   Meter #3   Meter #4

### {L1} Auto Prove ? (Y)

Enter [Y] to enable the auto-proving feature. Enter [N] to disable auto-proving. Enabling the auto-prove function will cause the flowmeter to be automatically proved on flow rate changes and after a meter has been out of service. The auto-prove enable is cancelled whenever a meter fails an automatic prove on 10 consecutive attempts.

### {L1} Use MF in Net ? (Y)

Enter [Y] to apply the meter factor in the net and mass flow equations. Enter [N] to ignore the meter factor in flow calculations; nonetheless, it will still appear on all reports.

### {L1} Use LCF in Gross ?

This entry applies when Flow Rate/Viscosity Linearization is selected (see 'Viscosity Linear' entry below). Enter [Y] to apply the Linearization Correction Factor (LCF) to gross flow rate and gross totals. Enter [N] if the LCF is not to be applied. The calculation of the gross indicated volume for each option is as follows:

- If "Yes" is selected  $\Rightarrow$  Gross = (Flowmeter Pulses/ Flowmeter K Factor) x LCF
- If "No" is selected  $\Rightarrow$  Gross = Flowmeter Pulses/ Flowmeter K Factor

### {L1} Temp Compensated ?

In some cases, the flowmeter may be fitted with a mechanical or electronic temperature compensator. Enter [Y] for the OMNI Flow Computer to set the temperature correction (VCF) to 1.0000 in all equations. Enter [N] if the meter provides gross uncompensated pulses.

### {L1} S&W as Aux "n"

Select the auxiliary input or other source to be used to input the S&W % for each meter run: 0=None, 1=Use Auxiliary Input #1, 2= Use Auxiliary Input #2, 3= Use Auxiliary Input #3, 4= Use Auxiliary Input #1; 5=Modbus Direct. The flow computer will use this input to determine Net Standard Volume (S&W corrected volume).

### {L1} Viscosity Linearization

Select the source of the viscosity value for the LCF for each meter run: 0=None, 1=Use Auxiliary Input #1, 2= Use Auxiliary Input #2, 3= Use Auxiliary Input #3, 4= Use Auxiliary Input #1; 5=Modbus Direct.

### {L1} Select Helical Turbine

Enter [Y] to select a Helical Turbine Flowmeter. Enter [N] to select a Positive Displacement (PD) Flowmeter. The algorithm used to linearize the flowmeter for flow and viscosity effects is different depending on whether the flowmeter is a helical turbine type or a PD type.

### {L1} Meter Model Number

Enter the model number of the flowmeter (up to 8 alphanumeric characters). This entry usually appears on the prove report.

### {L1} Meter Size

Enter the size of the flowmeter (up to 8 alphanumeric characters). This entry usually appears on the prove report.

### {L1} Meter Serial Number

Enter the serial number of the flowmeter (up to 8 alphanumeric characters). This entry usually appears on the prove report.

## 2.9. Configuring Temperature



**INFO:** The first menu, 'Misc Configuration', should always be completed first as these entries specify the number and type of input and output devices connected to the flow computer; i.e., the menus following the 'Misc Configuration' menu do not ask for configuration data unless a transducer has been defined.



**Flow Computer Configuration via the Menu Selection Method:** It is best to use this method when programming an application for the first time as every possible option and variable will be prompted. Once a computer is in operation and you become familiar with the application you can decide to use the faster Random Access Method described below.

Once you have finished entering data in a setup submenu, press the [Prog] key to return to the 'Select Group Entry' screen.

Proceed as described in this manual for each setup option



**Meter Temperature Setup via the Random Access Method -** Setup entries require that you be in the Program Mode. In the Display Mode press the [Prog] key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press [Temp] [Enter], or [Temp] [Meter] [n] [Enter] or [Meter] [n] [Temp] [Enter] (n = Meter Run # 1, 2, 3 or 4). Use [↑] / [↓] keys to scroll.



\* **Note:** Not Valid when a RTD Probe is specified

### 2.9.1. Accessing the Temperature Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press [Setup] [Enter] and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
Station Setup
Meter Run Setup
Temperature Setup _
    
```

Use the [↑]/[↓] (up/down arrow) keys to move the cursor to 'Temperature Setup' and press [Enter] to access the submenu.

### 2.9.2. Station and Meter Run Temperature Settings

Station      Meter #1      Meter #2      Meter #3      Meter #4

**Low Alarm Limit** \_\_\_\_\_

Enter the temperature below which the flowmeter low alarm activates. Transducer values approximately 5% below this entry fail to low.

**High Alarm Limit** \_\_\_\_\_

Enter the temperature above which the flowmeter high alarm activates. Transducer values approximately 5% above this entry fail to high.

**{L2} Override** \_\_\_\_\_

Enter the temperature value that is substituted for the live transducer value, depending on the override code. An '\*' displayed along side of the value indicates that the override value is substituted.

**{L2} Override Code** \_\_\_\_\_

Enter the Override Code strategy:

0 = Never use override code

- 1 = Always use override code
- 2 = Use override code on transmitter failure
- 3 = On transmitter failures use last hour's average

**{L1} at 4mA\*** \_\_\_\_\_

Enter the temperature engineering units that the transmitter outputs at 4mA or 1volt, or lower range limit (LRV) of Honeywell Smart Transmitters.

**{L1} at 20mA\*** \_\_\_\_\_

Enter the temperature engineering units that the transmitter outputs at 20mA or 5 Volts, or upper range limit (URV) of Honeywell Smart Transmitters.

Station	Meter #1	Meter #2	Meter #3	Meter #4
<b>{L1} Damping Code</b> _____				

This entry only applies to Honeywell digital transmitters connected to an H Type combo module. The process variable (i.e., temperature) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry.

For Temperature Transmitters, enter the selected Damping Code:

- |                 |                   |
|-----------------|-------------------|
| 0 = 0 seconds   | 5 = 6.3 seconds   |
| 1 = 0.3 seconds | 6 = 12.7 seconds  |
| 2 = 0.7 seconds | 7 = 25.5 seconds  |
| 3 = 1.5 seconds | 8 = 51.5 seconds  |
| 4 = 3.1 seconds | 9 = 102.5 seconds |

### 2.9.3. Station and Meter Run Density Temperature Settings



**Meter Temperature Density Temperature Setup via the Random Access Method** - To access these settings, in the Program Mode press **[Density] [Temp] [Enter]**.



**INFO:** The Density Temperature sensor is used to compensate for temperature expansion effects which effect the periodic time of oscillation of the densitometer. It is also used when desired to calculate the density of the liquid to reference temperature using API 2540; Table 23, 23A or 23B



**\* NOTE:** Not Valid when a RTD Probe is specified

Station	Meter #1	Meter #2	Meter #3	Meter #4
<b>Low Limit</b> _____				

Enter the temperature below which the densitometer low alarm activates. Transducer values approximately 5% below this entry activate the transducer fail low alarm.

<b>High Limit</b> _____				
-------------------------	--	--	--	--

Enter the temperature above which the densitometer high alarm activates. Transducer values approximately 10% above this entry activate the transducer fail high alarm.

<b>{L2} Override</b> _____				
----------------------------	--	--	--	--

Enter the temperature value that is substituted for the live transducer value, depending on the override code. An "\*" displayed along side of the value indicates that the override value is substituted.

<b>{L2} Override Code</b> _____				
---------------------------------	--	--	--	--

Enter the Override Code strategy:

- 0 = Never use override code
- 1 = Always use override code
- 2 = Use override code on transmitter failure
- 3 = On transmitter failures use last hour's average

<b>{L1} at 4mA*</b> _____				
---------------------------	--	--	--	--

Enter the temperature engineering units that the transducer outputs at 4mA or 1volt, or lower range limit (LRV) of Honeywell Smart Transmitters.

<b>{L1} at 20mA*</b> _____				
----------------------------	--	--	--	--

Enter the temperature engineering units that the transducer outputs at 20mA or 5volts, or upper range limit (URV) of Honeywell Smart Transmitters.

**{L1} Damping Code** \_\_\_\_\_

This entry only applies to Honeywell digital transmitters connected to an H Type combo module. The process variable (i.e., temperature) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry.

For Temperature Transmitters, enter the selected Damping Code:

0 = 0 seconds	5 = 6.3 seconds
1 = 0.3 seconds	6 = 12.7 seconds
2 = 0.7 seconds	7 = 25.5 seconds
3 = 1.5 seconds	8 = 51.5 seconds
4 = 3.1 seconds	9 = 102.5 seconds

**2.9.4. Prover Temperature Settings**

**Prover Temperature Setup via the Random Access Method** - Setup entries require that you be in the Program Mode. In the Display Mode press the **[Prog]** key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press **[Prove]** **[Temp]** **[Enter]** or **[Temp]** **[Prove]** **[Enter]**. Use **[↑]** / **[↓]** keys to scroll

InletOutlet**Low Alarm Limit** \_\_\_\_\_

Enter the temperature below which the prover low alarm activates. Transducer values approximately 5% below this entry activate the transducer fail low alarm.

**High Alarm Limit** \_\_\_\_\_

Enter the temperature above which the prover high alarm activates. Transducer values approximately 10% above this entry activate the transducer fail high alarm.

**{L2} Override** \_\_\_\_\_

Enter the temperature value that is substituted for the live transducer value, depending on the override code. An "\*" displayed along side of the value indicates that the override value is substituted.

**{L2} Override Code** \_\_\_\_\_

Enter the Override Code strategy:

0 = Never use override code
1 = Always use override code
2 = Use override code on transmitter failure
3 = On transmitter failures use last hour's average

**{L1} @ 4mA\*** \_\_\_\_\_

Enter the temperature engineering units that the transducer outputs at 4mA or 1volt, or lower range limit (LRV) of Honeywell Smart Transmitters.

**{L1} @ 20mA\*** \_\_\_\_\_

Enter the temperature engineering units that the transducer outputs at 20mA or 5volts, or upper range limit (URV) of Honeywell Smart Transmitters.

**{L1} Damping Code** \_\_\_\_\_

This entry only applies to Honeywell digital transmitters connected to an H Type combo module. The process variable (i.e., temperature) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry.

For Temperature Transmitters, enter the selected Damping Code:

0 = 0 seconds	5 = 6.3 seconds
1 = 0.3 seconds	6 = 12.7 seconds
2 = 0.7 seconds	7 = 25.5 seconds
3 = 1.5 seconds	8 = 51.5 seconds
4 = 3.1 seconds	9 = 102.5 seconds

## 2.9.5. Prover Density Temperature Settings

	<u>Inlet</u>	<u>Outlet</u>
<b>Low Alarm Limit</b>	_____	_____
Enter the temperature below which the prover low alarm activates. Transducer values approximately 5% below this entry activate the transducer fail low alarm.		
<b>High Alarm Limit</b>	_____	_____
Enter the temperature above which the prover high alarm activates. Transducer values approximately 10% above this entry activate the transducer fail high alarm.		
<b>{L2} Override</b>	_____	_____
Enter the temperature value that is substituted for the live transducer value, depending on the override code. An "*" displayed along side of the value indicates that the override value is substituted.		
<b>{L2} Override Code</b>	_____	_____
Enter the Override Code strategy:		
0 = Never use override code		
1 = Always use override code		
2 = Use override code on transmitter failure		
3 = On transmitter failures use last hour's average		
<b>{L1} at 4mA*</b>	_____	_____
Enter the temperature engineering units that the transducer outputs at 4mA or 1volt, or lower range limit (LRV) of Honeywell Smart Transmitters.		
<b>{L1} at 20mA*</b>	_____	_____
Enter the temperature engineering units that the transducer outputs at 20mA or 5volts, or upper range limit) URV of Honeywell Smart Transmitters.		
<b>{L1} Damping Code</b>	_____	_____
This entry only applies to Honeywell digital transmitters connected to an H Type combo module. The process variable (i.e., temperature) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry.		
For Temperature Transmitters, enter the selected Damping Code:		
0 = 0 seconds		
1 = 0.3 seconds		
2 = 0.7 seconds		
3 = 1.5 seconds		
4 = 3.1 seconds		
5 = 6.3 seconds		
6 = 12.7 seconds		
7 = 25.5 seconds		
8 = 51.5 seconds		
9 = 102.5 seconds		



## 2.10. Configuring Pressure



**Meter Pressure Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the **[Prog]** key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press **[Enter]**, or **[Press] [Meter] [n] [Enter]** or **[Meter] [n] [Press] [Enter]** ( $n = \text{Meter Run \# 1, 2, 3 or 4}$ ). Use **[↑]** / **[↓]** keys to scroll.

### 2.10.1. Accessing the Pressure Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press **[Setup] [Enter]** and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
Meter Run Setup
Temperature Setup
Pressure Setup  _
  
```

Use the **[↑]**/**[↓]** (up/down arrow) keys to move the cursor to 'Pressure Setup' and press **[Enter]** to access the submenu.

### 2.10.2. Station and Meter Run Pressure Settings

Station      Meter #1      Meter #2      Meter #3      Meter #4

**Low Alarm Limit** \_\_\_\_\_

Enter the pressure below which the flowmeter low alarm activates. Transducer values approximately 5% below this entry fail to low.

**High Alarm Limit** \_\_\_\_\_

Enter the pressure above which the flowmeter high alarm activates. Transducer values approximately 10% above this entry fail to high.

**{L2} Override** \_\_\_\_\_

Enter the pressure value that is substituted for the live transducer value, depending on the override code. An '\*' displayed along side of the value indicates that the override value is substituted.

**{L2} Override Code** \_\_\_\_\_

Enter the Override Code strategy:

- 0 = Never use override code
- 1 = Always use override code
- 2 = Use override code on transmitter failure
- 3 = On transmitter failures use last hour's average

**{L1} at 4mA\*** \_\_\_\_\_

Enter the pressure engineering units that the transmitter outputs at 4mA or 1volt, or lower range limit (LRV) of Honeywell Smart Transmitters.

**{L1} at 20mA\*** \_\_\_\_\_

Enter the pressure engineering units that the transmitter outputs at 20mA or 5volts, or upper range limit (URV) of Honeywell Smart Transmitters.

**Station    Meter #1    Meter #2    Meter #3    Meter #4**

**{L1} Damping Code** \_\_\_\_\_

This entry only applies to Honeywell digital transmitters connected to an H Type combo module. The process variable (i.e., pressure) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry.

For Pressure Transmitters, enter the selected Damping Code:

- 0 = 0 seconds                      5 = 2 seconds
- 1 = 0.16 seconds                6 = 4 seconds
- 2 = 0.32 seconds                7 = 8 seconds
- 3 = 0.48 seconds                8 = 16 seconds
- 4 = 1 seconds                     9 = 32 seconds

### 2.10.3. Station and Meter Run Density Pressure Settings



**Meter Density Pressure Setup via the Random Access Method:** To access these settings, in the Program Mode press [Density] [Press] [Enter].

**Station    Meter #1    Meter #2    Meter #3    Meter #4**

**Low Alarm Limit** \_\_\_\_\_

Enter the pressure below which the densitometer low alarm activates. Transducer values approximately 5% below this entry activate the transducer fail low alarm.

**High Alarm Limit** \_\_\_\_\_

Enter the pressure above which the densitometer high alarm activates. Transducer values approximately 10% above this entry activate the transducer fail high alarm.

**{L2} Override** \_\_\_\_\_

Enter the pressure value that is substituted for the live transducer value, depending on the override code. An "\*" displayed along side of the value indicates that the override value is substituted.

**{L2} Override Code** \_\_\_\_\_

Enter the Override Code strategy:

- 0 = Never use override code
- 1 = Always use override code
- 2 = Use override code on transmitter failure
- 3 = On transmitter failures use last hour's average

**{L1} at 4mA\*** \_\_\_\_\_

Enter the pressure engineering units that the transducer outputs at 4mA or 1 volt, or lower range limit (LRV) of Honeywell Smart Transmitters.

**{L1} at 20mA\*** \_\_\_\_\_

Enter the pressure engineering units that the transducer outputs at 20mA or 5volts, or upper range limit (URV) of Honeywell Smart Transmitters.

**{L1} Damping Code** \_\_\_\_\_

This entry only applies to Honeywell digital transmitters connected to an H Type combo module. The process variable (i.e., pressure) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry.

For Pressure Transmitters, enter the selected Damping Code:

- |                  |                |
|------------------|----------------|
| 0 = 0 seconds    | 5 = 2 seconds  |
| 1 = 0.16 seconds | 6 = 4 seconds  |
| 2 = 0.32 seconds | 7 = 8 seconds  |
| 3 = 0.48 seconds | 8 = 16 seconds |
| 4 = 1 seconds    | 9 = 32 seconds |

## 2.10.4. Prover Pressure Settings



**Prover Pressure Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the **[Prog]** key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press **[Prove] [Press] [Enter]** and use **[↑] / [↓]** keys to scroll.

	<u>Inlet</u>	<u>Outlet</u>
<b>Low Alarm Limit</b>	_____	_____
Enter the pressure below which the prover low alarm activates. Transducer values approximately 5% below this entry activate the transducer fail low alarm.		
<b>High Alarm Limit</b>	_____	_____
Enter the pressure above which the prover high alarm activates Transducer values approximately 10% above this entry activate the transducer fail high alarm.		
<b>{L2} Override</b>	_____	_____
Enter the pressure value that is substituted for the live transducer value, depending on the override code. An "*" displayed along side of the value indicates that the override value is substituted.		
<b>{L2} Override Code</b>	_____	_____
Enter the Override Code strategy: 0 = Never use override code 1 = Always use override code 2 = Use override code on transmitter failure 3 = On transmitter failures use last hour's average		
<b>{L1} at 4mA</b>	_____	_____
Enter the pressure engineering units that the transducer outputs at 4mA or 1volt, or lower range limit (LRV) of Honeywell Smart Transmitters.		
<b>{L1} at 20mA*</b>	_____	_____
Enter the pressure engineering units that the transducer outputs at 20mA or 5volts, or upper range limit (URV) of Honeywell Smart Transmitters.		
<b>{L1} Damping Code</b>	_____	_____
This entry only applies to Honeywell digital transmitters connected to an H Type combo module. The process variable (i.e., pressure) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry. For Pressure Transmitters, enter the selected Damping Code: 0 = 0 seconds                      5 = 2 seconds 1 = 0.16 seconds                      6 = 4 seconds 2 = 0.32 seconds                      7 = 8 seconds 3 = 0.48 seconds                      8 = 16 seconds 4 = 1 seconds                              9 = 32 seconds		
<b>{L1} Plenum Pressure at 4mA</b>	_____	_____
The plenum pressure applies only to Brooks compact provers. Enter the engineering units that the transmitter outputs at 4mA or 1volt or lower range limit (LRV) of Honeywell Smart Transmitters.		
<b>{L1} Plenum Pressure at 20mA</b>	_____	_____
The plenum pressure applies only to Brooks compact provers. Enter the engineering units that the transmitter outputs at 20mA or 5volts or upper range limit (URV) of Honeywell Smart Transmitters.		
<b>{L1} Plenum Pressure Damping Code</b>	_____	_____
This entry only applies to Honeywell digital transmitters connected to an H Type combo module. The process variable (i.e., pressure) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry. For Pressure Transmitters, enter the selected Damping Code: 0 = 0 seconds                      5 = 2 seconds 1 = 0.16 seconds                      6 = 4 seconds 2 = 0.32 seconds                      7 = 8 seconds 3 = 0.48 seconds                      8 = 16 seconds 4 = 1 seconds                              9 = 32 seconds		

### 2.10.5. Prover Density Pressure Settings



**Prover Density Pressure Setup via the Random Access Method:** To access these settings, in the Program Mode press [Prove] [Density] [Press] [Enter].



\* **NOTE:** Not valid when an RTD Probe is specified.

Inlet

Outlet

#### Low Alarm Limit

Enter the pressure below which the prover densitometer low alarm activates. Transducer values approximately 5% below this entry activate the transducer fail low alarm.

#### High Alarm Limit

Enter the pressure above which the prover densitometer high alarm activates. Transducer values approximately 10% above this entry activate the transducer fail high alarm.

#### {L2} Override

Enter the pressure value that is substituted for the live transducer value, depending on the override code. An "\*" displayed along side of the value indicates that the override value is substituted.

#### {L2} Override Code

Enter the Override Code strategy:

- 0 = Never use override code
- 1 = Always use override code
- 2 = Use override code on transmitter failure
- 3 = On transmitter failures use last hour's average

#### {L1} at 4mA

Enter the pressure engineering units that the transducer outputs at 4mA or 1volt, or lower range limit (LRV) of Honeywell Smart Transmitters.

#### {L1} at 20mA\*

Enter the pressure engineering units that the transducer outputs at 20mA or 5volts, or upper range limit (URV) of Honeywell Smart Transmitters.

#### {L1} Damping Code

This entry only applies to Honeywell digital transmitters connected to an H Type combo module. The process variable (i.e., pressure) is filtered by the transmitter before being sent to the flow computer. The time constant used depends on this entry.

For Pressure Transmitters, enter the selected Damping Code:

- 0 = 0 seconds
- 1 = 0.16 seconds
- 2 = 0.32 seconds
- 3 = 0.48 seconds
- 4 = 1 seconds
- 5 = 2 seconds
- 6 = 4 seconds
- 7 = 8 seconds
- 8 = 16 seconds
- 9 = 32 seconds

## 2.11. Configuring Meter Relative Density / API Relative Density

### 2.11.1. Accessing the Gravity/Density Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press [Setup] [Enter] and a menu similar to the following will be displayed:

```
***  SETUP MENU  ***
Temperature Setup
Pressure Setup
Grav/Density Setup _
```

Use the [↑]/[↓] (up/down arrow) keys to move the cursor to 'Grav/Density Setup' and press [Enter] to access the submenu.

### 2.11.2. Meter Relative Density / Density Settings



**Meter Specific Gravity/Density Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the [Prog] key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then enter the key press sequence that corresponds to the options you want to configure: **Specific Gravity:** To access these settings, press [S.G.] [Enter] or [S.G.] [Meter] [n] [Enter] or [Meter] [n] [S.G./API] [Enter]. **Density:** To access these settings, press [Density] [Enter] or [Density] [Meter] [n] [Enter] or [Meter] [n] [Density] [Enter]. **Digital Densitometers:** To access these settings, press [Factor] [Density] [Meter] [n] [Enter] or [Density] [Factor] [Meter] [n] [Enter]. ("n" represents the meter run # 1, 2, 3 or 4). **Note:** Digital densitometers can only be configured via the Random Access Method.



**INFO:** Densitometer constants are usually on a calibration certificate supplied by the densitometer manufacturer. Usually they are based on SI or metric units. For US customary applications you must ensure that the constants entered are based on gr/cc, °F and PSIG. Constants are always displayed using scientific notation; e.g.:  $K_0 = -1.490205E+00$  (gr/cc). To enter  $K_0$ , press [Clear] and press [-1.490205] [Alpha Shift] [E] [+00] [Enter].

### Relative Density, API Gravity or Density

Station      Meter #1      Meter #2      Meter #3      Meter #4

#### {L1A} Corr Factor \_\_\_\_\_

These entries apply if an analog gravitometer or densitometer is specified during the 'Config Meter Run' in 'Misc. Setup'. They are not available when using API or Specific Gravity gravimeters. Enter the Pycnometer Density Correction Factor (Limit: 0.8 to 1.2). (Usually very close to 1.0000).

#### Low Alarm Limit \_\_\_\_\_

Enter the gravity/density below which the prover densitometer low alarm activates. Transducer values approximately 5% below this entry activate the transducer fail low alarm.

**High Alarm Limit** \_\_\_\_\_

Enter the gravity/density above which the prover densitometer high alarm activates.  
Transducer values approximately 10% above this entry activate the transducer fail high alarm.

**{L2} Override** \_\_\_\_\_

Enter the gravity/density value that is substituted for the live transducer value, depending on the override code. An "\*" displayed along side of the value indicates that the override value is substituted.

**{L2} Override Code** \_\_\_\_\_

Enter the Override Code strategy:

- 0 = Never use override code
- 1 = Always use override code
- 2 = Use override code on transmitter failure
- 3 = On transmitter failures use last hour's average
- 4 = On transmitter failure use station transducer value
- 5 = On transmitter failure use absolute value of override SG/API of the running product.

**{L1} at 4 mA** \_\_\_\_\_

These entries apply if an analog gravitometer or densitometer is specified during the '**Config Meter Run**' in '**Misc. Setup**'. Engineering units that the transmitter outputs at 4mA or 1volt, or lower range limit (LRV) of Honeywell Smart Transmitters.

<u>Station</u>	<u>Meter #1</u>	<u>Meter #2</u>	<u>Meter #3</u>	<u>Meter #4</u>
----------------	-----------------	-----------------	-----------------	-----------------

**{L1} at 20 mA** \_\_\_\_\_

These entries apply if an analog gravitometer or densitometer is specified during the '**Config Meter Run**' in '**Misc. Setup**'. Engineering units that the transmitter outputs at 20mA or 5 Volts, or upper range limit (URV) of Honeywell Smart Transmitters.

**Digital Densitometers**

The following entries are required if a digital densitometer is specified during the '**Config Meter Run**' in the '**Misc. Setup**' menu. There are three selections which refer to digital densitometers: 4 = Solartron, 5 = Sarasota, 6 = UGC. ({L1} Password Level required, except for the Correction Factor.)

<u>Solartron</u>	<u>Station</u>	<u>Meter #1</u>	<u>Meter #2</u>	<u>Meter #3</u>	<u>Meter #4</u>
------------------	----------------	-----------------	-----------------	-----------------	-----------------

**{L1A} Corr Factor A** \_\_\_\_\_

The Factor A and Factor B entries only apply if an analog (4-20mA density linear) or a digital densitometer is specified during the 'Config Meter Run' in Misc. Setup'. It is not available when using specific gravity gravitometers. Meter Station only applies Factor A. Enter the Pycnometer Density correction factor (Limit: 0.8 to 1.2, usually very close to 1.0000). The densitometer factor is used to correct for minor calibration shifts of the densitometer. This factor is determined by checking the density reading versus the actual density measured using a pycnometer or similar device. You may enter an A or B correction factor for each densitometer. The actual factor depends on an entry made in the product setup area. When SG linear is selected as the density type during the 'Config Meter Run' in the "Misc Setup" Menu, correction factors A and B must be entered using OmniCom Configuration software. These entries will not appear on the OMNI front panel display).

{L1A} Corr Factor B \_\_\_\_\_

**Digital Densitometers Calibration Constants**

{L1} K <sub>0</sub>	_____	_____	_____	_____	_____
{L1} K <sub>1</sub>	_____	_____	_____	_____	_____
{L1} K <sub>2</sub>	_____	_____	_____	_____	_____
{L1} K <sub>18</sub>	_____	_____	_____	_____	_____
{L1} K <sub>19</sub>	_____	_____	_____	_____	_____
{L1} K <sub>20A</sub>	_____	_____	_____	_____	_____
{L1} K <sub>20B</sub>	_____	_____	_____	_____	_____
{L1} K <sub>21A</sub>	_____	_____	_____	_____	_____
{L1} K <sub>21B</sub>	_____	_____	_____	_____	_____
{L1} K <sub>R</sub>	_____	_____	_____	_____	_____
{L1} K <sub>J</sub>	_____	_____	_____	_____	_____

**Sarasota**                      **Station**                      **Meter #1**                      **Meter #2**                      **Meter #3**                      **Meter #4**

{L1B} Corr Factor A \_\_\_\_\_

Pycnometer Density correction factor (usually very close to 1.0000). An A and B factor are provided to cover differing products (limit: 0.8 to 1.2).

{L1B} Corr Factor B \_\_\_\_\_

{L1} D <sub>0</sub>	_____	_____	_____	_____	_____
{L1} T <sub>0</sub>	_____	_____	_____	_____	_____
{L1} T <sub>coef</sub>	_____	_____	_____	_____	_____
{L1} T <sub>cal</sub>	_____	_____	_____	_____	_____
{L1} P <sub>coef</sub>	_____	_____	_____	_____	_____
{L1} P <sub>cal</sub>	_____	_____	_____	_____	_____

**UGC**                                      **Station**                                      **Meter #1**                                      **Meter #2**                                      **Meter #3**                                      **Meter #4**

{L1A} Corr Factor A \_\_\_\_\_

Pycnometer Density correction factor (usually very close to 1.0000). An A and B factor are provided to cover differing products (limit: 0.8 to 1.2).

{L1A} Corr Factor B \_\_\_\_\_

{L1} K <sub>0</sub>	_____	_____	_____	_____	_____
{L1} K <sub>1</sub>	_____	_____	_____	_____	_____
{L1} K <sub>2</sub>	_____	_____	_____	_____	_____
{L1} T <sub>C</sub>	_____	_____	_____	_____	_____
{L1} K <sub>t1</sub>	_____	_____	_____	_____	_____
{L1} K <sub>t2</sub>	_____	_____	_____	_____	_____
{L1} K <sub>t3</sub>	_____	_____	_____	_____	_____
{L1} P <sub>c</sub>	_____	_____	_____	_____	_____
{L1} K <sub>p1</sub>	_____	_____	_____	_____	_____
{L1} K <sub>p2</sub>	_____	_____	_____	_____	_____
{L1} K <sub>p3</sub>	_____	_____	_____	_____	_____



## 2.12. Configuring PID Control Outputs



**PID Control Output Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the [Prog] key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press [Control] [n] [Enter] (n = PID Control Loop # 1, 2, 3 or 4). Use [↑] / [↓] keys to scroll.

### 2.12.1. Accessing the PID Control Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press [Setup] [Enter] and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
Pressure Setup
Grav/Density Setup
PID Control Setup _
  
```

Use the [↑]/[↓] (up/down arrow) keys to move the cursor to 'PID Control Setup' and press [Enter] to access the submenu.

### 2.12.2. PID Control Output Settings

Loop #1   Loop #2   Loop #3   Loop #4

#### Operating Mode

##### Manual Valve Open (Y/N) \_\_\_\_\_

Enter [Y] to adjust the valve open % and adjust using the [↑]/[↓] keys. Enter [N] to change to AUTO mode.

##### Local Setpoint (Y/N) \_\_\_\_\_

Enter [Y] to use a local set point and adjust using the [↑]/[↓] keys. Enter [N] for 'Remote' set point mode.

##### Secondary Setpoint Value \_\_\_\_\_

Enter the value in engineering units for the set point of the secondary variable. The primary variable will be the controlled variable until the secondary variable reaches this set point. The secondary variable will not be allowed to drop below or rise above this set point, depending on the "Error Select" entry in the 'Config PID' menu.

#### Tuning Adjustments

##### {L1} Primary Gain Factor \_\_\_\_\_

Enter a value between 0.01 to 99.99 for the Primary Gain Factor (Gain=1/Proportional Band).

##### {L1} Primary Integral Factor \_\_\_\_\_

Enter a value between 0.0 and 40.00 for the Primary Integral Factor (Repeats/Min=1/Integral Factor ⇔ the reciprocal of the reset period).

##### {L1} Secondary Gain Factor \_\_\_\_\_

Enter a value between 0.01 to 99.99 for the Secondary Gain Factor (Gain=1/Proportional Band).

The actual controller gain factor used when controlling the secondary variable is the product of this entry and the 'Primary Gain Factor'. Tune the primary control variable first and then use this entry to adjust for stable control of the secondary variable.

##### {L1} Secondary Integral Factor \_\_\_\_\_

Enter a value between 0 and 40.00 for the Secondary Integral Factor (Repeats/Min=1/Integral Factor ⇔ the reciprocal of the reset period).



**PID Startup, Stop and Shutdown Ramp Command Points:** *These have been added to eliminate the need to manipulate the PID permissives directly. Using these command points greatly simplifies operation of the PID ramping functions. (See database points 1727-1730, 1788-1791, 1792-1795 respectively.)*

Loop #1    Loop #2    Loop #3    Loop #4

**{L1} Deadband %** \_\_\_\_\_

Enter the dead band percent range. PID Control will only compensate for setpoint deviations out of this range. The control output will not change as long as the process input and the setpoint error (deviation) is within this dead band percentage limit range.

**{L1} Startup Ramp %** \_\_\_\_\_

Enter the maximum percentage to which the valve movement is limited per 500 msec at start-up. The control output is clamped at 0% until the 1<sup>st</sup> PID Permissive (PID #1-#4 ⇨ database points 1722-1725) is set true. The control output % is then allowed to increase at the start-up ramp rate.

**{L1} Shutdown Ramp %** \_\_\_\_\_

Enter the maximum percentage to which the valve movement is limited per 500 msec at shutdown. When the 1<sup>st</sup> PID Permissive is lost, the control output will ramp-down towards 0% at the shutdown ramp rate.

During the ramp-down phase, a 2<sup>nd</sup> PID Permissive (PID #1-#4 ⇨ database points 1752-1755) is used to provide a “ramp hold” function. If this 2<sup>nd</sup> permissive is true, 100 msec before entering the ramp-down phase, the control output % will ramp-down and be held at the minimum ramp-down limit % (see the following entry) until it goes false. The control output will then immediately go to 0% .

**{L1} Minimum Ramp to %** \_\_\_\_\_

Enter the minimum percentage that the control output will be allowed to ramp down to. In many cases, it is important to deliver a precise amount of product. This requires that the control output be ramped to some minimum % and held there until the required delivery is complete. The control output is then immediately set to 0%.

**Primary Controlled (Remote Setpoint) Variable**

**{L1} Low Limit** \_\_\_\_\_

Enter the engineering unit value below which the primary setpoint variable is not allowed to drop while in the remote setpoint mode.

**{L1} High Limit** \_\_\_\_\_

Enter the engineering unit value above which the primary setpoint variable is not allowed to rise while in the remote setpoint mode.

**{L1} at 4mA** \_\_\_\_\_

Enter the engineering unit value of the remote setpoint at 4 mA (1 volt) input. You must set this and the following entry even if you do not intend to use a remote setpoint. They are used to determine the scaling of the primary controlled variable.

**{L1} at 20mA** \_\_\_\_\_

Enter the engineering unit value of the remote setpoint at 20mA (5 volt) input. You must set this and the previous entry even if you do not intend to use a remote setpoint. They are used to determine the scaling of the primary controlled variable, which is usually 2 times the normal operating setpoint setting.

**Secondary Controlled (Setpoint) Variable**

**{L1} Zero Value** \_\_\_\_\_

If a secondary controlled variable is used, enter the value in engineering units of the variable which will represent zero.

**{L1} Full Scale Value** \_\_\_\_\_

Enter the value in engineering units of the secondary variable at controller full scale, which is usually 2 times the normal operating setpoint setting.

## 2.13. Configuring Provers



**Prover Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the **[Prog]** key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press **[Prove]** **[Setup]** **[Enter]** and use **[↑]** / **[↓]** keys to scroll .

### 2.13.1. Accessing the Prover Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press **[Setup]** **[Enter]** and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
Grav/Density Setup
PID Cont`rol Setup
Prover Setup      _
  
```

Use the **[↑]**/**[↓]** (up/down arrow) keys to move the cursor to 'Prover Setup' and press **[Enter]** to access the submenu.

### 2.13.2. Prover Settings

**{L2} Number of Runs to Average** \_\_\_\_\_

Enter the number of consecutive runs required to be considered a complete prove sequence. This number must be between 2 and 10.

**{L2} Maximum Number of Runs** \_\_\_\_\_

Enter the maximum number of runs that will be attempted to achieve a complete prove sequence. This number must be between 2 and 99.

**{L2} Prover Type** \_\_\_\_\_

Enter the type of prover in use:

- 0 = Unidirectional Pipe Prover
- 1 = Bi-directional Pipe Prover
- 2 = Unidirectional Compact Prover
- 3 = Bi-directional Small Volume Prover
- 4 = Master Meter
- 5 = Two-Series Bi-directional Pipe Prover.

Select the Unidirectional Compact **[2]** if you are using a Brooks Compact Prover.

Select the Master Meter Method to compare meter 1, 2 or 3 against the master meter. Meter #4 is always the master meter.

For Double Chronometry Proving use type 2 or 3.

**{L1} Prover Volume** \_\_\_\_\_

This entry does not apply when the prover type selected is a Uni-Compact. See Up Volume and Down Volume entries for uni-compact. Enter the water draw volume of the prover at base temperature and pressure.

Certain models of compact provers have different water draws, depending on whether the meters are upstream or downstream. This entry represents the "round-trip" volume for bi-directional provers and the downstream volume for compact provers. When using the Master

Meter Method, enter the minimum volume that must flow through the master meter (Meter #4) for each prove run.

**{L2} Number of Passes per Run to Average** \_\_\_\_\_

This entry applies to Unidirectional and Bi-directional compact provers only. Enter the number of single passes that will be averaged to make each run when using the pulse interpolation method. Valid entries are 1 through 25. A pass is round trip when using a bi-directional prover.

**{L1} Area Thermal Expansion Coeff Prover Barrel (Ga)** \_\_\_\_\_

This entry applies to unidirectional compact provers only (Brooks SVP and Calibron) Enter the squared coefficient of thermal expansion for the barrel of the compact prover. This Thermal Expansion Coefficient is used to calculate the CTSP factor for the compact prover:

For US Units: Carbon Steel = 0.0000124; Stainless Steel = 0.0000177, 304 Stainless Steel = 0.0000192, 17-4 Stainless Steel = 0.0000120. For Metric Units: Carbon Steel = 0.0000223; Stainless Steel = 0.0000319. 304 Stainless Steel = 0.0000345, 17-4 Stainless Steel = 0.0000216. (Revised 06/04)

**{L1} Linear Coefficient of Switch Rod (GI)** \_\_\_\_\_

This entry applies to Brooks Compact Provers or Calibron Provers Only. These provers use an invar rod to separate the optical detector switches. The Brooks compact Prover Switch rod has a coefficient of 0.0000008 per °F (US units) or 0.0000014 per °C (metric units). The Calibron Prover Switch Rod has a coefficient of 0.0000062 per °F (US units) or 0.0000116 per °C (metric units). (Revised 06/04)

**{L1} Plenum Pressure Constant** \_\_\_\_\_

This entry applies to Brooks Compact Provers only. Enter the Nitrogen Spring Plenum Pressure Constant used to calculate the plenum pressure needed to operate the Brooks Compact Prover. This pressure is related to the prover line pressure at the time of proving:

**Plenum Pressure = (Line Pressure / Plenum Constant) + 60 Psig**

The plenum constant depends on the size of the Brooks Compact Prover. Valid values are:

SIZE	PLENUM CONSTANT
8-inch	3.50
12-inch Mini	3.20
12-inch Standard	3.20

SIZE	PLENUM CONSTANT
18-inch	5.00
24-inch	5.88
Larger	Refer to Brooks

**{L2} Plenum Pressure Deadband %** \_\_\_\_\_

This entry applies to Brooks Compact Provers only. Enter the Plenum Pressure Deadband %. The Brooks Compact Prover requires that the plenum pressure be maintained within certain limits. The flow computer calculates the correct plenum pressure at the beginning of each prove sequence and will charge or vent nitrogen until the measured plenum pressure is within the specified deadband %.

**{L1} Prover Upstream Volume** \_\_\_\_\_

This entry applies to uni-compact provers only. Enter the upstream water draw volume at base temperature and pressure, if applicable.

**{L1} Prover Downstream Volume** \_\_\_\_\_

This entry applies to uni-compact provers only. Enter the downstream water draw volume at base temperature and pressure, if applicable.

**{L1} Over-travel** \_\_\_\_\_

This entry does not apply to Master Meter proving. Enter the estimated amount of flow that the sphere or piston displaces after activating the first detector switch, multiplied by 1.25.

**{L2} Inactivity Timer** \_\_\_\_\_

Enter the time in seconds before the prove is aborted due to prover inactivity. Make sure you allow enough time for the sphere or piston to travel between detector switches at the lowest flow rate expected. When using the Master Meter Method, allow enough time for the amount of flow to pass through the master meter at the lowest expected flow rate.

**{L1} Prover Diameter** \_\_\_\_\_

This entry is not applicable to Master Meter proving. Enter the internal diameter of the prover tube in inches or mm.

**{L1} Prover Wall Thickness** \_\_\_\_\_

This entry is not applicable to Master Meter proving. Enter the wall thickness of the prover tube in inches or mm, which is used to calculate the CPSP factor.

**{L1} Modulus of Elasticity** \_\_\_\_\_

This entry is not applicable to Master Meter proving. Enter the Prover Tube Modulus of Elasticity used to calculate the CPSP factor. (Revised 06/04)

For US Units: Mild Steel = 3.0E7; Stainless Steel = 2.8E7 to 2.9E7: (Brooks is 2.85E7)

For Metric Units: 2.07E8 or 1.93E8 to 2.0E8.

**{L1} Cubical Thermal Expansion Coefficient of Tube (Gc)** \_\_\_\_\_

This entry is not applicable to Compact Provers and Master Meter proving. Enter the Prover Tube Cubical Coefficient of Thermal Expansion for full sized pipe provers, used to calculate the CTSP factor. (Revised 06/04)

For US Units: Mild Steel = 0.0000186; Stainless Steel = 0.0000265.

For Metric Units: Mild Steel = 0.0000335; Stainless Steel = 0.00000477.

**{L1} Base Pressure** \_\_\_\_\_

This entry is not applicable to Master Meter proving. Enter the atmospheric pressure in PSIG or kPag, at which the prover was water drawn.

**{L1} Base Temperature** \_\_\_\_\_

This entry is not applicable to Master Meter proving. Enter the Base Temperature in °F or °C at which the prover was water drawn. This entry is used to calculate CTSP.

**{L2} Stability Check Sample Time** \_\_\_\_\_

Enter the Stability Check Sample Time in seconds, used to calculate the rate of change of temperature and flow rate at the prover or master meter. The prove sequence will not start until the temperature and flow rate are stable.

**{L2} Sample Time Temperature Change ( $\Delta$ Temp)** \_\_\_\_\_

Enter the temperature change allowed during the stability sample time (see previous entry). The change in temperature per sample period must be less than this value for the temperature to be considered stable enough to start a prove.

**{L2} Sample Time Flow Rate Change ( $\Delta$ Flow)** \_\_\_\_\_

Enter the change in flow rate allowed during the stability sample time (see previous two entries). The change in flow rate per sample period must be less than this value before the flow rate is considered to be stable enough to start a prove.

**{L2} Prover-to-Meter Temperature Deviation Range** \_\_\_\_\_

Enter the prover-to-meter temperature range (°C or °F) allowable after the temperature and flow rate have stabilized. The temperature at the meter and the prover must be within this limit or the prove sequence attempt will be aborted.

**{L2} Prove Run Meter Factor / Counts Repeatability** \_\_\_\_\_

Enter for the run repeatability calculation based on:

- 0 = Run Counts
- 1 = Run Calculated Meter Factor

Run counts repeatability is a more stringent test but may be difficult to achieve due to changing temperature and pressure during the prove sequence. Calculating repeatability based upon the calculated meter factor takes into account variations in temperature and pressure, and may be easier to achieve.

**{L2} Run Repeatability Maximum Deviation %** \_\_\_\_\_

Enter the maximum allowable percentage deviation between run counts or run meter factors (depending on selection of previous entry). The deviation is calculated by comparing the high/low meter counts or meter factors based on their low point, as follows:

$$\text{Deviation} = 100 (\text{High} - \text{Low}) / \text{Low Point}$$

This deviation is always calculated using the meter factor when the Master Meter Method of proving is selected.

**{L2} Meter Factor Deviation Percent** \_\_\_\_\_

The prove meter factor (just calculated) is compared against the current meter factor and must be within this percentage range to be accepted as a valid meter factor.

**{L2} Automatic Meter Factor Implementation?** \_\_\_\_\_

Enter [Y] to automatically implement the new meter factor and store in the appropriate product file. Enter [N] to select not to automatically implement the meter factor determined from the prove.

**{L2} Apply Meter Factor Retroactively?** \_\_\_\_\_

If you selected to auto-implement the meter factor for the previous entry, enter [Y] to retroactively apply the Meter Factor from the beginning of the batch. The old meter factor will be back calculated out of the current batch and daily totals. The batch and daily totals will be recalculated using the new meter factor. Enter [N] to have the Meter Factor applied from this point on.

**{L2} Archive All Reports Y/N** \_\_\_\_\_**{L2} Manual Implementation Time Limit** \_\_\_\_\_

In cases where 'Automatic Meter Factor Implementation' is not selected, the meter factor just calculated can be implemented manually by activating Modbus point **1787** within this number of minutes after the prove is completed. Activating point **1787** after the time limit will have no effect.

**Auto-Prove Flow Rate Change Percent** \_\_\_\_\_

This entry does not apply to Master Meter proving. Enter the Auto-Prove Flow Rate Change Percent Threshold. The Flow Rate Percent Change Flag will be set if the current flow rate differs from the last meter proving flow rate by more than this percent (i.e., a request for an auto-prove sequence will be flagged if the net/mass flow rate differs from the last proved rate by more than this percent, and remains outside this limit for the flow rate change period). A request for an automatic prove will only be made if both the Percent Change Flag and the Minimum Flow Change Flag are set (see following entry).

**Auto-Prove Flow Rate Change Threshold** \_\_\_\_\_

This entry does not apply to Master Meter proving. Enter the Minimum Flow Rate Change Threshold for automatic proving. The Minimum Flow Change Flag will be set if the current flow rate differs from the last meter proving flow rate by more than this amount. A request for an automatic prove will be made if both the Percent Change Flag and the Minimum Flow Change Flag are set (see previous entry). This entry eliminates unnecessary proves that would occur at low flow rates where the percentage change threshold would be a very small flow rate change.

**Auto-Prove Flow Rate Stable Period** \_\_\_\_\_

This entry does not apply to Master Meter proving. Enter the Flow Rate Stable Period in minutes, for auto-proving. A change in flow rate must be sustained for at least this period of time before an auto-prove sequence will be attempted.

**Auto-Prove Meter Down (Hours)**

This entry does not apply to Master Meter proving. Enter the Meter Shut-in Period in hours, for auto-proving. The need for an auto-prove will be flagged if a flowmeter is shut-in for more than this period of time.

**Auto-Prove Startup Flow**

This entry does not apply to Master Meter proving. Enter the startup flow for auto-proving. This is the amount of flow which must occur after startup before an auto-prove is attempted, after a meter has been shut-in for more than the Meter Shut-in Period (see previous entry).

**Auto-Prove Maximum Flow between Proves**

This entry does not apply to Master Meter proving. Enter the Maximum Flow between Proves. This entry represents the maximum amount of flow that can occur before a meter will be flagged for an auto-prove sequence, if the flow remains stable and the meter is not shut-in

## 2.14. Configuring Products



**Product Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the **[Prog]** key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press **[Product] [Enter]** or **[Product] [n] [Enter]** ( $n = \text{Product \# 1 through 16}$ ). Use **[↑]** / **[↓]** keys to scroll.

### 2.14.1. Accessing the Product Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press **[Setup] [Enter]** and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
PID Control Setup
Prover Setup
Product Setup  _
  
```

Use the **[↑]**/**[↓]** (up/down arrow) keys to move the cursor to 'Product Setup' and press **[Enter]** to access the submenu.

### 2.14.2. Product Settings

**Product #1****{L1} Name**

Enter the name of the product (up to 8 alphanumeric characters), right justified.

**{L1} Table Select**

Enter the number that corresponds to the API or GPA table to use for the product:

0	API 2540 Table 24A (US Units) / Table 54A (Metric Units)	18	m-xylene
1	API 2540 Table 24A (US Units) / Table 54A (Metric Units)	19	Styrene
2	Table 24C (US units) / Table 54C (metric units).	20	Xylene
3	GPA TP16 (US units) / TP16M (metric units).	21	p-Xylene
4	Mass Calculation	22	Cyclohexane
5	Propylene API 11.3.3.2 9 (US units) / 11.3.3.2M (metric units).	23	Ethylbenzene
6	E/P Mix.	24	Cumene
7	P/P Mix	25	Aromatic Hydrocarbon 300 - 350 Deg F 148.9 – 176.7 C
8	Ethylene IUPAC.	26	Aromatic Hydrocarbon 350 - 400 Deg F 176.7 – 204.4 C
9	Ethylene NIST 1045.	27	Water
10	Ethylene API 2565/11.3.2.	28	API 11.1 Crude
11	Carbon Dioxide CO2PAC.	29	API 11.1 Refined Products
12	Table 24 - 1952 Edition (US units) / Table 54 - 1952 Edition (metric units).	30	API 11.1 Lubricating Oil (Revision 20)
13	ASTM D1550/1551.	30	NGLProduct #1 and #2 Only) Revision 24
14	ASTM D1555.	31	API 11.1 Specialized Liquid
15	GPA TP27 Table 23/24E (US units) / Table 53/54E (metric units).	32	Anhydrous Ammonia
16	Benzene	40	NGL Products 1 & 2 Only
17	Toluene		





**INFO:** The following data, rounded to 4 digits is from GPZ 2145-92 and TP16:

Product	S.G.	kg/m3		Product	S.G.	kg/m3
Ethane	.3562	355.85		Iso Pentane	.6247	624.08
Propane	.5070	506.90		n-Pentane	.6311	630.48
HD5	.5010	500.50		n-Hexane	.6638	663.14
	.5050	504.50		Natural Gasolines	.6650	664.34
	.5100	509.50		n-Heptane	.6882	687.52
Propylene	.5228*	522.28*		n-Octane	.7070	706.30
Iso Butane	.5629	562.34		n-Nonane	.7219	721.19
	.5650	564.44		n-Decane	.7342	733.48
n-Butane	.5840	583.42				
	.5850	584.42				

\* Propylene figures are derived from API 11.3.3.2.



**INFO:** API 2540; Tables 23A or 23B (US), or 53A or 53B (metric); are also automatically used when applicable.

Tables 24A and 53A apply to Generalized Crude Oils (SG range: 1.076-.6110; Dens range: 1075-610.4).

Tables 24B and 53B apply to Generalized Products (SG range: 1.076-.6535; Dens range: 1075-652.8).

GPA TP16 and TP16M apply to LPG/NGL Products (SG range: .637-.495 on Version 20, and 636.4-494.5 on Version 24 of the OMNI).

These calculation methods use API Chapter 11.2.1 or 11.2.2, and 11.2.1M or 11.2.2M to calculate the pressure correction factor 'CPL'.

### {L2} API Relative Density (Gravity) Override

This entry applies only to US units (Revision 20). It will appear depending on which table is selected above. Enter the API Gravity at reference conditions. It is used to calculate the Volume Correction Factor (VCF) and the Pressure Correction Factor (CPL). The flow computer will accept any positive override value and use it as the API in calculations. The override gravity can also be entered as specific gravity (see next entry).

To use the live measured density or gravity value (obtained from a densitometer/gravitometer) in the equations, enter any minus number. The flow computer will then correct the signal from the densitometer or gravitometer to 60°F, if required (this may be flowing at flowing or reference conditions - see Meter Run I/O Point Configuration).

Should the gravitometer fail, the flow computer can be made to use the absolute value of the API Gravity Override. If the override code in 'Grav/Density Setup' is set to '5 = On transmitter failure', use absolute value of override SG/API for this product.

### {L2} Relative Density (SG) Override

This entry applies only to US units (Revision 20). It will appear depending on which table is selected above. You may enter an override gravity as either API or SG units when measuring crude oil or generalized refined products. The Computer will accept any positive override value and use it in the calculations.

To use the live measured density or gravity value (obtained from a densitometer/gravitometer) in the equations, enter any minus number. The flow computer will then correct the signal from the densitometer or gravitometer to 60°F, if required (this may be flowing at flowing or

reference conditions - see Meter Run I/O Point Configuration).

Should the gravitometer fail, the flow computer can be made to use the absolute value of the API Gravity Override. If the override code in Grav/Density Setup is set to '5=On transmitter failure', use absolute value of override SG/API for this product.

### {L2} Reference Density Override

This entry applies only to metric units (Revision 24) depending on which table is selected above. This is the density at reference conditions ( $\text{kg/m}^3$  at reference temperature). It is used to calculate the volume correction factor 'VCF' and the pressure correction factor 'CPL'.

**Using a Live Densitometer Signal** - Entering a value with a minus sign ahead of it causes the flow computer to use the live density signal to calculate the density at reference temperature.

**Using the Product Override if the Densitometer Fails** - Selecting 'fail code 5' at the densitometer setup menu will cause the flow computer to stop using the live density signal should it fail, and substitute the absolute value of the density override entry as the reference density. E.g.: Entering -750 causes the computer to ignore the override and use the live densitometer signal as long as the transducer is OK. A reference density of  $750 \text{ kg/m}^3$  will be used if the densitometer should fail.

### {L2} Reference Temperature

This entry applies only to metric units (Revision 24). Enter the base or reference temperature in °C at which net corrected volumes represent equivalent volumes of liquid.

### {L2} Mole Fraction of Propylene

This entry applies only when propylene is the table selected. Enter the fraction of pure propylene. Enter from [0.00] for 0% pure propylene to [1.00] for 100% pure propylene. For example, entering 0.96 represents 96% pure propylene.

### {L2} Alpha Coefficient

This entry applies depending on which table is selected above. API 2540, Tables 24C/54C equations require you to enter a value for 'alpha'. This alpha value is used to calculate the volume correction factor 'VCF'. Enter the thermal expansion coefficient at reference temperature as 0.000xxxx.

### {L2} F Factor Override

This entry applies depending on which table is selected above. Enter 0.0 if you wish the flow computer to use API 11.2.1 or 11.2.2 to calculate the compressibility factor 'F' used in the Cpl equation. Enter the compressibility factor 'F' if you wish to override the API calculated value.

### {L2} Vapor Pressure at 100°F (37.8°C)

This entry applies only when GPA TP16 (or TP16M) is entered for table select. The GPA TP16 standard specifies that the equilibrium pressure of the flowing fluid be calculated according to GPA TP15. Two equations are specified. The first designed for mainly pure products such as propanes, butanes and natural gasolines requires no input data other than the temperature at flowing conditions and the specific gravity at reference conditions. The second improved correlation is suitable for use with more varied NGL mixes where different product mixes could have the same specific gravity but different equilibrium pressures. If you wish to use the improved second method enter the vapor pressure at 100°F or 37.8°C. Enter a minus number to use the normal TP15 method for propanes, butanes and natural gasolines.

M.F. #1    M.F. #2    M.F. #3    M.F. #4

### Meter Factors

Enter the meter factor to be used by this flowmeter whenever this product is flowing. This factor will be automatically updated whenever a meter factor is changed due to a manual entry or an automatic implementation after a successful prove sequence.

### {L1A} Density Factor A/B

Density correction factor. Enter [0] to select Density Factor A to correct the densitometer. Enter [1] to select Density Factor B to correct the densitometer.

**Product #2 – Product #16 will have the same entries as shown above for product #1, Select which additional Products will be used and entry the correct data.**



*To select additional Product2 - Product 16 In the Display Mode press the [Prog] key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press [Product] [Enter] or [Product] [n] [Enter] (n = Product # 1, 2, 3, 4, 5, 6, 7 or 8). Use [↑] / [↓] keys to scroll.*

## 2.15. Configuring Batches

**Note:** See Chapter 3 “Computer Batching Operations” in Volume 2 for information on configuring your flow computer for batches.

## 2.16. Configuring Miscellaneous Factors



*Factor Setup via the Random Access Method: Setup entries require that you be in the Program Mode. In the Display Mode press the [Prog] key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press [[Factor] [Enter], or [Factor] [Meter] [n] [Enter], or [Meter] [n] [Factor] (n = Meter Run # 1, 2, 3, or 4). Use [↑] / [↓] keys to scroll.*

### 2.16.1. Accessing the Factor Setup Submenu

Applying the Menu Selection Method, in the ‘Select Group Entry’ screen (Program Mode) press [Setup] [Enter] and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
Batch Preset Setup
Batch Sequence
Factor Setup      _
  
```

Use the [↑]/[↓] (up/down arrow) keys to move the cursor to ‘Factor Setup’ and press [Enter] to access the submenu.

## 2.16.2. Factor Settings

### {L1} Weight of Water

Also known as absolute density of water. Weight of a barrel of water at 60°F or 15°C, and 14.696 PSia or 101.325 kPa(a). Used to convert from specific gravity units to mass. (From GPA 2145-92 = 8.3372 Lbm/Gal = 350.162 Lbs/Bbl).

**Note:** This is the true weight of water, NOT the conversion factor used to convert grs/cc to Lbs/Bbl sometimes given as 350.507. For metric versions (Revision 26), the default value is 999.012 kg/m<sup>3</sup>.

### {L1} Flow Average Factor

The flow averaging factor is the number of calculation cycles used to smooth the displayed flow rate. A number 1-99 will be accepted. (A calculation cycle is 500msec).

### {L1A} Alarm Deadband %

Nuisance alarms can occur when input variables spend any amount of time near the high or low alarm set points. These nuisance alarms can swamp the alarm log with useless alarms leaving no room for real alarms. This entry sets a percentage limit based on the 'high alarm' entry. A variable must return within the high/low alarm limits by more than this amount before the alarm is cleared. E.g.: High limit is 100°F, Low limit is 20°F, Alarm deadband is set to 2 percent. A transducer input which exceeded 100°F will set the 'high alarm'. The transducer signal must drop 2 percent below the high alarm setpoint (98°F) before the alarm will clear.

### {L1A} Alarm Timer in Seconds.

Nuisance alarms can occur if input variables are toggling in and out of alarm. These nuisance alarms can swamp the alarm log with useless alarms leaving no room for real alarms. When an alarm occurs, it is recorded immediately in the alarm log and the Nuisance Alarm Timer is started. If the same alarm occurs again while the timer is active, it will not be recorded in the log. Enter '0' seconds if you would like to record the alarm every time it occurs.

### {L1} Atmospheric Pressure (ABS)

This setting is used to convert flowing pressure readings in Psig to absolute pressure units PSia for US Units, and for the metric version in absolute units in conformance to pressure (metric) units selected.

### {L1} GrCC-Lbft3

Flowing density measured by most pulse type online densitometers provide grams/cc density units while the AGA 3-92 equations in version 21 firmware and the Anhydrous Ammonia in version 20.74.22+ firmware require density to be measured using lb/ft<sup>3</sup>. Enter the conversion factor needed to convert grams/cc to lb/ft<sup>3</sup>. (20.74.22+ and Application 21 Default = 62.42797).

### {L1} Select Pressure Units

This entry applies only to Revision 24.71+ (metric units) and is a global selection for all pressure variables within the flow computer:

1 Bar = 100 kPa, 1 kg/cm<sup>2</sup> = 98.0665 kPa

Display resolution is as follows:

XX.X kPa, X.XXX Bar, X.XXX kg/cm<sup>2</sup>

### {L1} Roll All Totalizers (# Digits, 0=9, 1=8)

Totalizers within the computer can be rolled at 8 or 9 significant digits. Default value is 9 (0). This is a read-only entry. This entry can only be changed at the keypad of the flow computer.

## Totalizer Decimal Place Resolution

The following are read-only entries that cannot be changed via OmniCom. To change totalizer resolution you must first 'Clear All Totals' in the 'Password Maintenance' menu from the front panel keypad of the flow computer. You will then be given the opportunity to set the totalizing resolution. Valid decimal place settings are: XX; X.X; X.XX; and X.XXX.

**Decimal Places Gross & Net Totalizers** \_\_\_\_\_

Decimal Places for Gross and Net Totalizer Resolution.

**Decimal Places Mass Totalizers** \_\_\_\_\_

Decimal Places for Mass Totalizer Resolution.

**Decimal Places for Correction Factors Appearing on Batch and Prove Reports**

The following two entries determine the number of decimal places for the following factors: Ctlm, Ctlp, Cplm, Cplp, Ctsp, Cpssp, CCF. Meter Factor and Density Pycnometer factor remain fixed at 4. For STRICT adherence to API MPMS 12.2 (default) select 4 decimal places. This is the recommend selection. Selecting 5 decimal places causes the flow computer to perform the normal API internal rounding and truncating rules with the exception of the last round which is to 5 places. Selecting 6 decimal places causes the flow computer to perform no internal rounding and truncating and round the final result to 6 decimal places.

**Decimal Places Factor Batch Report** \_\_\_\_\_

Enter the number of decimal places required for factors to be displayed on the batch report.

**Decimal Places of Meter Factor on Batch Report** \_\_\_\_\_

Enter the number of decimal places required for the meter factor appearing on the batch report.

**Decimal Places of Factors on Prove Report** \_\_\_\_\_

Enter the number of decimal places required for factors to be displayed on the prove report.

**Decimal Places of Meter Factor on Prove Report** \_\_\_\_\_

Enter the number of decimal places required for the meter factor appearing on the prove report.

## 2.17. Configuring Printers



**Printer Setup via the Random Access Method:** Setup entries require that you be in the Program Mode. In the Display Mode press the [Prog] key. The Program LED will glow green and the 'Select Group Entry' screen will appear. Then press [Print] [Setup] [Enter] and use [↑] / [↓] keys to scroll.

### 2.17.1. Accessing the Printer Setup Submenu

Applying the Menu Selection Method, in the 'Select Group Entry' screen (Program Mode) press [Setup] [Enter] and a menu similar to the following will be displayed:

```

***  SETUP MENU  ***
Batch Sequence
Factor Setup
Printer Setup  _

```

Use the [↑]/[↓] (up/down arrow) keys to move the cursor to 'Printer Setup' and press [Enter] to access the submenu.

## 2.17.2. Printer Settings

### {L1} Computer ID \_\_\_\_\_

Appears on all reports. Enter up to 8 alphanumeric characters to identify the flow computer.

### {L1} Print Interval in Minutes \_\_\_\_\_

Enter the number of minutes between each interval report. Entering [0] will disable interval reports. The maximum allowed is 1440 minutes which will provide one interval report per 24-hour period.

### {L1} Print Interval Start Time \_\_\_\_\_:

Enter the start time from which the interval report timer is based (e.g.: Entering '01:00' with a Print Interval of 120 minutes will provide an interval report every odd hour only).

### {L1} Daily Report Time \_\_\_\_\_:

Enter the hour at which the daily report will print at the beginning of the contract day (e.g.: 07:00).

### {L1} Disable Daily Report? \_\_\_\_\_

Enter [Y] to disable the Daily Report (default is 'N'). This simply blocks the report from printing. Data will still be sent to the historical buffers (last 8) and archive if archive is setup.

### {L1} Daylight Savings Time Start \_\_\_\_\_/\_\_\_\_\_/\_\_\_\_\_

Enter the Day/Month/Year that daylight savings time begins.

### {L1} Daylight Savings Time End \_\_\_\_\_/\_\_\_\_\_/\_\_\_\_\_

Enter the Day/Month/Year that daylight savings time ends.

### {L1} Disable Batch Stack Operation? \_\_\_\_\_

Enter Y if you wish to enter more than one product in the batch stack, but not have the batch stack go to the next product in the stack at batch end.

### {L1} Clear Daily Totals at Batch End? \_\_\_\_\_

Enter [N] to provide 24 hour totals of all flow through the flowmeter regardless of what product is run. Select [Y] to clear the totalizers at the end of each batch. This would mean that the daily totalizers would not necessarily represent 24 hours of flow but the amount of flow since the last batch end or the daily report

### {L1} Automatic Hourly Batch Select? \_\_\_\_\_

Enter [Y] to automatically cause a batch end every hour on the hour. If customized reports are selected a batch end report will be printed. If default reports are selected no batch end report will be printed.

### {L1} Automatic Weekly Batch Select? \_\_\_\_\_

Enter a number 1 through 7 to automatically print a batch end report in addition to a daily report on a specific day of the week (0=No batch end, 1=Monday, 2=Tuesday, etc.).

### {L1} Automatic Monthly Batch Select? \_\_\_\_\_

Enter a number 1 through 31 to automatically print a batch end report in place of a daily report on a specific day of the month (0=No batch end).

### {L1} Print Priority \_\_\_\_\_

Enter [0] when the computer is connected to a dedicated printer. If several computers are sharing a common printer, one computer must be designated as the master and must be assigned the number 1. The remaining computers must each be assigned a different Print Priority number between 2 and 12.

### {L1} Number of Nulls \_\_\_\_\_

For slow printers without an input buffer, a number of null characters can be sent after each carriage return or line feed. A number between 0-255 will be accepted. Set this to '0' if your printer supports hardware handshaking and you have connected pin 20 of the printer connector to terminal 6 of the flow computer (see **Chapter 3**).

### {L1} Use Default Snapshot Report? \_\_\_\_\_

Entering [Y] instructs the flow computer to use the default snapshot report format for Snapshot report. Enter [N] if you have downloaded your own custom snapshot templates using the OmniCom program.



**Common Printer Control Codes:** *Epson, IBM & Compatible:* Condensed Mode= 0F, Cancel Condensed= 12, *OKI Data Models:* Condensed Mode= 1D, Cancel Condensed= 1E, *HP Laser Jet II & Compatible:* Condensed= 1B266B3253, Cancel Cond= 1B266B3053.

### {L1} Use Default Batch Report? \_\_\_\_\_

Entering [Y] instructs the flow computer to use the default Batch report format for Batch End. Enter [N] if you have downloaded your own custom batch templates using the OmniCom program.

### {L1} Use Default Daily Report? \_\_\_\_\_

Entering [Y] instructs the flow computer to use the default Daily report format for Daily reports. Enter [N] if you have downloaded your own custom daily templates using the OmniCom program.

### {L1} Use Default Prove Report? \_\_\_\_\_

Entering [Y] instructs the flow computer to use the default Prove report format for Prove reports. Enter [N] if you have downloaded your own custom prove templates using the OmniCom program.

### {L1} Condensed Print Mode Control String \_\_\_\_\_

Certain default report templates exceed 80 columns when the computer is configured for 4 meter runs and a station. Enter the hexadecimal character string which will put the printer into the condensed print mode. Data must be in sets of 2 characters (i.e., 05 not 5). A maximum of 5 control characters are allowed.

### {L1} Cancel Condensed Print Mode Control String \_\_\_\_\_

**Uncondensed Print Mode.** Enter the hexadecimal character string which when sent to the printer will cancel the condensed print mode. Data must be in sets of 2 characters (i.e., 05 not 5). A maximum of 5 control characters are allowed.

### {L1} Company Name \_\_\_\_\_

Two lines of the display allow entry of the Company Name. On each line enter a maximum of 19 characters and press [Enter]. Both lines are concatenated and appear on all reports.

### {L1} Location \_\_\_\_\_

Two lines of the display allow entry of the station location Name. On each line enter a maximum of 19 characters and press [Enter]. Both lines are concatenated and appear on all reports.

**This page left intentionally blank.**



# Chapter 3

## User-Programmable Functions

---

---

### 3.1. Introduction

The computer performs many functions, displays and prints large amounts of data, but there are always some application-specific control functions, calculations or displays that cannot be anticipated.

The OMNI Flow Computer incorporates several programmable features that enable the user to easily customize the computer to fit a specific application.

- o User Programmable Boolean Flags and Statements
- o User Programmable Variables and Statements
- o User Configurable Display Screens
- o User Customized Report Templates

The first three Items are explained here. The last item requires the use of the OmniCom PC configuration software that comes with the flow computer.

### 3.2. User Programmable Boolean Flags and Statements

#### 3.2.1. What is a Boolean?

A Boolean point is simply a single bit register within the computer (sometimes called a flag) which has only two states, On or Off (True or False, 1 or 0). These Boolean flags or points are controlled and/or monitored by the flow computer and represent alarms, commands and status points. Each Boolean point is given an identifying number within the data base of the computer allowing the state (On or Off) to be monitored or modified by assigning that Boolean point to a physical digital I/O point or accessing it via a communication port. A maximum of 24 physical digital I/O points are available for monitoring limit switches, status signals or controlling relays or lamps.



**INFO:** The 4-digit 'point' numbers referred to in this chapter are Modbus index numbers used to identify each variable (Boolean or other) within the Modbus database. A complete listing and descriptions of database points is included in **Volume 4**.

Boolean points are numbered as follows:

1001 through 1024	Physical Digital I/O Points 1 through 24
1025 through 1088	Programmable Boolean Points (64 total)
1089 through 1099	Programmable Pulse outputs (11 total)
1100 through 1199	Meter Run #1 Boolean Points (Alarms, Status etc.)
1200 through 1299	Meter Run #2 Boolean Points (Alarms, Status etc.)
1300 through 1399	Meter Run #3 Boolean Points (Alarms, Status etc.)
1400 through 1499	Meter Run #4 Boolean Points (Alarms, Status etc.)
1500 through 1699	Scratchpad Storage for Results of Boolean Statements
1700 through 1799	Command or Status Inputs
1800 through 1899	Station Boolean Flags (Alarms, Status etc.)
1900 through 1999	Prover Boolean Flags (Alarms, Status etc.)
2100 through 2199	Meter Run #1 Totalizer Roll-over Flags
2200 through 2299	Meter Run #2 Totalizer Roll-over Flags
2300 through 2399	Meter Run #3 Totalizer Roll-over Flags
2400 through 2499	Meter Run #4 Totalizer Roll-over Flags
2600 through 2623	Miscellaneous Station Boolean Points (Alarms, Status etc.)
2700 through 2759	Miscellaneous Boolean Command Points
2800 through 2899	Station Totalizer Flags

### Physical Digital I/O Points (1001 → 1024)

Each of the physical digital I/O points is assigned to a valid Boolean point number as detailed above. Points 1700 through 1799 are command inputs which are described later, all other point assignments indicate that the I/O point is to be set up as an output point. Output points which are dedicated as flow accumulator outputs can be set up for pulse widths ranging from 10 msec to 100 sec in 10 msec increments. All other output point assignments have associated 'time ON delay' and 'time OFF delay' timers which are adjustable from 0.0 to 1000 sec in 100 msec increments.

### Programmable Boolean Points (1025 → 1088)

There are 64 user flags or Boolean points available and are controlled by 64 Boolean statements or equations. These are provided to perform sequencing and control functions. Each statement or equation is evaluated every 100 msec, starting at point 1025 and ending at point 1088. The results of these Boolean statements can then be assigned to physical digital I/O points. There are no restrictions as to what Boolean points can be used in a Boolean statement including the results of other Boolean statements or the status of physical I/O points.

### Programmable Accumulator Points (1089 → 1099)

There are 11 Programmable points that are used with Variable Points 7089 through 7099 for programming pulse outputs for Digital I/O or Front Panel Counters.

### Scratch Pad Boolean Points (1501 → 1649)

The 149 Boolean flags located between 1501 and 1649 are used to store temporary data that has been received via the Modbus link or put there by a Boolean statement. These Boolean variables can be sent to a digital output or used in the Boolean statements described above.

### Momentary Scratch Pad Boolean Points (1650 → 1699)

The 49 Boolean flags located between 1650 and 1699 can be use as momentary commands. When set true they remain on for two seconds.

### 3.2.2. Sign (+, -) of Analog or Calculated Variables (6001 → 8999)

The sign of analog or calculated variables can also be used in a Boolean statements by simply specifying the point number. The Boolean value of the variable is 'true ' if it is positive and 'false' if it has a negative value.

### 3.2.3. Boolean Statements and Functions



**TIP:** Leave plenty of empty statements between programmed ones. This will allow you to modify the execution order of your program if you need to later.



**INFO:** Use the Exclusive OR function "\*" to compare 2 points. The result of an Exclusive OR of 2 points is true only if both points are different states

Each Boolean statement consists of up to 7 variables optionally preceded by the Boolean '**NOT**' function and separated by one of the Boolean functions '**AND**', '**OR**', 'Exclusive **OR**' or '**EQUAL**'. The following symbols are used to represent the functions:

<u>Function</u>	<u>Symbol</u>
NOT	/
AND	&
OR	+
EX OR	*
EQUAL	=
IF	)
GOTO	<b>G</b>
MOVE RANGE	:
INDIRECT	"
COMPARE	%
TIMER FUNCTION	,
RISING EDGE	(
FALLING EDGE	(/
ONE SHOT	@

The '=' function allows a statement to be used to change the state of the Boolean point on the left of the equal sign (usually a command point). Evaluation precedence is left to right.

The “,” (Timer Function). You can delay activating or deactivating a Boolean point in increments of 100mS ticks to avoid momentary alarms or to allow time for status flags to remain on for extended periods so they can be detected via Modbus reads. This operator works in the same manner as the “Delay On” and “Delay Off” settings when configuring a digital output.

**To program the Boolean points proceed as follows:**

From the Display Mode press **[Prog] [Setup] [Enter]** and the following menu will be displayed:

```
*** Misc. Setup ***
Password Maint?(Y)_
Check Modules?(Y)
Config Station?(Y)
Config Meter "n"
Config Prove?(Y)
Config PID?(Y)
Config D/A Out "n"
Front Panel Counters
Program Booleans?
Program Variables?
User Display? "n"
```

Scroll down to '**Set Boolean? (Y)**' and enter **[Y]**. Assuming that no Booleans are as yet programmed, the display shows:

```
BOOLEAN POINT #10xx
25: -
26: -
27:
```

Note that the cursor is on the line labeled 25: At this point enter the Boolean equation that will cause Boolean point 1025 to be ON (TRUE).



**INFO:** Points 1005 and 1006 reflect the current status of physical I/O Points 05 and 06 which could be inputs connected to the outside world or outputs controlling relays, etc

For example, to turn Boolean 1025 ON whenever Boolean 1005 is OFF, **OR** whenever 1006 is ON, enter **[/1005+1006]** (note the use of the '/' to indicate the '**NOT**' function).

```
BOOLEAN POINT #10XX
25: /1005+1006
26: -
27:
```

Boolean 1025 could then be used in the statement following which defines Boolean 1026. For example, by including Boolean 1106 which indicates that meter #1 is being proved (see following page), Boolean 1026 will be ON whenever 'Meter 1 is being proved' **AND** (1005 is **NOT ON OR** 1006 is ON).

```

BOOLEAN POINT #10xx
25: /1005+1006
26: 1106&1025
27: _
    
```

Use the 'Up/Down' arrow keys to scroll though all 64 programmable Boolean points.

Remember that the Boolean statements are evaluated in order starting from 1025 proceeding to 1088. For maximum speed always ensure that statements used in other statements are evaluated ahead of time by placing them in the correct order.

**Example 1: Meter Failure Alarm for Two-Meter Run Application**


**Object:** Using signals from 'flow sensing switches' inserted into the pipeline, provide an alarm output which activates whenever the signals from the flow switches and flow meter signals differ, also provide a snapshot report by setting command point 1719.


**How the hardware is configured:**

Physical I/O points 02 and 03 are setup as inputs by assigning them to 1700 (see the Command and Status Booleans on a later page). They are connected to flow sensing switches on meter runs 1 and 2 respectively. The switches activate with flow.

Physical I/O point 03 is connected to a 'meter fail alarm bell'. The output is assigned to Programmable Boolean 1027. A 'delay ON' of 5 seconds is selected to eliminate spurious alarms which would occur during startup and shutdown. A 'delay OFF' of 5 seconds is selected to ensure that the alarm bell remains on for at least 5 seconds.


**The Booleans are programmed as follows:**

 **INFO:** Booleans 1025, 1026 and 1027 are only used as an example here. Any unused programmable Booleans can be used for this function



**Example 2: Automatic Run Switching for 4-Meter Run Application'**

**Object:** To improve metering accuracy by automatically selecting the correct flow meter run to be active in a multi run application. Small turbines need to be protected from over-speeding while for best accuracy larger turbines should be valved off when the flow drops below their minimum rate. In the example shown, except when switching from one flow meter to the other, only one flow meter run is active at one time. This is one example only. The number of runs open for a given application at any flow rate obviously depends on the size of the flow meters used.



Switching is based on the station flow gross flow rate which is compared to preset switching thresholds entered by the user (See '**Meter Station Settings'** in **Chapter 2**). Threshold Flags 1, 2 and 3 are set and reset according to the actual station flow rate.

The first task is identify the 4 zones and assign programmable Boolean points to them. This allows us to include them in further Boolean statements.

- Zone 1 = **NOT** Flag 1 **AND NOT** Flag 2 **AND NOT** Flag 3
- Zone 2 = Flag 1 **AND NOT** Flag 2 **AND NOT** Flag 3
- Zone 3 = Flag 1 **AND** Flag 2 **AND NOT** Flag3
- Zone 4 = Flag 1 **AND** Flag 2 **AND** Flag 3

As each statement can have only 3 terms in it we must pre-process some part of the equations. The term 'NOT Flag 2 AND NOT Flag 3' appears in Zone 1 and 2 equations.

Now we assign valid point numbers to our statements and rewrite them the way they will be input.

First one term needs to be pre-processed to simplify:

$$1025 = \text{NOT Flag 2 AND NOT Flag 3} \qquad 25: /1825\&/1826$$

Next the flow Zones are defined:


$$\text{Zone 1} = \text{NOT Flag 1 AND NOT Flag 2 AND NOT Flag 3} \qquad 26: /1824\&1025$$

$$\text{Zone 2} = \text{Flag 1 AND NOT Flag 2 AND NOT Flag 3} \qquad 27: 1824\&1025$$

$$\text{Zone 3} = \text{Flag 1 AND Flag 2 AND NOT Flag 3} \qquad 28: 1824\&1825\&/1826$$

$$\text{Zone 4} = \text{Flag 1 AND Flag 2 AND Flag 3} \qquad 29: 1824\&1825\&1826$$

The program thus far looks like:



In our example each meter run valve (V1, V2, V3 and V4) fails closed, energizes to open. A limit switch mounted on each valve indicates the fully open position (SW1, SW2, SW3 and SW4).




Fig. 3-1. Figure Showing Four-Meter Run Valve Switching

### 3.2.4. How the Digital I/O Assignments are Configured

We will use Physical I/O Points 11, 12, 13 and 14 to connect to valve limit switches SW1, SW2, SW3 and SW4 respectively. The switches activate when the appropriate valve is fully open. The points are designated as inputs by assigning them to the dummy input Boolean Point 1700 (see the Command and Status Booleans on a later page). Their data base point numbers are simply their I/O point number preceded by 10 (e.g.: I/O Point 11 = 1011).

Physical I/O points 15, 16, 17 and 18 are wired so as to open the meter run valves V1, V2, V3 and V4. They will be assigned to the Boolean Flags 32 (Point 1032) through 35 (Point 1035) which represent the required state of V1 through V4 as explained below.

The Boolean equations are as follows: Valve 1 (V1)

$$V1 = (\text{NOT SW2 AND NOT SW3 AND NOT SW4}) \text{ OR Zone 1}$$

*Valve #1 is opened when the flow is in Zone 1 and will remain open until at least 1 of the other 3 valves is fully open.*

Valves V2, V3 and V4 are programmed in a similar fashion.

$$V2 = (\text{NOT SW1 AND NOT SW3 AND NOT SW4}) \text{ OR Zone 2}$$

$$V3 = (\text{NOT SW1 AND NOT SW2 AND NOT SW4}) \text{ OR Zone 3}$$

$$V4 = (\text{NOT SW1 AND NOT SW2 AND NOT SW3}) \text{ OR Zone 4}$$

To simplify we pre-process the common terms. The term '**NOT SW3 AND NOT SW4**' is used to determine V1 and V2. The term '**NOT SW1 AND NOT SW2**' is used to determine V3 and V4.

Assigning the next valid point numbers to our Boolean statements and (1030 and 1031) re-write them the way they will be input.

$$1030 = \text{NOT SW3 AND NOT SW4} \qquad 30: /1013\&/1014$$

$$1031 = \text{NOT SW1 AND NOT SW2} \qquad 31: /1011\&/1012$$

The final Equations to determine the state of V1, V2, V3 and V4 on 1032, 1033, 1034, and 1035 are as follows:

$$V1 = \text{NOT SW2 AND (NOT SW3 AND NOT SW4) OR Zone 1} \qquad 32: /1012\&1030+1026$$

$$V2 = \text{NOT SW1 AND (NOT SW3 AND NOT SW4) OR Zone 2} \qquad 33: /1011\&1030+1027$$


$$V3 = (\text{NOT SW1 AND NOT SW2}) \text{ AND NOT SW4 OR Zone 3} \qquad 34: 1031\&/1014+1028$$

$$V4 = (\text{NOT SW1 AND NOT SW2}) \text{ AND NOT SW3 OR Zone 4} \qquad 35: 1031\&/1013+1029$$

The computer evaluates each expression from left to right, so the order of the variables in the above statements is critical. The logic requires that the **OR** variable comes last.



The final program consists of 11 statements:




The only thing left to do now is assign Booleans 1032, 1033, 1034 and 1035 to the appropriate digital I/O points which control V1, V2, V3 and V4. Here is a summary of all of the digital I/O as assigned:

PHYSICAL I/O POINT	ASSIGNED TO BOOLEAN	WIRED TO	SYMBOL
11	1700	Valve 1 Fully Open Switch	SW1
12	1700	Valve 2 Fully Open Switch	SW2
13	1700	Valve 3 Fully Open Switch	SW3
14	1700	Valve 4 Fully Open Switch	SW4
15	1032	Valve 1 Actuator	V1
16	1033	Valve 2 Actuator	V2
17	1034	Valve 3 Actuator	V3
18	1035	Valve 4 Actuator	V4



**INFO:** A summary list of common Boolean flags and alarms is included on the following pages.

Any pulse signal can be latched by using a small program similar to the following:



### 3.3. User Programmable Variables and Statements

There are 64 user-programmable floating point variables within the flow computer numbered 7025 through 7088. The value stored in each of these variables depends on an associated equation or statement. These statements are evaluated every 500 msec and the resultant variable values can be displayed on the LCD display, printed on a report, output to a D-A output, or accessed via one of the communication ports. Typical uses for the variables and statements include providing measurement units conversions, special averaging functions, limit checking and comparisons.

#### 3.3.1. Variable Statements and Mathematical Operators Allowed



**TIP:** The order of precedence is: ABSOLUTE, POWER, MULTIPLY & DIVIDE, ADD & SUBTRACT. Where operators have the same precedence the order is left to right.



**TIP:** RH = Right Hand Variable. LH = Left Hand Variable

Each statement can contain up to 3 variables or constants. The following symbols are used to represent the functions:

<u>Operator</u>	<u>Symbol</u>	<u>Description</u>
ADD	+	Add the two variables or constants
SUBTRACT	-	Subtract the RH variable or constant from LH
MULTIPLY	*	Multiply the two variables or constants
DIVIDE	/	Divide the two variables or constants
CONSTANT	#	The number following is interpreted as a constant
POWER	&	Raise the LH variable to the power of the RH
ABSOLUTE	\$	Use the abs. unsigned value of variable following
EQUAL	=	Make the variable on left equal to the expression on the right.
IF STATEMENT	)	The Logical Value of the variable to the left of the ) operator is true, evaluate the rest of the statement.
GOTO STATEMENT	G	Go to a different variable
MOVE RANGE	:	Move statement or result to another variable.
EXACT COMPARE	%	Compare a value with or equal to
TOTALIZE	,	Used to create custom totalizers where Remainders need to be carried into the custom totalizer in the next calculation cycle.
INDIRECT REFERENCE	;	Use the contents of the point following to Determine the address of the target data base point.
WRITE ASCII STRING	“	Write the ASCII string data contained between the quotes to the address to the left of the = sign
RISING EDGE	(	Rising Edge Operator eg (7501
FALLING EDGE	/	Falling Edge Operator eg (/7501
ONE SHOT	@	One Shot Operator eg @7505
RANGE CHECKER	<	Ranger Checking operator

To program the user variables proceed as follows: From the Display Mode press **[Prog] [Setup] [Enter] [Enter]** and the following menu will be displayed:

```

*** Misc. Setup ***
Password Maint?(Y)_
Check Modules?(Y)
Config Station?(Y)
Config Meter "n"
Config Prove?(Y)
Config PID?"n"
Config D/A Out "n"
Front Panel Counters
Program Booleans?
Program Variables?
  
```

Scroll down to **'Program Variables ? (Y)'** and enter **[Y]**. Assuming that no variables are as yet programmed, the display shows:


```

PROG. VARIABLE #70xx
25:  -
26:  -
27:
  
```

Note that the cursor is on the line labeled 25. At this point enter the variable equation that will calculate the value of variable 7025.


### Example 1:

To provide a variable (7025) which represents Meter Run #1 gross flow rate in barrels per day' in place of the usual barrels per hour, multiply the 'barrels/hour' variable (7101) by the constant 24.



### Example 2:

To provide a variable that represents 'gallons per minute' (7026) we can convert the 'barrels per hour' variable (7101) to gallons by multiplying by 0.7 (0.7 = 42/60 which is the number of gallons in a barrel / divided by the number of minutes in an hour).




**Example 3:**

To provide a variable (7028) that represents meter run #1 temperature in 'degrees Celsius' we subtract 32 from the 'degrees Fahrenheit' variable (7105) and divide the result (7027) by 1.8.

**Example 4:**

Gross barrels within the flow computer are simply flow meter counts divided by the flow meter 'K-Factor' (pulses per barrel); i.e., gross barrels are not meter factored. To provide a variable (7029) which represents Meter Run #1 gross meter factored barrels, multiply the batch gross barrel totalizer (5101) by the batch flow weighted average meter factor (5114).




**3.3.2. Using Boolean Variables in Variable Statements**


Boolean points used in a programmable variable statement are assigned the value 1.0 when the Boolean value is TRUE and 0.0 when the Boolean value is FALSE. By multiplying by a Boolean the user can set a variable to 0.0 when the Boolean point has a value FALSE.

**Example:**

Provide a variable (7025) which functions as a 'Report Number'. The report number which will appear on each 'batch end report' must increment automatically after each batch and reset to zero at the contract day start hour on January 1 of each year.




Boolean 1835 is true one calculation cycle at the end of a batch. Boolean point 1834 is equal to 1.0 for one calculation cycle on the contract day start hour on January 1. If statement 1834 is true we reset counter 7025.



### 3.3.3. Entering Values Directly into the User Variables

In some cases it may be necessary to enter data directly into a user variable (not the expression, just the variable). For example, to preset the 'Report Number' Variable 7025 in the example above we proceed as follows. While in the Display Mode press **[Prog] [Input] [Enter]**, the following will display:



### 3.3.4. Using the Variable Expression as a Prompt

Entering plain text into the expression associated with the variable causes the computer no problems. It ignores the text and leaves the variable unchanged.

For example:

```
USER VARIABLE 7025
Value ?      .00018
Enter Lbs to SCF ?
```

### 3.3.5. Password Level Needed to Change the Value of a User Variable

The first four variables, 7025, 7026, 7027 and 7028 require 'Level 2' password. the remaining variables require 'Level 1'.

### 3.3.6. Using Variables in Boolean Expressions




**NOTE:** See the beginning of this chapter on how to program a Boolean expression if necessary.

In some cases it is also necessary to trigger some type of an event based on the value of a calculated variable. Boolean variables used in the Boolean expressions and described in the previous text can have only one of two values, ON or OFF (TRUE or FALSE). How can the floating point numbers described in this chapter be used in a Boolean expression? Simply using the fact that a variable can be either positive (TRUE) or negative (FALSE). Any variable or floating point can be used in a Boolean expression.

**Example:**


Provide an alarm and snapshot report which will occur when the absolute difference in net flow rate between Meter Runs #1 and #2 exceeds 10 bbls/hr, but only when Meter Run #1 flow rate is greater than 1000 bbls/hr.



Variable 7031 will be positive (TRUE) if Meter Runs #1 and #2 flow rates differ by more than 10 bbls/hr. Variable 7032 will be positive (TRUE) when Meter Run #1 flow rate exceeds 1000 bbls/hr .

User variables 7031 and 7032 shown above must both be positive for the alarm to be set. In addition, we will require that the condition must exist for 5 minutes to minimize spurious alarms. The alarm will be activated by Physical I/O Point #02 and we will use Boolean statements 1025 and 1026.

Enter the following Boolean statements (1025 and 1026 used as example only):



To complete the example we assign Digital I/O Point #02 (Point # 1002) to 1025 and select a 'delay on' of 3000 to provide a 5 minute delay on activate (3000 ticks = 3000 x 100 msec = 300 seconds). Set the 'delay off' to 0.

## 3.4. User Configurable Display Screens



**INFO:** The computer checks for the user display key presses first so you may override an existing display screen by selecting the same key press sequence .

The user can specify up to eight display screen setups. Each display screen can be programmed to show four variables, each with a descriptive tag. Any variable within the data base can be selected for display.

Steps needed to configure a display screen are:

- 1) Specify a sequence of up to four key presses that will be used to recall the display. Key presses are identified by the A through Z character on each key. For each variable (four maximum):
- 2) Specify the eight character string to be used to identify the variable. Any valid characters on the keypad can be used.
- 3) Specify the database index or point number.
- 4) Specify the display resolution of the variable (i.e., how many digits to the right of the decimal point).

Should the number exceed the display capacity, the decimal will be automatically shifted right to counter the overflow. The computer will shift to scientific display mode if the integer part of the number exceeds +/- 9,999,999.

To configure the user display screens proceed as follows:

From the Display Mode press **[Prog] [Setup] [Enter] [Enter]** and the following menu will be displayed:

```

*** Misc. Setup ***
Password Maint?(Y)_
Check Modules?(Y)
Config Station?(Y)
Config Meter "n"
Config Prove?(Y)
Config PID? "n"
Config D/A Out "n"
Front Panel Counters
Program Booleans?
Program Variables?
User Display? "n"
Config Digital "n"
Serial I/O "n"
Custom Packet?(Y)
  
```

Scroll down to **'User Display? "n"'** and enter 1 through 8 to specify which screen you wish to configure.

The screen for Display #1 shows:



Use the 'UP/DOWN' arrows to scroll through the screen. For 'Key Press' enter the key press sequence (up to 4 keys) that will be used to recall this display. The keys are identified by the letters A through Z.




Fig. 3-2. Keypad Layout - A through Z Keys




**Example:**

You wish to recall 'User Display #1' by pressing **[Gross] [Meter] [1]**, select the key sequence **[A] [L] [O]** as shown below.

```

USER DISPLAY #1
Key Press A L O
Var #1 Tag
Var #1 Index
Var #1 Dec.
    
```

Continue configuring User Display #1 by entering the description tag, index number and decimal position required for each variable.



In the preceding example, User Display #1 is used to display Meter Run #1:

Variable #1	Flow rate in MSCF per Hour
Variable #2	Accumulated Batch MSCF
Variable #3	Batch Preset MSCF To Deliver
Variable #4	Meter Factor for the Batch

The screen is recalled by pressing **[Gross] [Meter] [1] [Enter]** and displays:

```
USER DISPLAY # 1
M1 MSCF      1234.56
M1 MMSCF    123456789
M1 PRSET     1234567
M1 MFACT     1.0000
```



# Chapter 4

## Flow Equations and Algorithms for US Customary Units (Revision 20.74+)

### 4.1. Liquid Flow Rate for Flowmeters

The calculations performed for liquid helical turbine, positive displacement and mass flowmeters are as follows:

#### 4.1.1. Volumetric Flow Rate at Flowing Conditions 'Q<sub>v</sub>' (Bbls/hr)

$$Q_{v(Iv)} = \frac{f_{Hz}}{K_{Fnom}} \times 3600$$

#### 4.1.2. Volumetric Flow Rate at Base Conditions 'Q<sub>b</sub>' (Bbls/hr)

$$Q_{b(esv)} = Q_{v(Iv)} \times V_{CF} \times C_{PL} \times M_F$$

$$Q_{b(NSv)} = Q_{b(esv)} \times C_{S\&W}$$

#### 4.1.3. Mass Flow Rate 'Q<sub>m</sub>' (KLbs/hr)

$$Q_m = \frac{Q_{v(Iv)} \times \rho_F \times M_F}{1000}$$

$$Q_m = \frac{Q_{v(esv)} \times \rho_b}{1000}$$

#### 4.1.4. Calculations for Liquid Flows When “Mass Pulses” is Selected (Mass Calculation Standard not Selected)

$$\text{Gross Flowrate} = (\text{bbl/hr}) \frac{\text{Mass Pulses}}{\text{Density} \times \text{Meter Factor}} \times 3600$$

$$\text{Mass Flowrate} = (\text{bbl/hr}) \frac{\text{Mass Pulses}}{\text{K Factor}} \times 3600$$

$$\text{Net Flowrate} = (\text{bbl/hr}) \frac{\text{Mass Pulses}}{\text{Density}} \times \text{CTL} \times \text{CPL} \times 3600$$

#### 4.1.5. Mass Measurement Standard with “Mass Pulses” Selected

Mass Flowrate = Mass Pulses / K-Factor (pulses/bbl) x 3600 x MF  
(multiplied by 3.6 instead of 3600 if Metric OMNI)

Gross Flowrate = Mass Flowrate / Live Density x Meter Factor

Net Flowrate = Gross Flowrate x CTL x CPL x MF

Where CPL set to 1.0000 and CTL = Live Density / Absolute Ref. Density (fixed override entered as a negative number in Product Data Menu)

Therefore,

Net Flowrate = Mass Flowrate / Absolute Ref. Density (fixed override entered as a negative number in Product Data menu)

#### 4.1.6. “Mass Calculation” Algorithm with Volumetric Flowmeter Pulses

Gross Flowrate = Volume Pulses / K-Factor x 3600

Net Flowrate = Gross Flowrate x CTL x CPL x MF

Where CPL set to 1.0000 and CTL = Live Density/Ref. Density (fixed density override entered as a negative number in Product Data menu)

Mass Flowrate = Gross Flowrate x Live Density x MF

## For Propylene

Net Flowrate = Gross Flowrate x CCF x MF

Mass Flowrate = Gross Flowrate x MF x Flowing SG x Wt of H<sub>2</sub>O @60°F & 14.696 Psia

Where:

CCF = Ratio of Calculated Flowing Density to Density at 600F and Saturation Pressure.

Calculated Flowing Density = Density at Flowing Temperature and Pressure  
Calculated using API Chapter 11.3.3.2

Flowing SG = (Calculated Flowing Density in Lbs/Ft<sup>3</sup> x 0.0161846) / 0.999012

## Density of Ethane, Propane and C3+ Mixes

The density of these mixes at flowing temperature and pressure is calculated from a computer algorithm developed by Phillips Petroleum (August 1992). The algorithm was based on data published in GPA TP1, TP2 and TP5.

## Density and other physical properties of Ethylene (IUPAC)

The physical properties of Ethylene calculated are: density, viscosity and isentropic exponent at flowing temperature and pressures. These are calculated using equations based on the International Union of Pure and Applied Chemistry Ethylene Tables (IUPAC)

### Density of Ethylene (NIST)

Ethylene density is calculated using NIST 1045 standard (formerly NBS 1045)

### Density of Ethylene (API)

Ethylene density is calculated using the PAI 11.3.2.1 (formerly API 2565). This is the unmodified original standard.

## 4.1.7. Nomenclature

$Q_{V(IV)}$  = gross indicated volumetric flow rate at flowing conditions, in barrels per hour (Bbls/hr)

$Q_{b(GSV)}$  = gross standard volumetric flow rate at base conditions, in barrels per hour (Bbls/hr)

$Q_{b(NSV)}$  = net standard volumetric flow rate at base conditions, in barrels per hour (Bbls/hr)

$Q_m$  = mass flow rate at flowing conditions for gas turbine flowmeters, in thousands of pounds mass per hour (Klbm/hr)

$f_{Hz}$  = total number of pulses emitted from the flowmeter pulse train per second.

$K_{F_{nom}}$  = nominal K factor, in pulses per barrel ( $f_{Hz}/Bbl$ ) —supplied by the flow transmitter manufacturer

$M_F$  = meter factor in use

$C_{TL}$  = volume correction factor (dimensionless – see 4.2.2 this chapter)

$C_{PL}$  = correction factor for pressure on liquid (dimensionless – see 4.2.3 this chapter)

$C_{S\&W}$  = correction factor for percent of sediment and water (%S&W) content in fluid (dimensionless – see 4.2.3 this chapter)

$\rho_f$  = fluid (live) density at flowing conditions (actual temperature and pressure), in lb/bbl

$\rho_b$  = calculated reference density at base conditions (standard or reference temperature and pressure), in gm/cc

SG = relative density at 60°F and equilibrium pressure multiplied by the weight in pounds of one cubic foot water at 60°F and 14,696 pounds per square inch absolute (PSIa)

## 4.2. Correction Factors for Liquid Flow



**Dimensionless Values:** The calculated correction factors for liquid flow equations are dimensionless; however, consistent units must be used when applicable.

The flow rate equations for flowmeters require calculating the following correction factors:

- \* Meter Factor in Use ' $M_F$ '
- \* Volume Correction Factor ' $V_{CF}$ ' or ( $C_{TL}$ )
- \* Correction Factor for Pressure on Liquid ' $C_{PL}$ '
- \* Correction Factor for Sediment and Water Content ' $C_{S\&W}$ '
- \* Linearizing Coefficient ' $L_{CF}$ '

### 4.2.1. Volume Correction Factor 'C<sub>TL</sub>'

$$C_{TL} = e^{\left( -\alpha T \times \Delta T \times \left[ 1 + \left( 0.8 \times \alpha T_r \times \Delta T \right) \right] \right)}$$

Where:

C<sub>TL</sub> = volume correction factor

e = Napierian constant  
= 2.71828

$\alpha T_r$  = correction for expansion at reference temperature

$$= \frac{K_0 + (K_1 \times RHO_{Tr})}{(RHO_{Tr})^2}$$

Where:

K<sub>0</sub> & K<sub>1</sub> = physical constants derived from mathematical data published in the API MPMS, as follows:

Product Type	Crude Oil	Fuel Oil	Jet Group	Gasoline
API Tables	6A, 23A	6B, 23B	6B, 23B	6B, 23B
API Gravity Range	0° to 100°	0° to 37°	37.1° to 47.9°	52.1° to 85°
Relative Density Range	0.6110 to 1.0760	0.8400 to 1.0760	0.7890 to 0.8395	0.6535 to 0.7705
K <sub>0</sub>	341.0957	103.8720	330.3010	192.4571
K <sub>1</sub>	0	0.2701	0	0.2438

RHO<sub>Tr</sub> = product density at reference temperature

$$= \frac{141.5 \times \rho_{H_2O}}{API_{60} + 131.5}$$

Where:

$\rho_{H_2O}$  = density of water

API<sub>60</sub> = API gravity, in degrees



**When Product is between Jet Group and Gasoline:**

$$\alpha T_r = A + \frac{B}{(\text{RHO}_{T_r})^2}$$

Where:

A & B are numerical constants obtained from API Standards as follows:

Between Jet & Gasoline	
API Tables	6B, 24B, 5B, 23B
API Gravity Range	48.0° to 52.0°
Relative Density Range	0.7710 to 0.7885
A	-0.0018684
B	1489.067

$\Delta T$  = differential Temperature

$$= T_a - T_r$$

Where:

$T_a$  = actual temperature, in °F

$T_r$  = reference temperature, in °F

**4.2.2. Correction Factor for Pressure on Liquid 'C<sub>PL</sub>'**

$$C_{PL} = \frac{1}{1 - (P - P_e) \times F}$$

Where:

$C_{PL}$  = correction factor for pressure on liquid (dimensionless)

$P$  = flowing pressure in pounds per square inch gauge (PSI<sub>g</sub>)

$P_e$  = equilibrium vapor pressure calculated from the correlations developed by Dr. R. W. Hankinson, et al., of Phillips Petroleum Company for members of the GPA, and published as GPA Technical Publication N<sup>o</sup> 15.

$F$  = Compressibility factor for hydrocarbons; using API MPMS 11.2.1 for liquids 0 to 90 API relative density; and using API MPMS 11.2.2 for hydrocarbons ranging 0.35 to 0.637 relative density and -50°F to 140°F.

### 4.2.3. Correction Factor for Sediment and Water Content 'C<sub>S&W</sub>'

$$C_{S\&W} = 1 - \frac{\%S\&W}{100}$$

Where:

C<sub>S&W</sub> = correction factor for percent of sediment and water (%S&W) content in fluid (dimensionless)

%S&W = percent of sediment and water content in fluid

### 4.2.4. Linearizing Coefficient 'L<sub>CF</sub>'

#### Helical Turbine Flowmeters

$$L_{CF} = a + \frac{b}{x} + \frac{c}{x^2} + \frac{d}{x^3} + \frac{e}{x^4} + \frac{f}{x^5} + \frac{g}{x^6}$$

#### Positive Displacement Flowmeters

$$L_{CF} = a = \frac{x^c}{b}$$

Where:

$$x = \frac{\text{flowrate 'Q' (barrels per hour)}}{\text{viscosity 'μ' (centistokes)}}$$

## 4.3. Densities and Other Properties of Liquids

The flow rate equations for flowmeters require determining the following densities and other properties:

- \* Flowing Density 'ρ<sub>f</sub>' for Crude Oil and Refined Products
- \* Density of Ethane, Propane and Methane Mixes
- \* Density of Water
- \* Density and Relative Density (Specific Gravity) Calculated from Live Digital Densitometer Output Frequency

### 4.3.1. Flowing Density ' $\rho_f$ ' for Crude Oil and Refined Products

$$\rho_f = \rho_b \times C_{TL} \times C_{PL}$$

Where:

$\rho_f$  = fluid density at flowing conditions (actual temperature and pressure), in gm/cc

$\rho_b$  = fluid density at base conditions (standard/reference temperature and pressure), in gm/cc

SG = relative density at 60°F and equilibrium pressure multiplied by the weight in pounds of one cubic foot water at 60°F and 14,696 pounds per square inch absolute (PSIa)

$C_{TL}$  = volume correction factor (ASTM D1250)

$C_{PL}$  = correction factor for pressure on liquid

### 4.3.2. Density and Relative Density (Specific Gravity) Calculated from Live Digital Densitometer Output Frequency



**Density and Relative Density Values Determined from Densitometer and Gravimeter Frequency Signals:** The equations used to determine the density and relative density via density transducers are provided by the respective manufacturers.



**Densitometer Calibration Constants** - In many cases the densitometer constants supplied by the manufacturers are based on SI or metric units. You must ensure that the constants entered are based on grams/cc, °F and PSIG. Contact the densitometer manufacturer or OMNI if you require assistance.

The calculations expressed in this section are performed by the OMNI to determine the density from frequency signals received from the following third party densitometers and gravimeters:

- \* Sarasota™ / Peek™
- \* UGC™
- \* Solartron™

#### Sarasota Density (gm/cc)

Sarasota density is calculated using the frequency signal produced by a Sarasota densitometer, and applying temperature and pressure corrections as shown below:

$$D_c = D_{CF} \times \frac{D_0' (t - t_0')}{t_0'} \times \frac{2 + K (t - t_0')}{t_0'}$$

Where:

$D_c$  = corrected density

$D_{CF}$  = Density correction factor

$D_0$  = calibration constant, in mass/volume\*



**NOTE:**  $D_0'$  must be expressed in pounds per cubic foot (gm/cc).

$t$  = densitometer oscillation period in microseconds ( $\mu\text{sec}$ )

$t_0$  = calibration constant, in microseconds

$t_0' = T_{\text{coef}} \times (T_f - T_{\text{cal}}) + P_{\text{coef}} \times (P_f - P_{\text{cal}}) + t_0$

where:

$T_f$  = flowing temperature, in °F

$T_{\text{coef}}$  = temperature coefficient, in  $\mu\text{sec}/^\circ\text{F}$

$P_f$  = flowing pressure, in PSIG

$P_{\text{coef}}$  = pressure coefficient, in  $\mu\text{sec}/\text{PSIG}$

$P_{\text{cal}}$  = calibration pressure, in PSIG

$K$  = spool calibration constant

### UGC Density (grams/cc)



**Density and Relative Density Values Determined from Densitometer and Gravimeter Frequency Signals** - The equations used to determine the density and relative density via density transducers are provided by the respective manufacturers.

UGC density is calculated using the frequency signal produced by a UGC densitometer, and applying temperature and pressure corrections as shown below:

#### UNCORRECTED DENSITY:

$$D = K_0 + (K_1 \times t) + (K_2 \times t^2)$$

Where:

D = uncorrected density, in grams/cc

$\left. \begin{array}{l} K_0 \\ K_1 \\ K_2 \end{array} \right\}$  = calibration constants of density probe, entered via the keypad

t = densitometer oscillation time period, in microseconds ( $\mu\text{sec}$ )

#### CORRECTED DENSITY:

$$D_c = D_{CF} \times \left\{ \left[ \left( K_{P_3} D^2 + K_{P_2} D + K_{P_1} \right) \times (P_f - P_c) \right] + \left[ \left( K_{t_3} D^2 + K_{t_2} D + K_{t_1} \right) \times (T_f - T_c) \right] + D \right\}$$

Where:

$D_c$  = corrected density, in grams/cc

$D_{CF}$  = density correction factor

D = uncorrected density, in grams/cc

$\left. \begin{array}{l} K_{P_1} \\ K_{P_2} \\ K_{P_3} \end{array} \right\}$  = pressure constants

$P_f$  = flowing pressure, in PSIG

$P_c$  = calibration pressure, in PSIG

$\left. \begin{array}{l} K_{t_1} \\ K_{t_2} \\ K_{t_3} \end{array} \right\}$  = temperature constants

$T_f$  = flowing temperature, in °F

$T_c$  = calibration temperature, in °F

### Solartron™ Density (grams/cc)



**Densitometer Calibration Constants** - In many cases the densitometer constants supplied by the manufacturers are based on SI or metric units. You must ensure that the constants entered are based on grams/cc, °F and PSig. Contact the densitometer manufacture or OMNI if you require assistance.

Solartron™ density is calculated using the frequency signal produced by a Solartron frequency densitometer, and applying temperature and pressure corrections as detailed below.

#### UNCORRECTED DENSITY:

$$D = K_0 + (K_1 \times t) + (K_2 \times t^2)$$

Where:

D = uncorrected density, in grams/cc

$\left. \begin{array}{l} K_0 \\ K_1 \\ K_2 \end{array} \right\}$  = calibration constants supplied by Solartron, in grams/cc and °F

t = densitometer oscillation time period, in microseconds (µsec)

#### TEMPERATURE COMPENSATED DENSITY:

$$D_T = D \times [1 + K_{18} (T_f - 68)] + [K_{19} (T_f - 68)]$$

Where:

$D_T$  = temperature corrected density, in grams/cc

D = uncompensated density, in grams/cc

$\left. \begin{array}{l} K_{18} \\ K_{19} \end{array} \right\}$  = calibration constants supplied by Solartron

$T_f$  = Temperature in °F

#### TEMPERATURE AND PRESSURE COMPENSATED DENSITY:

$$D_{PT} = D_T \times [1 + (K_{20} \times P_f) + (K_{21} \times P_f)]$$

Where:

$D_{PT}$  = temperature and pressure compensated density, in grams/cc

$D_T$  = temperature compensated density, in grams/cc

$$K_{20} = K_{20A} + (K_{20B} \times P_f)$$

$$K_{21} = K_{21A} + (K_{21B} \times P_f)$$

$\left. \begin{array}{l} K_{20A} \\ K_{20B} \\ K_{21A} \\ K_{21B} \end{array} \right\}$  = calibration constants supplied by Solartron

$P_f$  = flowing pressure in PSig

**Additional Density Equation for Velocity of Sound Effects:**

For LPG Products in the range of 0.350 - 0.550 grams/cc, the following term can be applied to the temperature and pressure compensated density 'D<sub>tp</sub>':

$$D_{VOS} = D_{tp} + K_r (D_{tp} - K_j)^3$$

Where:

D<sub>VOS</sub> = density for velocity of sound effects, in grams/cc

D<sub>tp</sub> = temperature and pressure compensated density, in grams/cc

$\left. \begin{matrix} K_r \\ K_j \end{matrix} \right\}$  = calibration constants supplied by Solartron

Users wishing to implement the above term are advised to contact Solartron™ to obtain a reworked calibration sheet containing the coefficients 'K<sub>r</sub>' and 'K<sub>j</sub>'. (Typically, K<sub>r</sub> = 1.1 and K<sub>j</sub> = 0.5). If you do not want to implement the above term, enter 0.0 for K<sub>r</sub>.

## 4.4. Recalculation of Batch Ticket

The actual values of API<sub>60</sub> and %S&W that correspond to a batch are obtained after the batch has ended. The option to recalculate the batch ticket adjusts the batch quantities to actual results when the new, actual values of API<sub>60</sub> and %S&W are entered. The calculations performed are:

- \* Recalculated Gross Standard Volume
- \* Recalculated Net Standard Volume
- \* Factored Gross Volume
- \* Net Weight Delivered

### 4.4.1. Recalculated Gross Standard Volume 'GSV<sub>Recalc</sub>' (Bbls)

$$GSV_{Recalc} = BGF \times V_{CF_a} \times C_{PL_a} \times \overline{M}_F$$

Where:

GSV<sub>Recalc</sub> = recalculated gross standard volume, in barrels (Bbls)

BGF = batch gross volume

V<sub>CF<sub>a</sub></sub> = recalculated volume correction factor (correction for temperature on liquid; ASTM D1250) using batch average temperature and entered (actual) API<sub>60<sub>a</sub></sub> (see 5.2.2 this chapter)

C<sub>PL<sub>a</sub></sub> = recalculated correction factor for pressure on liquid using batch average pressure and entered (actual) API<sub>60<sub>a</sub></sub> (see 5.2.3 this chapter)

$\overline{M_F}$  = average meter factor (see 5.2.1 this chapter)

#### 4.4.2. Recalculated Net Standard Volume

##### Recalculated Net Standard Volume in US Customary Units 'NSV' (Bbls)

$$NSV_{\text{Recalc}} = GSV_{\text{Recalc}} \times C_{\text{S\&W}_a}$$

Where:

$NSV_{\text{Recalc}}$  = recalculated net standard volume at 60°F and 0 PSIG, in barrels (Bbls)

$GSV_{\text{Recalc}}$  = recalculated gross standard volume, in barrels (Bbls)

$C_{\text{S\&W}_a}$  = actual correction factor for percent of sediment and water (%S&W) content in fluid (dimensionless)

### 4.5. Liquid Flow Rate for Provers

The calculations performed for unidirectional, bi-directional and small volume (compact) provers are as follows:

#### 4.5.1. Prove Gross Flow Rate at Flowing Conditions (Bbls/hr)

##### Gross Flow Rate for Uni- and Bi-directional Provers ' $PQ_{v(U/B)}$ '

$$PQ_{v(U/B)} = \frac{Pf_{\text{Hz}}}{K_{\text{Fnom}}} \times 3600$$

##### Gross Flow Rate for Small Volume (Compact) Provers ' $PQ_{v(SVP)}$ '

$$PQ_{v(SVP)} = \frac{PV_b}{Td_{\text{vol}}} \times 3600$$

#### 4.5.2. Prove Flow Rate using Pulse Interpolation Method

$$\text{Prove Interpoated Counts} = \text{Integer Counts} \left( \frac{Td_{\text{vol}}}{Td_{\text{fmp}}} \right)$$



### 4.5.3. Meter Factors for Provers

#### Prove Meter Factor 'PM<sub>F</sub>'

$$PM_F = \frac{PV_b \times C_{TSP} \times C_{PSP} \times C_{TLP} \times C_{PLP}}{\frac{Pf}{K_F} \times C_{TLM} \times C_{PLM}}$$

Where:

PM<sub>F</sub> = prove meter factor (dimensionless)

PV<sub>b</sub> = base prover volume at 60°F and 0 PSig, in barrels (Bbls)

Pf = number of flow pulses during the prove

C<sub>TSP</sub> = correction factor for effects of temperature on steel at the prover

#### **For Uni- and Bi-directional Provers:**

$$C_{TSP} = 1 + \left[ (\bar{T} - \bar{T}_b) \times t_{coef} \right]$$

Where:

$\bar{T}$  = average prover temperature, in °F

$\bar{T}_b$  = average base prover temperature, in °F

t<sub>coef</sub> = coefficient of cubical expansion per °F of the prover tube

#### **For Small Volume (Compact) Provers:**

$$C_{TSP} = \left( 1 + \left[ (\bar{T} - \bar{T}_b) \times t_{coef_P} \right] \right) \times \left( 1 + \left[ (\bar{T}_i - \bar{T}_b) \times t_{coef_i} \right] \right)$$

Where:

$\bar{T}$  = average prover temperature, in °F

$\bar{T}_i$  = average prover switch rod temperature, in °F

$\bar{T}_b$  = average base prover temperature, in °F

t<sub>coef<sub>P</sub></sub> = square coefficient of expansion per °F of the prover tube

t<sub>coef<sub>i</sub></sub> = linear coefficient of cubical expansion per °F of the prover switch rod

$C_{PSP}$  = correction factor for effects of pressure on steel at the prover

$$= 1 + \frac{(P - P_b) \times D}{E \times t}$$

Where:

$P$  = internal prover pressure, in PSIG

$P_b$  = base prover pressure, in PSIG

$D$  = internal prover tube diameter, in inches

$E$  = modulus of elasticity for prover tube

$t$  = wall thickness of prover tube, in inches

$C_{TLP}$  = correction factor for effects of temperature on liquid (volume correction factor) at the prover

= volume correction factor ' $V_{CF}$ ', where the actual temperature ' $T_a$ ' is replaced by the average temperature during the prove, at the prover (see **5.2.2** this chapter)

$C_{PLP}$  = correction factor for effects of pressure on liquid at the prover

= correction factor for pressure on liquid ' $C_{PL}$ ', where the flowing pressure ' $P$ ' is replaced by average pressure during the prove, at the prover (see **5.2.3** this chapter)

$C_{TLM}$  = correction factor for effects of temperature on liquid (volume correction factor) at the flowmeter

= volume correction factor ' $V_{CF}$ ', where the actual temperature ' $T_a$ ' is replaced by the average temperature during the prove, at the flowmeter (see **5.2.2** this chapter)

$C_{PLM}$  = correction factor for effects of pressure on liquid at the flowmeter

= correction factor for pressure on liquid ' $C_{PL}$ ', where the flowing pressure ' $P$ ' is replaced by average pressure during the prove, at the flowmeter (see **5.2.3** this chapter)

**Prove Meter Factor at Base Prove Flow Rate 'PM<sub>F<sub>PQ<sub>b</sub></sub></sub>'**

$$PM_{F_{PQ_b}} = PM_F + (M_{F_{BCPQ_b}} - M_{F_{BCPQ_v}})$$

Where:

$M_{F_{PQ_b}}$  = meter factor at base prove flow rate

$PM_F$  = prove meter factor

$M_{F_{BCPQ_b}}$  = meter factor interpolated from base flowmeter factor curve, using base prove flow rate

$M_{F_{BCPQ_v}}$  = meter factor interpolated from base flowmeter factor curve, using actual prove flow rate

**Meter Factor Offset from Base Curve Obtained from Proving 'M<sub>F<sub>PO</sub></sub>'**

$$M_{F_{PO}} = M_{F_{PQ_b}} - M_{F_{BCPQ_b}}$$

Where:

$M_{F_{PO}}$  = meter factor offset from base meter factor curve obtained from proving

$M_{F_{PQ_b}}$  = meter factor at base prove flow rate

$M_{F_{BCPQ_b}}$  = meter factor interpolated from base flowmeter factor curve, using base prove flow rate

**4.6. Calculations for PID Control****4.6.1. Primary Variable Error % 'e<sub>p</sub>'****Forward Action**

$$e_p = \text{Primary Setpoint \% Span} - \text{Primary Variable \% Span}$$

**Reverse Action**

$$e_p = \text{Primary Variable \% Span} - \text{Primary Setpoint \%}$$

### 4.6.2. Secondary Variable Error % 'e<sub>s</sub>'

#### Forward Action

$$e_s = \text{Secondary Gain} \times (\text{Sec. Setpoint \% Span} - \text{Sec. Variable \% Span})$$

#### Reverse Action

$$e_s = \text{Secondary Gain} \times (\text{Sec. Variable \% Span} - \text{Sec. Setpoint \% Span})$$

### 4.6.3. Control Output % 'C<sub>0</sub>' (Before Startup Limit Function)

#### Controlling on Primary Variable

$$C_0 = \text{Primary Gain} \times (e_p + \Sigma e)$$

#### Controlling on Secondary Variable

$$C_0 = \text{Primary Gain} \times (e_s + \Sigma e)$$

### 4.6.4. Integral Error 'Σe'

#### Controlling on Primary Variable

$$\Sigma e = (\text{Repeats per Minute of Primary Variable} \times \text{Sample Period} \times e_p) + \Sigma e_{n-1}$$

#### Controlling on Secondary Variable

$$\Sigma e = (\text{Repeats per Minute of Sec Variable} \times \text{Sample period} \times e_s) + \Sigma e_{n-1}$$

**This page left intentionally blank.**

# Chapter 5

## Flow Equations and Algorithms for SI (Metric) Units (Revision 24.74)

### 5.1. Liquid Flow Rate for Flowmeters

The calculations performed for liquid helical turbine, positive displacement and mass flowmeters are as follows:

#### 5.1.1. Volumetric Flow Rate at Flowing Conditions 'Q<sub>v</sub>' (m<sup>3</sup>/hr)

$$Q_{v(IV)} = \frac{f_{Hz}}{K_{Fnom}} \times 3600$$

#### 5.1.2. Volumetric Flow Rate at Base Conditions 'Q<sub>b</sub>' (Nm<sup>3</sup>/hr)

$$Q_{b(GSV)} = Q_{v(IV)} \times V_{CF} \times C_{PL} \times M_F$$

#### 5.1.3. Mass Flow Rate 'Q<sub>m</sub>' (Ton/hr)

$$Q_m = \frac{Q_{v(IV)} \times \rho_f \times M_F}{1000}$$

$$Q_m = \frac{Q_{v(GSV)} \times \rho_b}{1000}$$

#### 5.1.4. Flow Rates for Mass Pulses

The calculations performed for liquid helical turbine, positive displacement and mass flowmeters when **mass pulses** are selected are as follows:

**Gross Flow Rate 'Q<sub>v(m)</sub>' (m<sup>3</sup>/hr)**

$$Q_{v(m)} = \frac{f_m}{\rho_f \times K_F} \times 3600$$

**Net Flow Rate 'Q<sub>b(m)</sub>' (Nm<sup>3</sup>/hr)**

$$Q_{b(m)} = Q_{v(m)} \times V_{CF} \times C_{PL}$$

**Mass Flow Rate 'Q<sub>m(m)</sub>' (Kg/hr)**

$$Q_{m(m)} = \frac{f_m}{K_F} \times 3600$$

### 5.1.5. Nomenclature

$Q_{V(IV)}$  = gross indicated volumetric flow rate at flowing conditions, in cubic meters per hour ( $m^3/hr$ )

$Q_{b(GSV)}$  = gross standard volumetric (net) flow rate at base conditions, in net cubic meters per hour ( $Nm^3/hr$ )

$Q_m$  = mass flow rate at flowing conditions, in metric ton per hour (Ton/hr)

$Q_{V(m)}$  = gross flow rate when mass pulses are selected, in cubic meters per hour ( $m^3/hr$ )

$Q_{b(m)}$  = net flow rate when mass pulses are selected, in net cubic meters per hour ( $Nm^3/hr$ )

$Q_{m(m)}$  = mass flow rate when mass pulses are selected, in kilograms per hour (Kg/hr)

$f_{Hz}$  = total number of pulses emitted from the flowmeter pulse train per second.

$K_{F_{nom}}$  = nominal K factor, in pulses per cubic meter ( $f_{Hz}/m^3$ )—supplied by the flow transmitter manufacturer

$K_F$  = K factor, in pulses per kilogram ( $f_{Hz}/Kg$ )

$M_F$  = meter factor user-entered via OMNI flow computer keypad, downloaded from SCADA or other emote device, or automatically changed by a sequence of proves (dimensionless — for prove meter factor calculation see 5.4.3 this chapter)

$V_{CF}$  = volume correction factor (dimensionless—see 5.2.1 this chapter)

$C_{PL}$  = correction factor for pressure on liquid (dimensionless—see 5.2.2 this chapter)

$\rho_f$  = fluid (live) density at flowing conditions (actual temperature and pressure), in kilograms per cubic meter ( $Kgs/m^3$ —see 5.3 this chapter)

$\rho_b$  = calculated reference density at base conditions (standard or reference temperature and pressure), kilograms per cubic meter ( $Kgs/m^3$  at 15°F and equilibrium pressure)

## 5.2. Correction Factors for Liquid Flow



**Dimensionless Values** - The calculated correction factors for liquid flow equations are dimensionless; however, consistent units must be used when applicable.

The flow rate equations for flowmeters require calculating the following correction factors:

- \* Volume Correction Factor 'V<sub>CF</sub>'
- \* Correction Factor for Pressure on Liquid 'C<sub>PL</sub>'



### 5.2.1. Volume Correction Factor 'V<sub>CF</sub>'

$$V_{CF} = e \left( -\alpha_{Tr} \times \Delta T \times \left[ 1 + \left( 0.8 \times \alpha_{Tr} \times \Delta T \right) \right] \right)$$

Where:

V<sub>CF</sub> = volume correction factor

e = Napierian constant  
= 2.71828

$\alpha_{Tr}$  = correction for expansion at reference temperature

$$= \frac{K_0 + (K_1 \times RHO_{Tr})}{(RHO_{Tr})^2}$$

Where:

K<sub>0</sub> & K<sub>1</sub> = physical constants derived from mathematical data published in the API MPMS, as follows:

Product Type	Crude Oil	Fuel Oil	Jet Group	Gasoline
API Table	54A	54B	54B	54B
Density Range in Kgs/m <sup>3</sup>	610.5 to 1075	839 to 1075	788 to 838.5	653 to 771
K <sub>0</sub>	613.9723	186.9696	594.5418	346.4228
K <sub>1</sub>	0	0.4862	0	0.4388

RHO<sub>Tr</sub> = product density at reference temperature

#### When Product is between Jet Group and Gasoline:

$$\alpha_{Tr} = A + \frac{B}{(RHO_{Tr})^2}$$

Where:

A & B are numerical constants obtained from API Standards as follows:

Between Jet & Gasoline	
API Tables	54B
Density Range (Kgs/m <sup>3</sup> )	770.5 to 787.5
A	-0.00336312
B	2680.3206

$\Delta T$  = differential temperature

$$= T_a - T_r$$

Where:

T<sub>a</sub> = actual temperature, in °C

T<sub>r</sub> = reference temperature, in °C

### 5.2.2. Correction Factor for Pressure on Liquid 'C<sub>PL</sub>'

$$C_{PL} = \frac{1}{1 - (P - P_e) \times F}$$

Where:

C<sub>PL</sub> = correction factor for pressure on liquid (dimensionless)

P = flowing pressure in kiloPascals gauge (kPag)

P<sub>e</sub> = equilibrium vapor pressure calculated from the correlations developed by Dr. R. W. Hankinson, et al., of Phillips Petroleum Company for members of the GPA, and published as GPA Technical Publication N<sup>o</sup> 15.

F = Compressibility factor for hydrocarbons; using API Chapter 11.2.1M for Crude Oil (638 to 1075 kg/m<sup>3</sup> density, -30°C to 90°C), using API Chapter 11.2.2M for Hydrocarbon Products (350-637 kg/m<sup>3</sup> density, -46°C to 60°C).

## 5.3. Densities and Other Properties of Liquids

The flow rate equations for flowmeters require determining the following densities and other properties:

- \* Flowing Density 'ρ<sub>f</sub>' for Crude Oil and Refined Products
- \* Density of Ethane, Propane and Methane Mixes
- \* Density and Relative Density (Specific Gravity) Calculated from Live Digital Densitometer Output Frequency

### 5.3.1. Flowing Density 'ρ<sub>f</sub>' for Crude Oil and Refined Products

$$\rho_f = \rho_b \times V_{CF} \times C_{PL}$$

Where:

ρ<sub>f</sub> = fluid density at flowing conditions (actual temperature and pressure), in kilograms per cubic meter (Kgs/m<sup>3</sup>)

ρ<sub>b</sub> = fluid density at base conditions (standard/reference temperature and pressure), in kilograms per cubic meter (Kgs/m<sup>3</sup>)  
= density at 15°C and equilibrium pressure

V<sub>CF</sub> = volume correction factor (ASTM D1250)

C<sub>PL</sub> = correction factor for pressure on liquid

### 5.3.2. Density of Ethane, Propane and C3+ Mixes

The density of these mixes at flowing temperature and pressure is calculated from a computer algorithm developed by Phillips Petroleum (August 1992). The algorithm was based on data published in GPA TP1, TP2 and TP5.

### 5.3.3. Density and Relative Density (Specific Gravity) Calculated from Live Digital Densitometer Output Frequency



**Density and Relative Density Values Determined from Densitometer and Gravimeter Frequency Signals:** The equations used to determine the density and relative density via density transducers are provided by the respective manufacturers.



**Densitometer Calibration Constants** - In many cases the densitometer constants supplied by the manufacturers are based on SI or metric units. You must ensure that the constants entered are based on Kg/m<sup>3</sup>, °C and kPa. Contact the densitometer manufacturer or OMNI if you require assistance

The calculations expressed in this section are performed by the OMNI to determine the density from frequency signals received from the following third party densitometers and gravimeters:

- \* Sarasota™ / Peek™
- \* UGC™
- \* Solartron™

#### Sarasota Density (Kgs/m<sup>3</sup>)

Sarasota density is calculated using the frequency signal produced by a Sarasota densitometer, and applying temperature and pressure corrections as shown below:

$$D_c = D_{cf} \times (D_0 \times (t - t_0')/t_0') \times (2 + (K \times (t - t_0')/t_0'))$$

Where:

$D_c$  = corrected density

$D_{CF}$  = Density correction factor

$D_0$  = calibration constant, in mass/volume\*



\* **NOTE:**  $D_0'$  must be expressed in kilograms per cubic meter (Kg/m<sup>3</sup>).

t = densitometer oscillation period in microseconds (μsec)

t<sub>0</sub> = calibration constant, in microseconds

$$t_0' = T_{coef} \times (T_f - T_{cal}) + P_{coef} \times (P_f - P_{cal}) + t_0$$

where:

T<sub>f</sub> = flowing temperature, in °C

T<sub>coef</sub> = temperature coefficient, in μsec/°C

P<sub>f</sub> = flowing pressure, in kPag

P<sub>coef</sub> = pressure coefficient, in μsec/ kPag

P<sub>cal</sub> = calibration pressure, in kPag

K = spool calibration constant

**UGC Density (Kgs/m<sup>3</sup>)**

UGC density is calculated using the frequency signal produced by a UGC densitometer, and applying temperature and pressure corrections as shown below:

**UNCORRECTED DENSITY:**

$$D = K_0 + (K_1 \times t) + (K_2 \times t^2)$$

Where:

D = uncorrected density, in Kgs/m<sup>3</sup>

$\left. \begin{matrix} K_0 \\ K_1 \\ K_2 \end{matrix} \right\} = \text{calibration constants of density probe, entered via the keypad}$

t = densitometer oscillation time period, in microseconds (μsec)

**CORRECTED DENSITY:**

$$D_c = D_{CF} \times \left\{ \left[ \left( K_{P_3} D^2 + K_{P_2} D + K_{P_1} \right) \times (P_f - P_c) \right] + \left[ \left( K_{t_3} D^2 + K_{t_2} D + K_{t_1} \right) \times (T_f - T_c) \right] + D \right\}$$

Where:

D<sub>c</sub> = corrected density, in Kgs/m<sup>3</sup>

D<sub>CF</sub> = density correction factor

D = uncorrected density, in Kgs/m<sup>3</sup>

$\left. \begin{matrix} K_{P_1} \\ K_{P_2} \\ K_{P_3} \end{matrix} \right\} = \text{pressure constants}$

$P_f$  = flowing pressure, in kPag

$P_c$  = calibration pressure, in kPag

$\left. \begin{array}{l} K_{t_1} \\ K_{t_2} \\ K_{t_3} \end{array} \right\}$  = temperature constants

$T_f$  = flowing temperature, in °C

$T_c$  = calibration temperature, in °C

### **Solartron™ Density (Kgs/m<sup>3</sup>)**

Solartron™ density is calculated using the frequency signal produced by a Solartron frequency densitometer, and applying temperature and pressure corrections as detailed below.

#### **UNCORRECTED DENSITY:**

$$D = K_0 + (K_1 \times t) + (K_2 \times t^2)$$

Where:

$D$  = uncorrected density, in Kgs/m<sup>3</sup>

$\left. \begin{array}{l} K_0 \\ K_1 \\ K_2 \end{array} \right\}$  = calibration constants supplied by Solartron, in Kgs/m<sup>3</sup> and °C

$t$  = densitometer oscillation time period, in microseconds (μsec)

#### **TEMPERATURE COMPENSATED DENSITY:**

$$D_T = D \times [1 + K_{18} (T_f - 20)] + [K_{19} (T_f - 20)]$$

Where:

$D_T$  = temperature corrected density, in Kgs/m<sup>3</sup>

$D$  = uncompensated density, in Kgs/m<sup>3</sup>

$\left. \begin{array}{l} K_{18} \\ K_{19} \end{array} \right\}$  = calibration constants supplied by Solartron

$T_f$  = Temperature in °C

**TEMPERATURE AND PRESSURE COMPENSATED DENSITY:**

$$D_{PT} = D_T \times [1 + (K_{20} \times P_f) + (K_{21} \times P_f)]$$

Where:

$D_{PT}$  = temperature and pressure compensated density, in Kgs/m<sup>3</sup>

$D_T$  = temperature compensated density, in Kgs/m<sup>3</sup>

$$K_{20A} + (K_{20B} \times P_f)$$

$$K_{21} = K_{21A} + (K_{21B} \times P_f)$$

$\left. \begin{array}{l} K_{20A} \\ K_{20B} \\ K_{21A} \\ K_{21B} \end{array} \right\} = \text{calibration constants supplied by Solartron}$

$P_f$  = flowing pressure in kPag

**Additional Density Equation for Velocity of Sound Effects:**

For LPG Products in the range of 350 to 550 Kgs/m<sup>3</sup>, the following term can be applied to the temperature and pressure compensated density 'D<sub>tp</sub>':

$$D_{VOS} = D_{tp} + K_r (D_{tp} - K_j)^3$$

Where:

D<sub>VOS</sub> = density for velocity of sound effects, in Kgs/m<sup>3</sup>

D<sub>tp</sub> = temperature and pressure compensated density, in Kgs/m<sup>3</sup>

$\left. \begin{matrix} K_r \\ K_j \end{matrix} \right\}$  = calibration constants supplied by Solartron

Users wishing to implement the above term are advised to contact Solartron™ to obtain a reworked calibration sheet containing the coefficients 'K<sub>r</sub>' and 'K<sub>j</sub>'. (Typically, K<sub>r</sub> = 1.1 and K<sub>j</sub> = 500). If you do not want to implement the above term, enter 0.0 for K<sub>r</sub>.

## 5.4. Liquid Flow Rate for Provers

The calculations performed for unidirectional, bi-directional and small volume (compact) provers are as follows:

### 5.4.1. Prove Gross Flow Rate at Flowing Conditions (m<sup>3</sup>/hr)

**Gross Flow Rate for Uni- and Bi-directional Provers 'PQ<sub>v(U/B)</sub>'**

$$PQ_{v(U/B)} = \frac{Pf_{Hz}}{K_{Fnom}} \times 3600$$

**Gross Flow Rate for Small Volume (Compact) Provers 'PQ<sub>v(SVP)</sub>'**

$$PQ_{v(SVP)} = \frac{PV_b}{Td_{vol}} \times 3600$$

**Pulse Interpolation Method**

$$\text{Interpolated Counts} = \text{Integer Counts} \left( \frac{Td_{vol}}{Td_{fmp}} \right)$$

### 5.4.2. Nomenclature

$PQ_{V(U/B)}$  = prove gross flow rate at flowing conditions for uni- and bi-directional provers, in cubic meters per hour ( $m^3/hr$ )

$PQ_{V(SVP)}$  = prove gross flow rate at flowing conditions for small volume (compact) provers, in cubic meters per hour ( $m^3/hr$ )

$PV_b$  = base prover volume at 15°C and equilibrium pressure, in cubic meters ( $m^3$ )

$Pf_{Hz}$  = total number of flow pulses per second during the prove

$K_{F_{nom}}$  = nominal K factor, in pulses per barrel ( $f_{Hz}/m^3$ )—supplied by the flow transmitter manufacturer

$Td_{vol}$  = timer pulses accumulated between detectors switches (each pulse is 200 nanoseconds)

$Td_{fmp}$  = timer pulses accumulated between first flow pulse after each detector switches (each pulse is 200 nanoseconds)



### 5.4.3. Meter Factors for Provers



**Prove Meter Factor when Proving Propylene Product:** CPLM and CPLP are set to 1.0000. CTLM and CTLP are set to equal CCFM and CCFP respectively, where CCF is the ratio of density at flowing conditions to density at reference conditions, as per API MPMS 11.3.3.2.

*Note: API MPMS 11.3.3.2 requires input variables to be in US customary units of measure and provides flowing density in US units. The OMNI flow computer automatically converts metric units to and from US units and uses the algorithm as is.*



**Prove Meter Factor when Proving Ethylene Product -** All liquid correction factors are set to 1.0000. Meter factors are calculated based on mass flow at the meter versus mass in the prover

#### Prove Meter Factor 'PM<sub>F</sub>'

$$PM_F = \frac{PV_b \times C_{TSP} \times C_{PSP} \times C_{TLP} \times C_{PLP}}{\frac{Pf}{K_F} \times C_{TLM} \times C_{PLM}}$$

#### Prove Meter Factor when Proving with Mass Pulses 'PM<sub>Fm</sub>'

$$PM_F = \frac{PV_b \times C_{TSP} \times C_{PSP} \times \overline{\rho_f} \times D_F}{\frac{Pf}{K_F}}$$

Where:

PM<sub>F</sub> = prove meter factor (dimensionless)

PV<sub>b</sub> = base prover volume

Pf = number of flow pulses during the prove

$\overline{\rho_f}$  = average fluid (live) density at flowing conditions (actual temperature and pressure), in kilograms per cubic meter (Kgs/m<sup>3</sup> —see 5.3 this chapter)

#### If Prover Densitometer Not Used:

$$\text{Prover Density} = \text{Meter Density} \times \frac{C_{TLP} \times C_{PLP}}{C_{TLM} \times C_{PLM}}$$

D<sub>F</sub> = densitometer density factor

C<sub>TSP</sub> = correction factor for effects of temperature on steel at the prover

#### For Uni- and Bi-directional Provers:

$$C_{TSP} = 1 + \left[ (\overline{T} - \overline{T}_b) \times t_{coef_p} \right]$$

**For Small Volume (Compact) Provers:**

$$C_{TSP} = \left( 1 + \left[ (\bar{T} - \bar{T}_b) \times t_{coef_p} \right] \right) \times \left( 1 + \left[ (\bar{T}_i - \bar{T}_b) \times t_{coef_i} \right] \right)$$

Where:

 $\bar{T}$  = average prover temperature, in °C $\bar{T}_i$  = average prover switch rod temperature, in °C $\bar{T}_b$  = average base prover temperature, in °C $t_{coef_p}$  = square coefficient of expansion per °C of the prover tube $t_{coef_i}$  = linear coefficient of cubical expansion per °C of the prover switch rod

CPSP = correction factor for effects of pressure on steel at the prover

$$= 1 + \frac{(P - P_b) \times D}{E \times t}$$

Where:

P = internal prover pressure, in kPag

P<sub>b</sub> = base prover pressure, in kPag

D = internal prover tube diameter, in mm

E = modulus of elasticity for prover tube

t = wall thickness of prover tube, in mm

C<sub>TLP</sub> = correction factor for effects of temperature on liquid (volume correction factor) at the prover= volume correction factor 'V<sub>CF</sub>', where the actual temperature 'T<sub>a</sub>' is replaced by the average temperature during the prove, at the prover (see 5.2.1 this chapter)C<sub>PLP</sub> = correction factor for effects of pressure on liquid at the prover= correction factor for pressure on liquid 'C<sub>PL</sub>', where the flowing pressure 'P' is replaced by average pressure during the prove, at the prover (see 5.2.2 this chapter)C<sub>TLM</sub> = correction factor for effects of temperature on liquid (volume correction factor) at the flowmeter= volume correction factor 'V<sub>CF</sub>', where the actual temperature 'T<sub>a</sub>' is replaced by the average temperature during the prove, at the flowmeter (see 5.2.1 this chapter)C<sub>PLM</sub> = correction factor for effects of pressure on liquid at the flowmeter= correction factor for pressure on liquid 'C<sub>PL</sub>', where the flowing pressure 'P' is replaced by average pressure during the prove, at the flowmeter (see 5.2.2 this chapter)

## 5.5. Calculations for PID Control

### 5.5.1. Primary Variable Error % 'e<sub>p</sub>'

#### Forward Action

$$e_p = \text{Primary Setpoint \% Span} - \text{Primary Variable \% Span}$$

#### Reverse Action

$$e_p = \text{Primary Variable \% Span} - \text{Primary Setpoint \%}$$

### 5.5.2. Secondary Variable Error % 'e<sub>s</sub>'

#### Forward Action

$$e_s = \text{Secondary Gain} \times (\text{Sec. Setpoint \% Span} - \text{Sec. Variable \% Span})$$

#### Reverse Action

$$e_s = \text{Secondary Gain} \times (\text{Sec. Variable \% Span} - \text{Sec. Setpoint \% Span})$$

### 5.5.3. Control Output % 'C<sub>0</sub>' (Before Startup Limit Function)

#### Controlling on Primary Variable

$$C_0 = \text{Primary Gain} \times (e_p + \sum e)$$

#### Controlling on Secondary Variable

$$C_0 = \text{Primary Gain} \times (e_s + \sum e)$$

### 5.5.4. Integral Error 'Σe'

#### Controlling on Primary Variable

$$\sum e = (\text{Repeats per Minute of Primary Variable} \times \text{Sample Period} \times e_p) + \sum e_{n-1}$$

#### Controlling on Secondary Variable

$$\sum e = (\text{Repeats per Minute of Sec Variable} \times \text{Sample period} \times e_s) + \sum e_{n-1}$$